



Multimedia Storage Viewer P-4000

User's Guide

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. The information contained herein is designed only for use with this Epson product. Epson is not responsible for any use of this information as applied to other products.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

Seiko Epson Corporation shall not be held liable for any damage resulting from electromagnetic interference that occurs from the use of any interface cables other than those designated as Epson Approved Products by Seiko Epson Corporation.

EPSON® is a registered trademark and EPSON Stylus™ is a trademark of Seiko Epson Corporation.

Copyright 2002 Seiko Epson Corporation. All rights reserved. USB DIRECT-PRINT™ is a trademark of Seiko Epson Corporation. The USB DIRECT-PRINT logo is a trademark of Seiko Epson Corporation.

Microsoft® and Windows® are registered trademarks of Microsoft Corporation.

Apple® and Macintosh® are registered trademarks of Apple Computer, Inc.

SD™ is a trademark.

QuickTime and the QuickTime logo are trademarks or registered trademarks of Apple Computer, Inc., used under license.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

Copyright © 2005 Seiko Epson Corporation. All rights reserved.

Contents

Chapter 1 Introduction

Main Features	6
Important Safety Instructions	7
Warnings, Cautions, and Notes	7
When using P-4000	7
When using the battery	8
When Storing the batteries	9
When Disposing of the batteries.....	9
When using the AC adapter	10
When using a memory card	12
When using the LCD	12
When storing, maintaining, or transporting P-4000.....	12
Safety information for United Kingdom users...	13
For United Kingdom, Hong Kong, and Singapore users	13

Chapter 2 Getting Started

Unpacking Your P-4000	14
Parts	15
Setting Up the P-4000	17
Charging the battery.....	17

Turning the power on	20
Turning the power off.....	21
Holding the button operations	22
How to use the Home screen.....	22
About the stand	23

Chapter 3 Using Memory Cards

Setting and Removing a Memory Card	24
Available types of memory cards	24
Setting a memory card into the CF Card slot	25
Removing a memory card from the CF Card slot.....	25
Setting a memory card into the SD Card slot	26
Removing a memory card from the SD Card slot.....	26
Copying Data from a Memory Card to P-4000	27

Chapter 4 Viewing and Playing Data

Viewing Images	29
Available types of image data	29
How to see the screen	30

Displaying images	31
Displaying images as a slide show	35
Playing Videos/Audio	35
Available types of video/audio data	35
Playing videos/audio with P-4000	37
Using buttons while playing videos/audio	37

Chapter 5 Managing Data

Using the Albums	39
About the PC_DATA folder	39
Copying the favorite data to an album	40
Creating a new album	42
Changing an album's name	43
Deleting an album	44
Setting an album shortcut	45
Deleting Data	46
Protecting Data	48
Setting an Album/Folder Thumbnail	49
Using the Pop Up Menu	49
Settings available in the pop up menu	49

Chapter 6 Direct Printing

Preparing to Print	51
Supported printers	51
Available types of paper	51
Connecting P-4000 to a printer	51

Printing Images	53
Printer settings	54
Set print quantities	54

Chapter 7 Using P-4000 With Other Devices

Using P-4000 With a Computer	56
Connecting P-4000 to a computer	56
Disconnecting P-4000 from a computer	58
Using A/V Out	58

Chapter 8 Customizing Settings

Changing the P-4000 Settings	60
--	----

Chapter 9 Operating the Software

System Requirements	62
For Windows	62
For Macintosh	62
About the Software	63
Installing the Software	63
For Windows users	63
For Macintosh users	64
Starting the Software	64
For Windows	64
For Macintosh	65
Uninstalling the Software	65

Finding More Information	65	About Optional Accessories	75
------------------------------------	----	--------------------------------------	----

Chapter 10 Maintenance and Troubleshooting

Cleaning the P-4000	66
Troubleshooting	66
Error messages/Icons	66
Problems and solutions	67
Power supply problems	68
Viewing and playing problems	68
Data operation problems	69
Printing problems	70
Resetting P-4000	70
Contacting Customer Support	71
Technical Support Web Site	71

Appendix A Appendix

Standards and Approvals	72
P-4000 (Model: G941B)	72
AC adapter (Model: A351H)	72
Battery (Model: D111A)	73
Specifications	73
General	73
Electrical	74
Interface	74
Battery	74
AC adapter	74

Introduction

Main Features

With P-4000, you can easily view, keep, and print images you have taken with a digital camera. You can also play videos and audio. The main features are described below.

- ❑ **Epson Photo Fine**
Epson Photo Fine is a high-resolution liquid crystal display. You can view images easily in high resolution anywhere, anytime without a computer or other special device.
- ❑ You can play videos and audio easily anywhere, anytime without a computer or other special device.
- ❑ You can print images directly to your Epson printer that supports USB DIRECT-PRINT.
- ❑ You can save images, videos, and audio in P-4000.

Note:

- ❑ *Do not expose the P-4000 to severe impact, doing so may cause malfunctions especially during turning operations.*
- ❑ *We strongly recommend you back up files stored on the HDD to another storage device periodically.*
- ❑ *Epson is not liable for any problems resulting from the loss or corruption of data on the HDD.*

Important Safety Instructions

Read all of these instructions before using P-4000, and keep this guide handy for later reference. Follow all warnings and instructions marked on P-4000 and the options.

Warnings, Cautions, and Notes



Warnings

must be followed carefully to avoid bodily injury.



Cautions

must be observed to avoid damage to your equipment.

Notes

contain important information and useful tips on the operation of your product.

When using P-4000

- ❑ Follow all warnings and instructions marked on this product.
- ❑ Use only AC adapter model A351H and Li-ion battery model D111A with this product.
- ❑ When connecting this product to a computer or other device with a cable, ensure the correct orientation of the connectors. Each connector has only one correct orientation. Inserting a connector in the wrong orientation may damage both devices connected by the cable.
- ❑ Do not insert objects into the slots or openings on this product.
- ❑ Do not touch the components inside this product unless instructed to do so in the user documentation. Never force this product's components into place. Although this product is designed to be sturdy, rough handling can damage it.
- ❑ Never spill liquid onto this product.
- ❑ If this product emits unusual noises, odors, or smoke, cancel the current operation and turn it off immediately. Remove the battery and disconnect the AC adapter from the product, then unplug the AC adapter from the power outlet. Contact our Customer Support.
- ❑ To prevent fire or electric shock, do not cover this product with a blanket or other covering that may give off a static electric shock.

- ❑ To prevent fire or electric shock, do not expose this product or its options to rain or moisture.
- ❑ To prevent fire or explosion, do not use this product where flammable or volatile gas is stored.
- ❑ Do not use this product outdoors during a thunderstorm.
- ❑ Do not use this product after moving it between extreme temperatures, which may cause condensation to form on electronic parts.
- ❑ If you use this product in places where the use of electronic devices is limited, such as in airplanes or hospitals, follow all instructions in those places.
- ❑ Use only AC adapter model A351H and P-4000 (Model G941B) to charge batteries.
- ❑ Do not use the battery that comes with this product for other devices.
- ❑ To protect against short-circuiting, do not remove the outside case of the battery.
- ❑ Do not handle the battery with wet hands or use them near water.
- ❑ Do not expose the battery to water or high humidity.
- ❑ Do not drop, puncture, disassemble, mutilate, or short-circuit the battery.

- ❑ Do not place the battery near or into fire or water.
- ❑ Do not use batteries that are leaking or damaged in any way.
- ❑ Do not charge the battery on devices except this product.
- ❑ Do not charge the battery near open flame or in very hot locations.
- ❑ Keep batteries away from heat sources.

When using the battery

- ❑ If battery acid gets into your eyes or on your skin, immediately rinse the affected area thoroughly with water and seek medical treatment. If a battery is swallowed, seek medical treatment immediately.
- ❑ Use only an Epson Li-ion battery for P-4000 according to the directions in the user documentation.

- ❑ Do not leave the battery in a vehicle to prevent the battery from overheating.
- ❑ Do not insert objects into any openings as they may touch dangerous voltage points or short-circuit components.
- ❑ Prevent the battery from coming into contact with metal objects that could short-circuit it, such as coins or keys.
- ❑ Do not insert the battery into power outlets or other power sources such as car cigarette lighter sockets.
- ❑ Do not solder wires or terminals directly to the battery.
- ❑ Do not touch battery terminals.
- ❑ Keep batteries away from open flame if they leak or smell strange.
- ❑ If overheating, discoloration, or distortion occur, remove the battery from this product and do not use it.
- ❑ Charge the battery before using it if it has not been used for a long period.

When Storing the batteries

- ❑ When not using this device for a long period, remove the batteries from this product and store them separately.
- ❑ Do not store batteries where the temperature or humidity is very high.
- ❑ Store batteries out of children's reach.

When Disposing of the batteries

Before disposing of batteries, make sure you discharge them completely.



Warning:

- ❑ *Be sure to securely cover the all end of the battery with tape to prevent combustion or explosion when disposing.*
- ❑ *Do not dispose of batteries as ordinary refuse. Instead, dispose of them in a collection or recycle box in accordance with local laws.*
- ❑ *Do not incinerate or dispose of the battery in fire.*

For European users:

Do not dispose of batteries with ordinary refuse. Instead, dispose of them in a recycle box in accordance with local laws.



For users in the United States and Canada:



This mark indicates that the battery will be recycled by RBRC. When you dispose of the battery, contact RBRC.

When using the AC adapter

- ❑ Use only the type of power source indicated on the AC adapter's label, and always supply power directly from a standard, domestic power outlet with a power cord that meets the relevant local safety standards. If you are not sure of the power supply specifications in your area, contact your local power company or contact our Customer Support.
- ❑ Place the AC adapter near an electrical outlet where the power cord can be easily unplugged.
- ❑ The AC adapter and AC power cable are designed for use and provided with this product. Do not attempt to use them with other electronic devices unless specified.
- ❑ Do not remove the AC adapter from this device during operations (connecting the AC adapter during operations is possible).
- ❑ The AC adapter included is designed for use with this product. Use of any other adapter could result in fire, electrical shock, or injury.
- ❑ Use only AC adapter model A351H with P-4000.
- ❑ Make sure the total amperage of all devices plugged into the power outlet does not exceed the power outlet's ampere rating.
- ❑ Do not connect the AC adapter when the battery is not installed. Otherwise, P-4000 may be damaged.

- ❑ If you plan to use this product in Germany, the building installation must be protected by a 16 amp circuit breaker to provide adequate short-circuit protection and over-current protection for this product.
- ❑ Do not use a damaged or frayed AC adapter.
- ❑ If you use an extension cord with this product, make sure the total amperage of all devices plugged into the extension cord does not exceed the cord's amperage rating.
- ❑ Never disassemble, modify, or attempt to repair the AC adapter by yourself except as specifically explained in this guide.
- ❑ Do not use power outlets controlled by wall switches or automatic timers.
- ❑ Do not use power outlets on the same circuit as large motors or other appliances that may cause voltage fluctuations.
- ❑ Avoid using outlets on the same circuit as photocopiers or air control systems that regularly switch on and off.
- ❑ To prevent fire or electric shock, do not cover the AC adapter with a blanket or similar covering.
- ❑ Position this product's power cord so that it will not be stepped on or run over.
- ❑ Do not place any objects on the power cord and the AC adapter.
- ❑ Keep the power cord straight at the ends and at the points where it enters the transformer.
- ❑ The power cord should be placed to avoid abrasions, cuts, fraying, crimping, kinking, and other damage.
- ❑ If the AC plug does not fit your outlet, have a proper outlet installed by a qualified electrician.
- ❑ Remove the AC plug from the outlet during lightning storms.

For US and Canadian users:

Use the included power cord or a 6 to 10 foot UL-approved type SPT-2 or heavier type, 2× 18 AWG cord with a 125 V 10 A plug and 125 V 7 A connector.

When using a memory card

- ❑ Only memory cards designed for the product's specifications can be used.
- ❑ Do not remove a memory card or turn off the product while the Access lamp is flashing. See "LCD and control panel" on page 16 to find where the Access lamp is.

When using the LCD

- ❑ The LCD panel on this product may contain a few small bright or dark spots. These are normal and do not mean that your LCD panel is damaged in any way.
- ❑ If the LCD panel on this product is damaged, consult your dealer.
- ❑ If the liquid crystal solution contained in the LCD panel on this product leaks out and gets onto your hands, wash them thoroughly with soap and water. If it gets into your eyes, flush them immediately with water. If discomfort or vision problems remain after a thorough flushing, see a doctor immediately.

- ❑ Only use a soft, dry cloth to clean the display. Do not use liquid or chemical cleaners.

When storing, maintaining, or transporting P-4000

- ❑ Do not store this product outdoors.
- ❑ Do not store this product near water.
- ❑ Do not store this product in a location subject to high temperature or humidity.
- ❑ Do not store this product in a location subject to rapid changes in temperature or humidity.
- ❑ Do not store this product in a location subject to direct sunlight or strong light sources.
- ❑ Unplug this product from the power outlet before cleaning it. Use a damp cloth for cleaning and do not use liquid or aerosol cleaners.

- ❑ Remove the battery from and unplug this product and refer servicing to qualified service personal under the following conditions: The power cord or plug is damaged; liquid has entered this product or its options; this product or its options have been dropped or the case is damaged; this product or its options do not operate normally or exhibit a distinct change in performance.

Safety information for United Kingdom users

The following safety information applies to the AC adapter.



Warning:

Refer to the rating plate for the voltage and check that the appliance voltage corresponds to the supply voltage.

Important:

The wires in the mains lead fitted to this appliance are colored in accordance with the following code:

Blue — Neutral

Brown — Live

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows;

The blue wire must be connected to the terminal in the plug marked with the letter N.

The brown wire must be connected to the terminal in the plug marked with the letter L.

If damage occurs to the plug, replace the cord set or consult a qualified electrician.


For United Kingdom, Hong Kong, and Singapore users

Replace fuses only with fuses of the correct size and rating.


Getting Started

Unpacking Your P-4000


Make sure that all of the items shown below were included in the box with your P-4000.




P-4000



Stand



Carrying case




USB cable



Strap



Lithium-ion battery




Power cable*



AC adapter



User's Guide (this guide)




Software CD-ROM


* The plug type for the power cable may vary, depending on the local standards.

Parts


Front



Back



LCD and control panel



Print button	Press this button to display the Print menu.
Menu button	Press this button to display the pop up menu. For details, see "Using the Pop Up Menu" on page 49.
Charge lamp (Green)	On when the battery is being charged.

Access lamp (Orange)	Flashes when accessing data on the HDD or a memory card.
4-way ring (Up/ Down/Left/Right button)	Press this button to move the cursor or highlight. You can select an object by pressing this button to the right, left, up, or down.
Illumination lamp (Blue)	Flashes during such operations as turning the power on, or during printing. The light also flashes when P-4000 is in the LCD power-off mode.
OK button	Press this button to determine the selection and proceed to the next step.
Cancel button	Press this button to cancel the selection and return to the previous screen.
Display button	Press this button to display information, instructions, or messages.

Home button	Press this button to go back to the Home screen.
-------------	--


Setting Up the P-4000

After unpacking your P-4000, set it up so it is ready to use. This section describes how to charge the battery and turn the power on and off.

Charging the battery


Installing the battery

1. Slide the battery cover to the left.




The battery cover opens.

2. Insert the battery into the compartment in the direction of the arrow on the battery.



3. Close the battery cover and slide it to the right until it clicks.



Charging the battery

After installing the battery, charge the battery using the AC adapter.

Note:

The battery status is always displayed at the top right corner of the LCD.

- : Indicates sufficient battery power.
- : Indicates moderate battery power.
- : Indicates low battery power.
- : Indicates battery power is running out. P-4000 is shut down automatically. Charge the battery using the AC adapter.
- : Indicates the AC adapter is connected to P-4000.


1. Make sure that the battery is installed.



Caution:

Do not connect the AC adapter when the battery is not installed. Doing so may cause P-4000 to be damaged.

2. Connect the AC adapter to P-4000 as shown below and plug the other end into a power outlet.



The Charge lamp is on during charging. When the battery is fully charged, the Charge lamp turns off. It takes about 3 hours to fully charge the battery when P-4000 is off. It takes more when you are operating it.

Note:

P-4000 stops charging, if the battery becomes hot when operating it during charging. In that case, it starts charging again when it cools down.

Removing the battery


1. Make sure that P-4000 is turned off.



Caution:


- ❑ Remove the AC adapter if it is connected to P-4000.
- ❑ Never remove the battery while P-4000 is turned on. Doing so may cause data in the card or HDD to be lost or damaged.

2. Open the battery cover.
3. Push the catch down.



The battery is pushed out.

4. Pull out the battery. Then close the battery cover.




Warning:

Do not carry loose batteries in your pockets.

Turning the power on


Slide the power switch to  as shown below. The power switch will return to the original position.




The illumination lamp turns on.

When you turn on P-4000 the first time, the Language setting screen and Date and time settings screen are displayed. Follow the instructions below.

1. The Language setting screen appears. Select the language you want to use with the 4-way ring, and press the OK button.



2. The Date and time settings screen appears. Press the Right or Left button on the control panel to change the value of the selected item.




3. After you finish making the setting, select a different item by pressing the UP or Down button on the control panel.
4. Repeat steps 2 and 3 until you finish making the date and time settings.
5. After you finish making all settings, press the OK button.

Note:

- ❑ *If you remove the battery from P-4000, the date and time settings will be erased after approximately one day at the most.*
- ❑ *If the date and time settings are erased, the Date and time settings screen is displayed when you turn on P-4000 next time.*
- ❑ *After changing the battery, make sure that the date and time is set correctly. If necessary, set the date and time again.*
- ❑ *You can change the settings later. See “Changing the P-4000 Settings” on page 60 for details about setting the date and time settings.*


Turning the power off

1. Make sure that the Access lamp is off.
2. Slide the power switch to  as shown below and hold it down for several seconds until the illumination lamp turns off. The power switch will return to the original position.



Holding the button operations

You can make the buttons of P-4000 ineffective temporarily by sliding the power switch to HOLD as shown below.




Note:

- ❑ To deactivate hold, slide the power switch back to the middle.
- ❑ Putting the button operations on hold is a useful function when you put P-4000 in your bag while listening to audio with the headphones.

How to use the Home screen

When turning P-4000 on, the Home screen appears first. All the operations can be started from this screen. You can return to the Home screen by pressing the Home button.



Battery icon


Indicates the remaining charge in the battery. See “Charging the battery” on page 17 for details.

Saved Data	Select to display folders that include data saved in P-4000 from memory cards.
Latest Data	Select to display the latest data saved in P-4000 from a memory card.
Albums	Select to display albums. See “Using the Albums” on page 39 to find information on the albums.
Album shortcut	Select to access a favorite album. You can set a shortcut icon for an album. See “Setting an album shortcut” on page 45 for details.
Memory Card	Select to display or copy data in the memory cards.
Settings	Select to set P-4000’s various settings.

You can also use the pop up menu by pressing the Menu button. For details, see “Using the Pop Up Menu” on page 49.

About the stand

You can use the stand when you view images and play movies. Set P-4000 to the stand as shown below.



Using Memory Cards

Setting and Removing a Memory Card

P-4000 provides you with the CF Card slot and SD Card slot.

This section describes how to set memory cards and copy data from them.



Caution:

- ❑ *To use a memory card correctly, read manuals provided with the memory card.*
- ❑ *Never remove a memory card while the ACCESS lamp flashes. Doing so may cause data in the card or HDD to be lost or damaged.*
- ❑ *Do not put stickers on memory cards. The sticker may peel off, preventing the card from being ejected and damaging P-4000.*
- ❑ *Avoid using or storing the card in direct sunlight, or in places that are extremely hot, humid, or dusty.*

Available types of memory cards

The following memory cards are available.

- ❑ CF (CompactFlash) memory card (Type1/Type2 and 3.3 V, including Micro Drive)
- ❑ SD memory card
- ❑ MultiMedia Card


Note:

A commercially available CF adapter is needed to use other memory cards. Contact our customer support for details.

Setting a memory card into the CF Card slot

You can set a CF card or other card with the CF adapter in the CF Card slot.

Insert the memory card into the memory card slot with the back side up to the LCD side. Then push the memory card fully into the slot.



Note:

Insert memory cards in the correct direction. Otherwise, the memory card and P-4000 may be damaged.

Removing a memory card from the CF Card slot


1. Make sure that the Access lamp is off.



Caution:

Never remove a memory card while the Access lamp flashes. Doing so may cause data in the card to be lost or damaged.

2. Push the eject button down and it comes out. Then push it again.



3. The memory card is pushed out. Pull out the memory card.

Note:

When using the memory card set in the CF adapter, do not remove only the memory card. Remove the CF adapter from the P-4000.


Note:

Insert memory cards in the correct direction. Otherwise, the memory card and P-4000 may be damaged.

Setting a memory card into the SD Card slot

You can set an SD memory card or MultiMedia card in the SD Card slot.

Insert the memory card into the memory card slot with the back side up to the LCD side. Then push the memory card fully into the slot.



Removing a memory card from the SD Card slot


1. Make sure that the Access lamp is off.



Caution:

Never remove a memory card while the Access lamp flashes. Doing so may cause data in the card to be lost or damaged.

2. Push the top part of the memory card.



3. The memory card is pushed out. Pull out the memory card.


4. In the Memory Card operation screen, select Copy Data from Memory Card by using the Up or Down button and press the OK button.

Copying Data from a Memory Card to P-4000

Note:

When the battery is low, copying may not be completed. Use the AC adapter if this happens.

1. Set the memory card.
2. Select Memory Card in the Home screen and press the OK button.
3. If necessary, select the memory card from which you wish to copy the data.



Note:

- *If you wish to make an album after copying, select Create Album After Copying Data and press the OK button. Then select an album in which to copy the data, or create a new album. See “Creating a new album” on page 42 for instructions on creating a new album.*

- ❑ *The confirmation dialog box below appears if the Delete Data After Copying setting in Copy Mode settings is set to Confirm. For details, see “Changing the P-4000 Settings” on page 60.*



The data you selected are copied in a folder that is automatically made in P-4000. The folder is named according to the date, for example “20030325.XXX.” XXX is the number assigned according to the copying order.

Note:

You can also copy data from P-4000 to a memory card by using the pop up menu. See “Using the Pop Up Menu” on page 49 for details.

5. Copying starts and the following dialog box appears.



Chapter 4

Viewing and Playing Data

Viewing Images

This section describes how to view images in the P-4000's HDD or the memory cards. When you would like to manage the data while connected to your computer, see "Using P-4000 With a Computer" on page 56.

Available types of image data

P-4000 supports images in the following format.

Supported Files	Extension	Details
JPEG*	.jpg .jpeg	Minimum size: 160 × 120 pixels Maximum size: 17.8 megapixels Maximum image aspect ratio: 8 : 1
TIFF	.tif .tiff	TIFF files that have been scanned with EPSON F-3200 Scanner. (displayed only as thumbnails)

Supported Files	Extension	Details
RAW**	.nef .crw .erf .cr2 .mrw .pef .orf***	JPEG data stored in the header of RAW files are displayed.



* The progressive JPEG format is not supported.

** P-4000 supports images in RAW format that you have taken with a digital camera produced by Nikon, Canon, KONICAMINOLTA, PENTAX, or Epson.

***RAW formatted images taken with an OLYMPUS digital camera can be displayed only as thumbnails.

How to see the screen

When you use the P-4000, you will find many icons on the screen. The illustration below shows what those icons indicate.



a	Indicates the PC_DATA folder. See "About the PC_DATA folder" on page 39 for details.
b	Indicates the battery status. See "Charging the battery" on page 18 for details.
c	Indicates a folder that includes an audio file and does not include image or video files.
d	Indicates that the album is set as an album shortcut.
e	Indicates a folder that was made on a computer and copied to an album in P-4000.
f	Indicates a supported movie file.
g	Indicates an image file in TIFF format.
h	Indicates an image file with P.I.F. frame.*
i	Indicates unsupported data, such as a document.**
j	Indicates an unsupported image file.
k	Indicates that the data is locked. See "Protecting Data" on page 48 for details.
l	Indicates an image file in RAW format.
m	Indicates that the print order setting is set for the image. The number next to the icon indicates the print quantity.
n	Indicates a supported audio file.

* P.I.F. icons are displayed only in Saved Data.

** You can set whether unsupported files are displayed or not. The factory setting is Hide. See "Changing the P-4000 Settings" on page 60 for details.

Note:

- ❑ *Files whose names contain characters other than alphanumeric are not displayed.*
- ❑ *When you select an album, data and subfolders included directly in the selected folder are displayed. Subfolders are displayed as  icon.*
- ❑ *When you select a folder in the Saved Data, all data including data in subfolders are displayed and subfolders are not displayed.*
- ❑ *Information or instructions are displayed by pressing the Display button. Information and instructions vary depending on the screen when you press the Display button.*

Displaying images

You can display all images in the Saved Data, Albums, or memory cards as thumbnails. You can also display an image in full-screen format by selecting the specified image from the listed images.

1. If you want to view images in a memory card, make sure that you set the memory card in the card slot.


2. For images in P-4000, select Saved Data or Albums in the Home screen, press the OK button, and go to step 5.

For images in the memory card, select Memory Card in the Home screen, press the OK button, and go to the next step.

**Note:**

You can also access the latest saved folder by selecting Latest Data. When you select Latest Data, go to step 6.


3. Select the memory card that includes the images that you want to view.



Note:

This screen is displayed only when two memory cards are set.

4. In the Memory Card operation screen, select Browse the Memory Card by using the Up or Down button, and press the OK button. Skip the next step and go to step 6.




5. Folders or albums including data such as images, videos, or audio appear. Select the folder or album which includes images you want to view by using the 4-way ring, and press the OK button.



Note:

- ❑ In the *Saved Data* screen, folders are displayed as grouped for every memory card. You can change the setting to display folders as grouped for every saved date. See “Using the Pop Up Menu” on page 49 or “Changing the P-4000 Settings” on page 60 for details.
- ❑ Holding the Up or Down button for a few seconds switches pages without moving the highlight.

6. Thumbnails of the images and other data are displayed. Select the image you want to view, and press the OK button.

**Note:**

Holding the Up or Down button for a few seconds switches pages without moving the highlight.

7. The selected image is enlarged to fit the full screen.

**Note:**

Pressing the Right displays the next image and pressing the Left button displays the previous image. Video, audio, and unsupported data are skipped.

Functions when displaying an image in the full screen

When you display an image in the full screen, the following functions are available.

Zooming in an image

Press the OK button. The image is zoomed in.

Note:

- ❑ Pressing the Cancel button zooms out the image.
- ❑ Pressing the Cancel button for a few seconds zooms the image out to the full screen.
- ❑ You can move the part of the image displayed by pressing the 4-way ring.

Rotating an image

Note:

This function is available only for images in albums.

1. Press the Menu button to display the pop up menu, then select Rotate.
2. The ► icon is displayed next to Rotate. Press the Right button.
3. The sub menu appears. Select Right to rotate the image 90° clockwise or Left to rotate it 90° counterclockwise.

Note:


- ❑ You can select other images in the folder to rotate by selecting Right-Select or Left-Select in the sub menu.

- ❑ You cannot rotate the JPEG files larger than 8.9 megapixels.

4. Press the OK button. Rotating the image starts.

Displaying information

Press the Display button. Exif information on the image is displayed. You can switch the displayed information to the histograms or operating instructions by pressing the Display button.




Displaying images as a slide show

You can display images in a folder or memory card as a slide show.

Note:

- ❑ Only images in the JPEG format can be displayed as a slide show.
 - ❑ It may take a long time to display depend on an image you select.
1. Select a folder or data you want to display as a slide show.
 2. Press the Menu button to display the pop up menu. Then select Start Slide Show and press the OK button.



The slide show starts.

Note:

- ❑ The slide show effect, duration, and BGM (Back Ground Music) can be selected. See “Using the Pop Up Menu” on page 49, or “Changing the P-4000 Settings” on page 60 for details.
- ❑ When BGM is set, you can turn the volume up or down by pressing the Up or Down button.

Playing Videos/Audio

This section describes how to play videos and audio in the P-4000's HDD or the memory cards.

Available types of video/audio data

P-4000 supports video/audio data in the following format.

Video

File Format	Video codec	Audio codec	Detail*
AVI	MPEG4 (Simple Profile)	AAC MP3	Minimum resolution: 160 × 112 pixels Maximum resolution: 640 × 480 pixels Maximum bit rate: 2.5 Mbps (Ave.) (at 30 fps)
	Motion-JPEG	ALaw μLaw PCM	Minimum resolution: 160 × 112 pixels Maximum resolution: 640 × 480 pixels Maximum bit rate: 3 Mbps
MOV	MPEG4 (Simple Profile)	AAC	Minimum resolution: 160 × 112 pixels Maximum resolution: 640 × 480 pixels Maximum bit rate: 2.5 Mbps (Ave.) (at 30 fps)
	Motion-JPEG	ALaw μLaw PCM	Minimum resolution: 160 × 112 pixels Maximum resolution: 640 × 480 pixels Maximum bit rate: 3 Mbps
MP4	MPEG4 (Simple Profile)	AAC	Minimum resolution: 160 × 112 pixels Maximum resolution: 640 × 480 pixels Maximum bit rate: 2.5 Mbps (Ave.) (at 30 fps)

File Format	Video codec	Audio codec	Detail*
ASF	MPEG4 (Simple Profile)	ADPCM	Minimum resolution: 160 × 112 pixels Maximum resolution: 640 × 480 pixels Maximum bit rate: 2.5 Mbps (Ave.) (at 30 fps)

* P-4000 supports video data of up to 2 GB.

Audio

File Format	Audio codec	Detail*
M4A	AAC (MPEG4)	Maximum bit rate: 320 kbps (48 kHz, 16 bit Stereo)
MP3	MP3	Maximum bit rate: 320 kbps (48 kHz, 16 bit Stereo)

* P-4000 supports audio data of up to 100 MB.

Note:

- ❑ *Some data cannot be played with P-4000 depending on the files.*
- ❑ *WMV, MPEG1/2, and DVD-Video are not supported.*

Playing videos/audio with P-4000

Select a video or audio that you want to play in the P-4000 or a memory card, and press the OK button.



The selected video or audio starts playing.

Note:

- ❑ All videos are played with the LCD resolution (640 × 480 pixel).
- ❑ When no key operations are performed for a few seconds while playing audio, the LCD turns off to conserve the battery. The LCD turns on when you press any button.
- ❑ You can register audio data as the slide show BGM using the pop up menu. See “Using the Pop Up Menu” on page 49 for details.

- ❑ You can listen to the audio using the headphones. When doing so, make sure that you insert the headphone cable into the headphone connector.

Using buttons while playing videos/audio

The tables below describe how the buttons work while playing videos/audio.

videos

Button	Function
OK button*	Pause the video
Cancel button	Stop the video and return to the previous screen.
Up button	Turn the volume up
Down button	Turn the volume down
Left button**	Rewind the video
Right button**	Forward the video

* You can start playing the video again by pressing the OK button while it is paused.

** Pressing the Left/Right button for a few seconds rewinds/forwards the video continuously.

Audio

Button	Function
OK button*	Pause the audio
Cancel button	Stop the audio and return to the previous screen.
Up button	Turn the volume up
Down button	Turn the volume down
Left button**	Skip back to the beginning of the audio that is currently playing. If you press the button at the beginning of the audio, the audio is skipped back to the previous one.
Right button**	Skip to the next audio.

* You can start playing the audio again by pressing the OK button while it is paused.

** Pressing the Left/Right button for a few seconds rewinds/forward the audio.

Chapter 5

Managing Data

Using the Albums


In the Albums, you can create albums copying your favorite images, videos, and audio from the Saved Data or a memory card and manage these data. You can classify and manage your data easily by making albums.

Albums already named exist as a default, and you can also name albums as you like.

For easy operation, you can create album shortcuts on the Home screen. See “Setting an album shortcut” on page 45 for details.

About the PC_DATA folder

In the Albums, PC_DATA folder exists as a default. When you copy data from your computer to P-4000 using the Explorer or Finder, copy data to the PC_DATA folder.




Note:

- ❑ The name of the PC_DATA folder cannot be changed.
- ❑ The PC_DATA folder cannot be deleted.

- ❑ You cannot set the data in the PC_DATA folder as an album thumbnail.

Copying the favorite data to an album

1. Select the data to be copied to an album in the thumbnails screen.



Note:


You can also select an image in full screen or a folder. In that case, go to the next step and skip 3 and 4.

2. Press the Menu button to display the pop up menu, and select Copy to Album by using the Up or Down button.




3. The ► icon is displayed next to Copy to Album. Press the Right button.

- The sub menu appears. If you want to copy only the selected data to an album, select This Data. If you want to copy all the data in the folder, select All. If you want to select the data to be copied, select Select. Then press the OK button.




Note:

When you select Select, data in the folder are displayed as thumbnails. Select the data you want to copy and press the OK button. The selected data is checked. After all the data you want to copy to an album are selected, press the Menu button.



- Select an album in which to copy the data, and press the OK button.




Copying to the album starts.

Note:


You can make a new album by selecting New. See the following “Creating a new album” for details.

Creating a new album

1. Follow steps 1 through 4 of “Copying the favorite data to an album” on page 40.
2. Select New and press the OK button.



3. If you want to use one of the preset album names, select the album's name from the displayed list, and press the OK button. Copying data to the album starts.




Note:

When you select a name which already exists, the new album is named with a number at the end of its name.

If you want to name the album yourself, select Text Input and press the OK button. Then go to the next step.

- The on-screen keyboard appears. Select a letter by using the 4-way ring and press the OK button to input the selected letter.




Note:

- To switch the letters between uppercase and lowercase, select CAPS and press the OK button.
 - To delete the last letter input, press the Cancel button or select BACKSPACE on the screen and press the OK button. To delete everything that was input, select Cancel on the screen and press the OK button.
- After you input the name, select OK on the screen by using the 4-way ring and press the OK button to fix it.


Changing an album's name

- Select an album that you want to change the name of, in the Albums.



- Press the Menu button to display the pop up menu.


3. Select Edit Album Name by using the Up or Down button, and press the OK button.




4. Follow steps 4 through 5 of “Creating a new album” on page 42.

Deleting an album


1. Select an album to delete in the Albums.



2. Press the Menu button to display the pop up menu, and select Delete Album by using the Up or Down button. Then press the OK button.



3. The confirmation dialog box appears. Select Yes and press the OK button.




Note:

If the deleted album was set as the album shortcut, the shortcut on the Home screen is also deleted.


Setting an album shortcut

You can create an album shortcut on the Home screen. The shortcut enables you to access your favorite albums easily.

1. Select an album that you want to make an album shortcut for.



2. Press the Menu button to display the pop up menu, and select Set as Album Shortcut by using the Up or Down button. Then press the OK button.




Note:

When you set an album as an album shortcut, ☆ icon is displayed on that album.

Deleting Data


1. Select the data that you want to delete in the thumbnails screen.



Note:


You can also select an image in full screen or a folder. In that case, go to the next step and skip 3 and 4.

2. Press the Menu button to display the pop up menu, and select Delete by using the Up or Down button.




3. The ► icon is displayed next to Delete. Press the Right button.


- The sub menu appears. If you want to delete only the selected data, select This Data. If you want to delete all the data in the folder, select All. If you want to select the data to be deleted in the folder, select Select. Then press the OK button.

**Note:**

When you select Select, data in the folder are displayed as thumbnails. Select the data you want to delete and press the OK button. The selected data is checked. After all the data you want to delete are selected, press the Menu button to delete the selected data.



5. The confirmation dialog box appears. Select Yes and press the OK button.



Protecting Data

You can lock the selected data or folder. When the item is locked, the  icon is displayed and cannot be deleted or rotated.

1. Select the data or folder that you want to lock.
2. Press the Menu button to display the pop up menu, and select Lock by using the Up or Down button. Then press the OK button.




Note:

The lock on the data remains in effect until you unlock it, even if you turn off the P-4000.

Setting an Album/Folder Thumbnail

You can set your favorite data as thumbnails for the album or folder in the Saved Data.


1. Select the data you want to set as the thumbnail for the album or folder in the Saved Data.
2. Press the Menu button to display the pop up menu, and select Set as the Album Thumbnail or Set as Folder Thumbnail by using the Up or Down button. Then press the OK button.



Using the Pop Up Menu

Pressing the Menu button displays the pop up menu.

The menu varies depending on the situation when you press the Menu button. See the following table for details.



Settings available in the pop up menu

Setting	Detail
Copy from Memory Card	Copy the selected data in a memory card to the HDD.
Copy to Album	Copy the selected data or folder to an album. See "Copying the favorite data to an album" on page 40 for details.

Setting	Detail
Copy to Memory Card	Copy the selected data or folder to a memory card.
Delete	Delete a selected data or folder. See "Deleting Data" on page 46 for details.
Delete Album	Delete the selected album. See "Deleting an album" on page 44 for details.
Display P.I.F. Frames*	Display the selected image with P.I.F. frame if the selected image includes the P.I.F. data. You can stop the P.I.F. mode by pressing the Cancel button.
Edit Album Name	Change the selected album's name. You can name it as you like using the on-screen keyboard. See "Changing an album's name" on page 43 for details.
Lock / Unlock	Lock or unlock the selected data or folder. See "Protecting Data" on page 48 for details.
Memory Card Basis / Daily Basis	Set how to display the folders in the Saved Data. Folders can be displayed as grouped for every memory card or every saved date.
Print Order	Set how many copies you wish to print of the selected images. See "Set print quantities" on page 54 for details.
Register to Slide show BGM	Register the selected audio data as the slide show BGM.
Rotate	Rotate a selected image in the album 90°. If a image is locked or has the auto-rotation Exif tag whose value is 2, 3, 4, 5, 6, 7, or 8, it cannot be rotated.

Setting	Detail
Set as Album Shortcut / Delete from Album Shortcut	Set the selected album as a shortcut that is displayed on the Home screen. You can set up to 3 shortcuts. Or, delete the selected shortcut. See "Setting an album shortcut" on page 45 for details.
Set as the Album Thumbnail / Set as Folder Thumbnail	Set the selected data as an album's / folder's icon.
Slide Show BGM**	Select the BGM which is played during the slide show.
Slide Show Duration**	Select the duration to switch the images during the slide show.
Slide Show Effect**	Select one of the five slide show effects. The slide show is executed with the selected effect.
Sort by Album Name	Sort albums by name.
Sort by Date	Sort albums by created date.
Start Slide Show	Images in the selected album or folder in Saved Data are displayed as a slide show. See "Displaying images as a slide show" on page 35 for details

* P.I.F is an abbreviation for Print Image Framer, which is a function that enables an image to have a frame. Most of the Epson digital cameras support this function.

** These settings are available only when a slide show is played.

Chapter 6

Direct Printing

Preparing to Print

You can print an image by connecting P-4000 directly to a printer. This section describes how to print the images on the P-4000.

Supported printers

P-4000 supports printers that are compatible with USB DIRECT-PRINT.

Available types of paper

P-4000 supports the following sizes and types of paper.

Paper	Size
Premium Glossy Photo Paper	4 × 6 in., 10 × 15 cm, 5 × 7 in., Letter, A4
Premium Semigloss Photo Paper	


Note:

For details about paper, see your printer's manuals.


Connecting P-4000 to a printer

The following procedure shows how to connect the P-4000 to the Stylus Photo R300/310. For other printers, refer to your printer's manual.


1. Make sure that P-4000 and the printer are turned off. Then remove the USB connector rubber cover.



2. Connect the USB cable to the P-4000.



3. Connect the other end of the USB cable to the connector on the printer.



Note:

- ❑ See your printer's manual for the location of the cable connector on your printer.
- ❑ Remove the USB cable when you operate P-4000 if it is not connected to a computer or printer.

Printing Images

Note:


Use the AC adapter when printing.

1. Select the image to print.
2. Press the Print button.
3. If you want to print only the selected image, select Print This Image. If you want to print all the images in the folder, select Print All Images. If you want to select the images to be printed in the folder, select Selected Images to Print. Then press the OK button.




Note:

When you select Selected Images to Print, the following screen appears. You can add some images to the previously set images to print. See "Set print quantities" on page 54 for details.



4. In the Print Settings screen, make the appropriate settings by using the 4-way ring and press the OK button.



Note:

- ❑ See the following “Printer settings” for details of each setting.
- ❑ The settings you made will be cleared when the image has finished printing.
- ❑ You cannot print the JPEG file if the vertical or the horizontal size of the image exceeds 4600 pixels.

Printing starts. The LCD turns off during printing and turns on again when the printing is finished. The LCD also turns on when you press any button during printing.

Printer settings

Setting	Detail
Number of Prints	Set the number of copies to print.
Print Date*	Set whether or not to print the date when the photo was taken.
Paper**	Set the type of paper to use.
Layout**	Set the layout of the printed images.
Print Mode**	Select the print mode.
Print P.I.F. Frames	Set to whether or not to print the P.I.F. Frame if the selected images include the P.I.F. data.

* If the image does not have the date information, the date of the file is printed.


** The value which has been set becomes the default setting from the next time.

Set print quantities


You can select the images and set the quantities to print before you start the printing process.

1. Select the image in the thumbnails screen or in the full screen.

- Press the Menu button to display the pop up menu, and select Print Order by using the Up or Down button.



- Press the Up or Down button to change the quantity of the selected image to print.



Note:

If you select the image in full screen, the screen that appears on your LCD is different from the above, but the instruction is the same.

- After you set the quantity, select a different image by using the Right or Left button.
- Repeat steps 3 and 4 until you set the print quantities for all images you want to print. Then press the OK button.

Note:

- ❑ *To print the images you set, follow the instructions in "Printing Images" on page 53.*
- ❑ *The settings you made will be cleared when the image has finished printing.*

Using P-4000 With Other Devices

Using P-4000 With a Computer

Connect P-4000 to a computer to display data on the monitor, copy data from the computer to P-4000, or from P-4000 to the computer. The computer recognizes P-4000 as an external HDD.


When using P-4000 with your computer, install the software from the software CD-ROM. For details, see “Installing the Software” on page 63.

Note:


When using P-4000 while it is connected to a computer, use the AC adapter.

Connecting P-4000 to a computer

1. Connect the AC adapter to P-4000. Then, turn on P-4000 and your computer.



2. Connect the USB cable to your computer. Then remove the USB connector rubber cover and connect the other end of the USB cable to P-4000.



The PC peripheral mode icon () is displayed for a short time, then the LCD turns off.

Note:

The LCD turns on when any button is pressed.

3. Start EPSON Photo!4, which you have installed on your computer from the CD-ROM. You can display or copy data with EPSON Photo!4. See the online EPSON Photo!4 User's Guide for instructions.


Note:

- ❑ You cannot move data in the memory card to your computer.
- ❑ When you see HDD of P-4000 in your computer, the "Albums" folder corresponds to Albums and the "Cards" folder corresponds to Saved Data.
- ❑ Do not change the name of the album folder ("Albums"), card folder ("Cards") and the folders under these two folders.
- ❑ When you copy data from your computer using the Explorer or Finder to P-4000, copy data to \Albums\PC_DATA. This folder exists as a default.
- ❑ Remove the USB cable when you operate P-4000 if it is not connected to a computer or printer.

Disconnecting P-4000 from a computer

For Windows users

1. Click Unplug or Eject Hardware on the computer screen.



Note:

The above message varies depending on your version of Windows.

2. Turn off P-4000 and remove the USB cable from the computer.

Note:

On Windows 98, when removing the cable from the computer after storing data to the computer without turning the computer off, the blue screen is displayed. To avoid this, turn the computer off before removing the cable.

3. Remove the USB cable from P-4000.

For Macintosh users

1. Drag and drop the P-4000 icon to the trash can on the computer screen.
2. Turn off P-4000 and remove the USB cable from the computer.
3. Remove the USB cable from P-4000.

Using A/V Out

P-4000 has an A/V Out connector. You can play slide shows and videos on the monitor just like on the LCD of P-4000 by connecting P-4000 to a monitor device, such as a TV, that has a video input connector.


Follow the instructions below to view images or play videos on TV.

1. Set the Video Out setting on P-4000 to the signal method of your TV.

Note:

See "Changing the P-4000 Settings" on page 60 for instructions on how to change the setting.

2. Connect a commercially available AV cable to the TV. Then connect the other end of the AV cable to P-4000.



3. Set the TV display to video input from P-4000.

Note:


- ❑ You can connect the AV cable to P-4000 even when P-4000 is on.
- ❑ The LCD turns off when you connect an AV cable to P-4000.
- ❑ Some monitors cannot display full images and the top and bottom parts may be missing.

Customizing Settings

This section describes how to customize P-4000 settings. You can customize various settings for displaying and copying images, or turn on the sound setting to make your P-4000 more fun to use.

Changing the P-4000 Settings

The settings described in the following sections can be changed from the Settings menu. To display the Settings menu, select Settings in the Home screen and press the OK button.



The following table shows details of each setting.

LCD Brightness setting	LCD Brightness	Change the brightness of the LCD. Select an appropriate brightness by using the Right or Left button.
Sound settings	Button Beep	When this setting is set to ON, a beep sounds when you do some operations.
	Volume	You can set the volume for playing audio and video.
Slide Show settings	Effects	Select one of the five slide show effects. The slide show is executed with the selected effect.
	Slideshow BGM	Select the BGM which is played during the slide show. You can select None, one of the five default audio, or audio data in the same folder.
	Duration	Set the duration to switch the images during a slide show. You can set the duration by moving the sliderbar from 3 seconds to 30 minutes.

Copy Mode setting	Delete Data After Copying	Set whether to delete the images in the memory card after copying them to the HDD automatically or not. When ON is set, the images are deleted. When Confirm is set, the dialog box that confirms deleting images appears before copying.
Power Save settings	Time before LCD power-off	Set the time after which the LCD's backlight turns off and the LCD goes blank if there are no operations. You can set the time by moving the slider from 1 minute to 10 minutes.
	Time before power-off	Set the time until the power is shut down automatically if there are no operations to save the battery. You can set the time by moving the slider from 1 minute to 15 minutes.
View Mode settings	Auto-rotation	Set whether to rotate the images automatically according to the Exif information.
	Folder view mode	Set how to display the folders in the Saved Data. When selecting Daily basis, the folders are displayed on a daily basis.
	Unsupported Files	Set whether the files in unsupported formats are displayed as thumbnails or not.
Video Out setting	Video out*	Select the signal method from either NTSC or PAL.
Date and time settings	Date and time**	Set the date and time.

Language setting	Language	Choose a language from among eight languages.
Hard Drive	Free Space	The HDD free space is displayed.

* After changing the setting, reconnect the VIDEO cable.

** When you change Date Format, the display of the Date and time settings screen also changes.

Operating the Software

System Requirements

The system requirements for using P-4000 with a computer are shown in the following table.

For Windows

OS	Microsoft® Windows® 98SE, Me, 2000 Professional, XP Home Edition, XP Professional
Processor	Pentium 1 GHz or higher
Memory	128 MB or more
Hard disk	50 MB or more free space is required for installation 1 GB or more free space is required for operation
Display	SVGA (800x600) or higher, 16 bit color or higher
Port	USB port (type A connector)

For Macintosh

	Mac OS® 9.1 or later	Mac OS X 10.2 or later
Processor	PowerPC G3 233MHz or higher	PowerPC G3 700MHz or higher
Memory	128 MB or more	256 MB or more
Hard disk	50 MB or more free space is required for installation 1 GB or more free space is required for operation	
Display	800x600 or higher, 32000 colors or more	
Port	USB port (type A connector)	

About the Software

The software CD-ROM provided with P-4000 includes the following software.

EPSON Photo!4	EPSON PhotoQuicker
QuickTime	Epson Storage Viewer USB driver (Windows 98 only)
EPSON PhotoStarter	EPSON CardMonitor

To install the software, follow the instructions in the next section.

Note:

The CameraStarter and AutoDownloader functions, which are part of EPSON Photo!4, cannot be used with P-4000. These functions are available only with EPSON digital cameras.

Installing the Software

Insert the software CD in the CD-ROM or DVD drive, and then start the installer following the instructions below.

For Windows users

Note:

For Windows XP and Windows 2000, you need the administrative privilege to install the software.

1. The installer starts automatically. If necessary, start it by double-clicking the EPSON CD-ROM icon.
2. If a message appears to prompt you to disable your antivirus software, click Continue.
3. If you are prompted to select a language, select your preferred language.
4. On the Software Installation screen, click Install. Follow the on-screen instruction until all of the software is installed.
5. When a message appears to indicate that installation is complete, click Exit or Restart Now.

Note:

When Restart Now appears, click this button to restart your computer.

For Macintosh users

1. For Mac OS X users:
Double-click the EPSON CD-ROM icon on your desk top.
Double-click Mac OS X icon in the EPSON folder.

For Mac OS 9 users:
Double-click the EPSON CD-ROM icon on your desk top.
Double-click Mac OS 9 icon in the EPSON folder.

2. If a message appears to prompt you to disable your antivirus software, click Continue.
3. If you are prompted to select a language, select your preferred language.
4. On the Software Installation screen, click Install. Follow the on-screen instruction until all of the software is installed.

For Mac OS X users:
If the Authenticate window appears, click the key icon, enter the administrator's name and password, and then click OK.

5. When a message appears to indicate that installation is complete, click Exit or Restart Now.

Note:

When Restart Now appears, click this button to restart your computer.

Starting the Software

This section describes how to start the software.

For Windows

Software	Menu
EPSON Photo!4	Click Start, point to All Programs (or Programs), and then select EPSON Camera. Select EPSON Photo!4, and then click EPSON Photo!4.
EPSON PhotoQuicker	Click Start, point to All Programs (or Programs), and then select EPSON PhotoQuicker. Click EPSON PhotoQuicker3.4.

For Macintosh

Software	Menu
EPSON Photo!4	Double-click the EPSON Photo!4 icon in the EPSON Photo!4 program folder.
EPSON PhotoQuicker	Double-click the EPSON PhotoQuicker icon in the EPSON PhotoQuicker program folder on your desktop.

Uninstalling the Software

Execute an uninstall program for each application. For details, see online help for each applications.

Finding More Information

To learn more about the software provided on the software CD-ROM, see the online EPSON Photo!4 or EPSON PhotoQuicker User's Guide.

Start the software and access the online User's Guide and then follow the steps below.

Software	To start online User's Guide...
EPSON Photo!4	From the Help menu (Windows), Apple menu (Mac OS 8.6 to 9.X) or EPSON Photo!4menu (Mac OS X), click EPSON Photo!4 Help.
EPSON PhotoQuicker	Click the Help button on the dialog box.

Note:

You can access the online EPSON Photo!4 or EPSON PhotoQuicker User's Guide using the Start menu in Windows, or in Macintosh, double-click the MANUAL folder in each of the software's program folders, and then double-click INDEX.HTM.

Maintenance and Troubleshooting

Cleaning the P-4000

To keep your P-4000 operating at its best, you should clean it thoroughly several times a year. Before you perform any maintenance on P-4000, be sure to read the “Important Safety Instructions” on page 7. Then follow these guidelines.

- ❑ Be sure to turn P-4000 off before cleaning.
- ❑ Use a clean, dry cloth to keep P-4000 free of dust.
- ❑ Do not use harsh or abrasive cleaners.
- ❑ If necessary, clean the battery contacts with a dry cloth.

Troubleshooting

When a problem occurs, an error message or icon usually appears in the LCD. Refer to the following section to solve the problem.

Error messages/Icons

Error message/Icon	Description
A file access error has occurred. Do not eject the memory card if it is being accessed.	Wait until the Access lamp turns off, and reinsert the memory card and try again.
An error occurred while verifying. Files will not be deleted.	Some files failed to be deleted. Check the data.
Some errors occurred while copying. Copying was canceled.	Some files were skipped, the memory card may be write-protected. Check the memory card and try again.
Some errors occurred while deleting files. The operation was canceled.	Some files were skipped, the memory card may be write-protected. Check the memory card and try again.

Error message/icon	Description
There is no response from the printer. Make sure the printer is on.	<p>Make sure that your printer is on and the USB cable is connected correctly.</p> <p>Check your printer and printer's manual.</p>
You must set the date and time to ensure correct operation.	See "Changing the P-4000 Settings" on page 60 and set the date and time.
	Wait until P-4000 cools down.
	The battery power is running out. Charge the battery. See "Charging the battery" on page 17 for details.
 <p>Press Reset</p>	Press the reset button. See "Resetting P-4000" on page 70 to find how to use the reset button.

Problems and solutions

Use the information in this section to find the source of and solution to P-4000 problems.

Determine the type of problem that occurred, and see the appropriate section below:

"Power supply problems" on page 68

"Viewing and playing problems" on page 68

"Data operation problems" on page 69

"Printing problems" on page 70

Power supply problems

The power does not turn on.

Cause	What to do
The battery has run out.	When the  icon is displayed on the top right corner of the LCD, the battery has run out. See “Charging the battery” on page 17 and charge the battery.
The battery is set incorrectly.	Make sure that the battery is installed correctly. See “Installing the battery” on page 17.

Viewing and playing problems

The data is not displayed.

Cause	What to do
The image format is not supported.	See “Available types of image data” on page 29 and make sure the image format is supported.

The data is not displayed.

Cause	What to do
The video or audio data you selected is not supported.	See “Available types of video/audio data” on page 35 and make sure the data is supported.
The data is broken.	Copy the data again.
The LCD Brightness setting is too dark.	See “Changing the P-4000 Settings” on page 60 and make sure the LCD Brightness setting is set properly.
The video cable is connected to P-4000.	Disconnect the VIDEO cable to display the LCD.

The movie is not displayed clearly or stops abruptly.

Cause	What to do
The bit rate of the data is too high.	Check the bit rate. See “Available types of video/audio data” on page 35 for details.

Sound breaks off when the video or audio is played.

Cause	What to do
The bit rate of the data is too high.	Check the bit rate. See "Available types of video/audio data" on page 35 for details.

No sound comes out when a video is played.

Cause	What to do
The Audio Codec of the data is not supported.	Check the file format. See "Available types of video/audio data" on page 35 for details.

Data operation problems**Cannot copy.**

Cause	What to do
The space available on the HDD is not sufficient to copy all of the data in the memory card.	Delete unnecessary data in the HDD or reduce the number of data to copy from the memory card.

Cannot copy.

Cause	What to do
The data may be broken.	Try to copy a different data.

Cannot delete.

Cause	What to do
The data is locked.	See "Using the Pop Up Menu" on page 49 and unlock the data to delete it.


Printing problems

Cannot print.

Cause	What to do
The printer is not supported.	See "Supported printers" on page 51 and make sure that your printer supports direct print with P-4000.
The printer's power is off.	Turn on the printer.
The USB cable is not connected correctly.	See "Connecting P-4000 to a printer" on page 51 and reconnect P-4000 to the printer.
The data is broken.	Try to copy a different data.

Resetting P-4000

When an error occurs and operations cannot be done, you can reset P-4000 by pressing the reset button with a thin object as shown below.



Contacting Customer Support

If your Epson product is not operating properly and you cannot solve the problem using the troubleshooting information in your product documentation, contact customer support services for assistance. Check your Pan-European Warranty Document for information on how to contact EPSON Customer support. They will be able to help you much more quickly if you give them the following information:

- Product serial number
(The serial number label is usually on the back of the product.)
- Product model
- Product software version
(Click About, Version Info, or similar button in the product software.)
- Brand and model of your computer
- Your computer operating system name and version
- Names and versions of the software applications you normally use with your product

Technical Support Web Site

Go to <http://www.epson.com> and select the Support section of your local EPSON web site for the latest drivers, FAQs, manuals and other downloadables.

Epson's Technical Support Web Site provides help with problems that cannot be solved using the troubleshooting information in your printer documentation.

Appendix

Standards and Approvals

P-4000 (Model: G941B)

U.S. model:

EMC	FCC Part 15 Subpart B Class B CSA C108.8 Class B
-----	---

European model:

EMC Directive 89/336/EEC	EN 55022 Class B EN 55024 EN 61000-3-2 (Use with AC adapter) EN 61000-3-3 (Use with AC adapter)
--------------------------	--

Taiwan model:

EMC	CNS13438 Class B
-----	------------------

AC adapter (Model: A351H)

U.S. model:

Safety	UL60950 CSA C22.2 No.60950
EMC	FCC Part 15 Subpart B Class B CSA C108.8 Class B

European model:

Low Voltage Directive 73/23/EEC EMC Directive 89/336/EEC	EN 60950 EN 55022 Class B EN 55024 EN 61000-3-2 EN 61000-3-3
---	--

Taiwan model:

EMC	CNS13438 Class B
-----	------------------

Battery (Model: D111A)

U.S. model:

Safety	UL2054
--------	--------

European model:

EMC Directive 89/336/EEC	EN 55022 Class B EN 55024
--------------------------	------------------------------

Specifications

General

CPU	TMS320DM270
LCD	EPSON VGA TFT LCD
HDD	2.5" HDD (80 GB) FAT 32

Dimensions and weight	Height: 84 mm (3.3 inches)* Width: 147 mm (5.8 inches)* Depth: 31.4 mm (1.2 inches)* Weight: Approx. 415 g (0.9 lb) (including the battery)
Temperature	Operating: 5 to 35°C** Non-operating: -20 to 60°C
Humidity (without condensation)	Operating: 30 to 80%** Non-operating: 10 to 80%
Altitude	Operating: 3048 m / 10000 ft or less Non-operating: 12192 m / 40000 ft or less
Memory card***	CompactFlash memory card (Type1/Type2 and 3.3 V, including MicroDrive), SD memory card, MultiMedia Card
Power sources	Lithium-ion battery (Model: D111A) AC adapter (Model: A351H)
Battery life (when fully charged) ****	Approx. 3.2 hours when playing a slide show (in the default settings) Approx. 2.7 hours when playing video (MPEG4, 1 Mbps) Approx. 4.7 hours when playing audio (MP3, 128 kbps, using the headphones)

* Dimensions do not include projections.

** Charging is recognized as operating.

*** A commercially available CF adapter is needed to use other memory cards. Contact our customer support for details.

**** Times may vary depending on the memory card being used, the number of files, ambient temperature, and other factors.

Electrical

Input voltage	DC 5.0 V
Rated current	Maximum 2.3 A
Power consumption	4 W (Using with the battery) 9 W (Using with the AC adapter)

Interface

USB connector	One USB 2.0 (Mass Storage Class) interface for Slave
A/V Out connector	Quadropole mini pin jack (Ø 3.5 mm)
Headphone Out Connector	M3 stereo mini pin jack (Ø 3.5 mm)
CF Card slot	One slot (Type1/Type2, 3.3V) for CompactFlash memory card and MicroDrive
SD Card slot	One slot for SD memory card and MultiMedia card

Battery

Type	Lithium Ion Battery
Model	D111A
Size (H × W × L)	22.45 mm × 20.4 mm × 71 mm
Ratings	3.7 V, 2600 mAh (Typ.)
Temperature	Storing: -20 to 40°C*

* Keep the battery in a cool place when storing it for a long period.

AC adapter

Model	A351H
Input	AC 100 - 240 V, 50 - 60 Hz, 0.3 A - 0.1 A
Output	DC 5.0 V, 2.3 A
Power consumption	Maximum 18 W

About Optional Accessories

The following options are available for P-4000.

optional product	product code
Lithium Ion Battery (Model: D111A)	B32B81826**

* The asterisk (*) is a substitute for the last digit, which varies by country.

Glossary

The following definitions apply specifically to P-4000.

AAC

An audio compression standard with high compression efficiency.

Exif (Exchanged Image File Format)

A file format for JPEG data to add image information, such as thumbnails, date photo taken, and image size.

JPEG

A file format for strong color and grayscale images in compressed files. Data saved using the JPEG format generally receives greater compression than data saved using TIFF and other formats.

MPEG4

An audio compression standard with high compression efficiency.

Motion-JPEG

A video compression algorithm that plays video by displaying still photos (JPEG files) continuously at a high speed.

MP3

An audio compression standard that can compress data to the ratio of 10% without decreasing sound quality.

NTSC/PAL

Broadcast analog color TV standards. NTSC is used mainly in Japan, North America, and various South American countries. PAL is used mainly in Western Europe (except France), China, and some other Asian countries.

pixel

Short for picture element. Each image is composed of a number of pixels. Pixels are also counted in units of dots.

Progressive JPEG

A kind of the JPEG format. An image in the progressive JPEG is displayed by gradually improving the resolutions.

RAW

A file for unprocessed data output from the CCD. You need to install special software to display the raw data.

TIFF (Tagged Image File Format)

A file format that can store an image in different resolutions or coding to one file.

USB DIRECT-PRINT

A function that enables you to print directly from a device connected to your printer via a USB cable.

Index

A

AC adapter
connecting, 18

Album
about, 39
changing the name, 43
creating, 42
deleting, 44

Approvals, 72

Audio
available types, 35
playing, 37

Available types of image data, 29

Available types of memory cards, 24

Available types of paper, 51

Available types of video/audio data, 35

B

Battery
charging, 18
installing, 17
removing, 19

C

Changing P-4000 settings, 60

Charging the battery, 18

Cleaning P-4000, 66

Connecting
to a computer, 56
to a printer, 51

Contacting EPSON, 71

Customer support, 71

Customizing settings, 60

D

Data

copying from a memory card to P-4000, 27

copying image, 40

deleting, 46

displaying on the computer's monitor, 56

Direct printing, 51

Displaying images, 29

E

Error messages/Icons, 66

H

Holding the button operations, 22

How to use the menu, 22

I

Image

- available types, 29
- copying to an album, 40
- displaying as a slide show, 35
- displaying as thumbnails, 31
- viewing, 29

Installing

- battery, 17
- software, 63

M

Main features, 6

Main menu, 22

Memory card

- available types, 24
- removing, 25, 26

P

Parts and their functions, 15

- back, 15
- front, 15
- LCD and control panel, 16

Pop up menu, 49

Printing

- printing images, 53
- setting print quantity, 54

Problems and solutions, 67

R

Removing a memory card, 25, 26

Resetting P-4000, 70

S

Setting

- copy mode settings, 60
- date and time settings, 60
- language setting, 60
- LCD brightness setting, 60
- power save settings, 60
- slide show settings, 60
- sound setting, 60
- video out setting, 60
- view mode settings, 60

Setting up P-4000, 17

Software

- finding more information, 65
- installing, 63
- starting, 64
- system requirements, 62
- uninstalling, 65

Specifications

- AC adapter, 74
- battery, 74
- electrical, 74
- general, 73
- interface, 74
- standards and approvals, 72

Standards, 72

Supported printers, 51

T

- Technical support, 71
- Troubleshooting, 66
 - data operation problems, 69
 - power supply problems, 68
 - printing problems, 70
 - viewing and playing problems, 68
- Turning the power off, 21
- Turning the power on, 20

U

- Uninstalling
 - software, 65
- Unpacking P-4000, 14
- Using
 - albums, 39
 - pop up menu, 49
 - video output, 58

V

- Video
 - available types, 35
 - playing, 37

