


# Get to know your PictureMate

## Control Panel





Pressing the Mode button will change the following options.

	Print all the photos, print photos pre-selected in your digital camera when DPOF information is stored on the memory card, or print directly from a digital camera.
	Print selected photos.
	Print an index of all the photos.
	Display setup and maintenance options.

Pressing the Layout button will change the following layout options.

	Print without margins.
	Print with margins.
	Print 2 per sheet without margins.

## Printer Parts



---

# Contents

## ***Safety Instructions***

---

Important Safety Instructions . . . . .	1
Warnings, Cautions, and Notes . . . . .	8

## ***Welcome!***

---

A Quick Introduction to the Digital Photography Process <sup>9</sup>	
Supported Photo Formats . . . . .	11
Where to Find Information . . . . .	11

## ***Preparing to Print***

---

Loading Paper . . . . .	12
Paper Handling Instructions . . . . .	13
Inserting Your Memory Card . . . . .	14

## ***Basic Photo Printing***

---

Printing All Photos . . . . .	16
Printing Selected Photos . . . . .	16
Printing an Index . . . . .	17
Printing Camera-Selected DPOF Photos . . . . .	17

## ***Printing Options***

---

Printing Photos in Black and White or Sepia . . . . .	18
Fixing Your Photos . . . . .	18
Adding the Date or Time . . . . .	19
Resetting the printing options . . . . .	21

## ***Saving Your Photos to an External Device (Backup)***

---

### ***Printing From an External Device***

---

Printing From an External Drive . . . . .	24
Printing From a PictBridge-Enabled Camera . . . . .	25
Printing From a Bluetooth Device . . . . .	26

### ***Replacing the Photo Cartridge***

---

Checking the Photo Cartridge Status (Ink Level) . . . . .	32
Replacing the Photo Cartridge . . . . .	33

### ***Taking PictureMate With You***

---

## ***Maintaining PictureMate***

---

Checking the Print Head Nozzles . . . . .	39
Cleaning the Print Head . . . . .	40
Aligning the Print Head . . . . .	41
Cleaning PictureMate . . . . .	42

## ***Troubleshooting***

---

Error/Warning Messages . . . . .	43
Printer Power Problems . . . . .	43
Print and Noise Problems . . . . .	44
Photo Quality Problems . . . . .	45
Problems With Paper Feeding . . . . .	46
Miscellaneous Printout Problems . . . . .	47

## ***Contacting Customer Support***

---

Regional Customer Services . . . . .	48
Technical Support Web Site . . . . .	48

## ***Options and Consumable Products***

---

Options . . . . .	49
Consumable Products . . . . .	49
Using the Optional Battery . . . . .	50

## ***Printer Specifications***

---

## ***Index***

---

### ***Panel Icon List***

---

# EPSON®

## Photo Printer

# PictureMate™ 100

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. The information contained herein is designed only for use with this Epson printer. Epson is not responsible for any use of this information as applied to other printers.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

Seiko Epson Corporation shall not be held liable for any damage resulting from electromagnetic interference that occurs from the use of any interface cables other than those designated as Epson Approved Products by Seiko Epson Corporation.

EPSON® is a registered trademark and PictureMate™ is a trademark of Seiko Epson Corporation.

PRINT Image Matching™ and the PRINT Image Matching logo are trademarks of Seiko Epson Corporation.

Copyright © 2001 Seiko Epson Corporation. All rights reserved. USB DIRECT-PRINT™ and the USB DIRECT-PRINT logo are trademarks of Seiko Epson Corporation.

Copyright © 2002 Seiko Epson Corporation. All rights reserved. Microsoft® and Windows® are registered trademarks of Microsoft Corporation.

Apple® and Macintosh® are registered trademarks of Apple Computer, Inc.

DPOF™ is a trademark of CANON INC., Eastman Kodak Company, Fuji Photo Film Co., Ltd. and Matsushita Electric Industrial Co., Ltd.

The BLUETOOTH™ trademarks are owned by Bluetooth SIG, Inc., U.S.A. and licensed to Seiko Epson Corporation.

Zip® is a registered trademark of Iomega Corporation.

SD™ is a trademark.

Memory stick, Memory Stick Duo, Memory Stick PRO, and Memory Stick PRO Duo are trademarks of Sony Corporation.

xD-Picture Card™ is a trademark of Fuji Photo Film Co., Ltd.

*General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.*

Copyright © 2005 Seiko Epson Corporation. All rights reserved.



---

# Safety Instructions

---

## Important Safety Instructions

Read all of the instructions in this section before using your printer. Also, be sure to follow all warnings and instructions marked on the printer.

### When choosing a place for the printer

Observe the following when choosing a place for the printer:

- ❑ Place the printer on a flat, stable surface that extends beyond the base of the printer in all directions. If you place the printer by the wall, leave more than 10 cm between the back of the printer and the wall. The printer will not operate properly if it is tilted at an angle.
- ❑ When storing or transporting the printer, do not tilt it, stand it on its side, or turn it upside down. Otherwise, ink may leak from the cartridge.
- ❑ Leave enough space in front of the printer for the paper to be fully ejected.
- ❑ Avoid places subject to rapid changes in temperature and humidity. Also, keep the printer and the AC adapter away from direct sunlight, strong light, water, or heat sources.
- ❑ Do not leave the printer in a place subject to high temperature, such as in a car. Also, keep the printer away from direct sunlight, strong light, and heat sources. Otherwise, the printer may be damaged or ink may leak.
- ❑ Avoid places subject to dust, shock, or vibration.
- ❑ Leave enough room around the printer to allow for sufficient ventilation.
- ❑ Place the AC adapter near a wall outlet where the plug can be easily unplugged.
- ❑ Do not place or store the printer, the AC adapter, or the optional battery outdoors.

## ***When setting up your printer***

Observe the following when setting up the printer:

- ❑ Do not block or cover the vents and openings in the printer.
- ❑ Power supply cords should be placed to avoid abrasions, cuts, fraying, crimping, and kinking. Do not place objects on top of power-supply cords and do not allow the AC adapter or power-supply cords to be stepped on or run over. Be particularly careful to keep all power-supply cords straight at the ends and the points where they enter and leave the AC adapter.
- ❑ Use only the power-supply cords that comes with this product. Use of another cord may result in fire or electrical shock, or injury.
- ❑ The AC adapter model A361H is designed for use with the printer with which it was included. Do not attempt to use it with other electronic devices unless specified.
- ❑ Use only the type of power source indicated on the AC adapter's label, and always supply power directly from a standard domestic electrical outlet with the AC power cord that meets the relevant local safety standards.
- ❑ Avoid using outlets on the same circuit as photocopiers or air control systems that regularly switch on and off.
- ❑ Avoid using electrical outlets controlled by wall switches or automatic timers.
- ❑ Keep the entire computer system away from potential sources of electromagnetic interference, such as loudspeakers or the base units of cordless telephones.
- ❑ Do not use a damaged or frayed power cord, AC adapter, and the optional battery.
- ❑ If you use an extension cord with the printer, make sure that the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating. Also, make sure that the total ampere rating of all devices plugged into the wall outlet does not exceed the wall outlet's ampere rating.

- ❑ Never disassemble, modify, or attempt to repair the AC adapter, power cord, printer, and options by yourself except as specifically explained in the printer's guides.
- ❑ Unplug the printer and the AC adapter, remove the optional battery from the printer, and refer servicing to qualified service personnel under the following conditions:

The power cord or plug is damaged; liquid has entered the printer, the AC adapter, or the optional battery; the printer, the AC adapter or the optional battery has been dropped or the casing damaged; the printer, the AC adapter or the optional battery does not operate normally or exhibits a distinct change in performance. (Do not adjust controls that are not covered by the operating instructions.)

- ❑ Do not use with wet hands.
- ❑ If you plan to use the AC adapter in Germany, the building installation must be protected by a 10 or 16 amp circuit breaker to provide adequate short-circuit protection and over-current protection for this printer.

### ***For United Kingdom, Singapore, and Hong Kong users***

- ❑ Replace fuses only with fuses of the correct size and rating.

#### Safety requirements

##### Mains plug:

Use a 3-pin mains plug that is registered with the Safety Authority.

##### Flexible cord:

Use a double insulated flexible cord that is certified\* to the relevant IEC or BS standards.

##### Appliance connector:

Use an appliance connector certified\* to the relevant IEC or BS Standards.

\* certified by member of IECCEB CB Scheme.

### ***For United Kingdom users***

The following safety information applies to the AC adapter.

- ❑ **Warning:** Refer to the rating plate for the voltage and check that the appliance voltage corresponds to the supply voltage.

- ❑ **Important:** The wires in the mains lead fitted to this appliance are coloured in accordance with following code: Blue - Neutral, Brown - Live

If you have to fit a plug:

- ❑ As the colours of the mains lead of the appliance may not match the coloured markings used to identify the terminals in a plug, please observe the following:

The blue wire must be connected to the terminal in the plug marked with the letter N.

The brown wire must be connected to the terminal in the plug marked with the letter L.

- ❑ If damage occurs to the plug, replace the cord set or consult a qualified electrician.

## ***When using the printer***

Observe the following when using the printer:

- ❑ If you use the printer in places where the use of electronic devices is limited, such as in airplanes or hospitals, follow all instructions in those places.

- ❑ Do not insert objects through the slots in the printer.
- ❑ Take care not to spill liquid on the printer and the AC adapter.
- ❑ Do not put your hand inside the printer or touch the photo cartridge during printing.
- ❑ Always turn the printer off using the I/O On button. Do not unplug the printer or turn off the power to the outlet until the power light goes out.
- ❑ Before transporting the printer, make sure that the photo cartridge is in place.
- ❑ Leave the photo cartridge installed. Removing the cartridge can dehydrate the print head and may prevent the printer from printing.

## ***When using a memory card***

- ❑ Use only memory cards compatible with the printer. Refer to Inserting Your Memory Cards.

## ***When using LCD***

- ❑ The LCD panel contains a few small bright or dark spots. These are normal and do not mean that the LCD monitor is damaged in any way.
- ❑ Only use a dry, soft cloth to clean the LCD panel. Do not use liquid or chemical cleansers.
- ❑ If the LCD panel on your printer's control panel is damaged, contact your dealer. If the liquid crystal solution gets on your hands, wash them thoroughly with soap and water. If the liquid crystal solution gets into your eyes, flush them immediately with water. If discomfort or vision problems remain after a thorough flushing, see a doctor immediately.

## ***When using the optional Bluetooth Photo Print Adapter***

Refer to the Bluetooth Photo Print Adapter's documentation for the safety instructions.

## ***When using the optional battery***

- ❑ If battery acid gets into your eyes or on your skin, immediately rinse the affected area thoroughly with water and seek medical treatment. If a battery is swallowed, seek medical treatment immediately.
- ❑ Use only an Epson Li-ion battery model EU-112 for this printer according to the directions in the user documentation. Replacing the battery with an incorrect model may cause an explosion.
- ❑ Use only AC adapter model A361H to charge the battery and operate the printer.
- ❑ Do not charge or use the battery with devices other than the specified product. Using the battery with other devices may damage the battery or other devices, or may cause an explosion.
- ❑ To protect against short circuits, do not remove the outside case of the battery.
- ❑ Do not handle the battery with wet hands or use them near water.

- ❑ Do not expose the battery to water or high humidity.
- ❑ Do not drop, puncture, disassemble, mutilate, or short-circuit the battery.
- ❑ Do not place the battery near or into fire or water.
- ❑ Do not use the battery that is leaking or damaged in any way.
- ❑ Do not charge the battery on devices except this printer.
- ❑ Do not charge the battery near open flame or in very hot locations.
- ❑ Keep the battery away from heat sources.
- ❑ Do not leave the battery in a vehicle to prevent the battery from overheating.
- ❑ Do not insert objects into any openings as they may touch dangerous voltage points or short-circuit components.
- ❑ Prevent the battery from coming into contact with metal objects that could short-circuit it, such as coins or keys.
- ❑ Do not solder wires or terminals directly to the battery.
- ❑ Do not touch battery terminals.
- ❑ Keep the battery away from open flame if they leak or smell strange.
- ❑ If overheating, discoloration, or deformation occur, remove the battery from the printer and do not use it.
- ❑ Charge the battery before using it if it has not been used for a long period.

### ***When storing the optional battery***

- ❑ When not using the printer for a long period of time, remove the battery from the printer and store them separately to avoid over-discharging the battery.
- ❑ Do not store the battery where the temperature or humidity is very high.
- ❑ Store the battery out of children's reach.

## When disposing of the optional battery

Before disposing of the battery, make sure you discharge them completely.



### **Warning:**

- ❑ *Do not dispose of batteries as ordinary refuse. Instead, dispose of them in a collection or recycle box in accordance with local laws.*
- ❑ *Do not incinerate or dispose of the battery in fire.*

For European users:

Do not dispose of batteries as ordinary refuse. Instead, dispose of them in a recycle box in accordance with local laws.



## When handling photo cartridges

Observe the following when handling photo cartridges:

- ❑ Do not shake photo cartridge after removing it from the bag; this can cause leakage.
- ❑ Do not remove or tear the label on the cartridge; this can cause leakage.
- ❑ Do not use a photo cartridge beyond the date printed on the cartridge carton: otherwise, it may result in reduced print quality. For best results, use up the photo cartridge within six months of installing it.
- ❑ Do not dismantle photo cartridges or try to refill them. This could damage the print head.
- ❑ After bringing a photo cartridge inside from a cold storage site, allow it to warm up at room temperature for at least three hours before using it.
- ❑ Store photo cartridges in a cool, dark place.
- ❑ The IC chip on the photo cartridge retains a variety of cartridge-related information, such as the amount of ink remaining, so that the cartridge may be removed and reinstalled freely. However, each time the cartridge is inserted, some ink is consumed because the printer automatically performs a reliability check.

- ❑ Store each photo cartridge so that the bottom of its packaging faces down.

## **ENERGY STAR® Compliance**



As an ENERGY STAR® Partner, Epson has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

The International ENERGY STAR® Office Equipment Program is a voluntary partnership with the computer and office equipment industry to promote the introduction of energy-efficient personal computers, monitors, printers, fax machines, copiers, scanners, and multifunction devices in an effort to reduce air pollution caused by power generation. Their standards and logos are uniform among participating nations.

---

## **Warnings, Cautions, and Notes**



### **Warnings**

*must be followed carefully to avoid bodily injury.*



### **Cautions**

*must be observed to avoid damage to your equipment.*

### **Notes**

*contain important information and useful tips on the operation of your printer.*

---

# Welcome!

PictureMate™ is your easy-to-use, personal photo lab. Just insert a digital camera memory card and you're ready to print brilliant photos. Because PictureMate is light and portable, you can print whenever and wherever you take pictures.

---

## A Quick Introduction to the Digital Photography Process

With film cameras, the process was simple; buy film, take pictures, leave the film at the photo lab, and come back later for your photos and negatives. Since you had negatives, you could take them back later if you wanted reprints.



The digital process is simple too, and it gives you complete control. Just follow these basic steps:

### 1. Review and Delete

After you finish taking your photos, review them on your digital camera's screen. Delete the photos you don't want to print or keep.




### 2. Print

Insert your camera's memory card in PictureMate, choose your photos, and print.



### 3. Save

To preserve your digital photo files (just like film negatives), save them to a CD or your computer. Then you can reprint them any time.




#### 4. Clear the Memory Card

After you save your photo files, delete them from your memory card so you have room for more photos.

### Special Features

Printing with your PictureMate becomes even easier with these special features:



LCD panel



DPOF

From the PictureMate LCD panel, you can print all your photos or you can select just the ones you want. See “Basic Photo Printing” on page 16.

If your camera supports DPOF (Digital Print Order Format), you can pre-select which photos to print while the memory card is still in your camera. Then, when you insert the card into PictureMate, it knows which photos you chose. See “Printing Camera-Selected DPOF Photos” on page 17.



If you have a PictBridge<sup>®</sup>- or USB DP (USB Direct Print)-enabled camera, you can connect the camera to PictureMate and control printing right from your camera. See “Printing From a PictBridge-Enabled Camera” on page 25.



If you have a Bluetooth<sup>®</sup>-enabled PDA, mobile phone, or computer, you can send photos wirelessly to PictureMate for printing. You just need the optional Epson<sup>®</sup> Bluetooth Photo Print Adapter. See “Printing From a Bluetooth Device” on page 26.



If you want to print in other places without convenient electrical outlets, you can buy the optional PictureMate battery. See “Options and Consumable Products” on page 49.

**Note:**

PictureMate also supports P.I.M. (PRINT Image Matching™) image enhancement standard that is built into many cameras. To see if your camera is P.I.M.-enabled, see your camera's documentation.

---

## Supported Photo Formats



Make sure your photos meet these requirements for printing with your PictureMate:

- JPEG files or uncompressed TIFF files only
- Resolutions ranging from 80 × 80 to 4600 × 4600 pixels

PictureMate recognizes and prints the first 999 photos on your memory card.

---

## Where to Find Information

### Unpacking and setting up



Start Here

See your *Start Here* to unpack, set up, and use your PictureMate.

### Printing and changing settings



Basic Operation Guide

*Basic Operation Guide* (this book) explains how to print photos directly from your camera's memory card. It also covers how to print from other devices, replace the PictureMate Photo Cartridge, take care of PictureMate, and troubleshoot problems.

### Using your PictureMate with a computer



The on-screen *User's Guide* on the CD provides comprehensive information and instructions for using PictureMate with a computer.

---

## Preparing to Print

Before you can print, you need to load paper and insert your memory card in PictureMate.

---

### Loading Paper


Follow these steps to load PictureMate Photo Paper:



**Caution:**

*Do not load plain paper; this may damage PictureMate.*


1. Move the handle to the back and down. Then open the paper support and output tray.




**Note:**

*Keep the handle all the way down when printing, to allow paper to feed through.*

- Slide the top part of the paper support up gently until it clicks into place.



- Place your paper against the right edge, with the glossy side up.



**Note:**

*Make sure paper is glossy side up to prevent smearing.*

- Slide the left edge guide against the paper. Make sure it is snug, but not so tight that paper can't move.

**Note:**

*When you need more paper, order a PictureMate PicturePack. See "Consumable Products" on page 49 for more information.*

---

## Paper Handling Instructions

### When storing printouts

- ❑ Do not touch the printed side or stack your printouts until the ink is dry.
- ❑ To avoid scratching the image, be sure not to rub the printed side of the paper. If the printed side is rubbed too strongly, ink may come off the paper.
- ❑ Do not stack printouts with the image sides touching.
- ❑ Do not stack printouts and conventional film photographs with the image sides touching.
- ❑ If you stack printouts, place a sheet of plain paper or other absorbent paper between the individual prints.

### When storing unused paper

Return any unused paper to the original package, and store it away from extreme temperatures, high humidity, and bright lights.

## When displaying printouts

- ❑ When displaying your printouts indoors, Epson recommends placing your printouts in glass frames to preserve the colors in your image.
- ❑ Avoid displaying your printouts outdoors or in a place exposed to direct sunlight to prevent fading.


### Note:

For best results, allow your prints to dry thoroughly for 24 hours before framing.

---

## Inserting Your Memory Card

1. Press the I/O On button to turn on PictureMate.
2. Open the memory card cover.



3. Insert the memory card into the correct slot, as shown in the illustration.

Top:



SmartMedia™



xD-Picture Card™  
xD-Picture Card™ Type M

Middle:



Sony Memory Stick®  
Memory Stick Duo™ \*  
Memory Stick PRO™  
Memory Stick PRO Duo™ \*  
MagicGate™ Memory Stick  
MagicGate Memory Stick Duo™ \*



SD (Secure Digital)  
miniSD™ card \*\*  
MMC™ (MultiMediaCard™)

Bottom:



Microdrive™  
CompactFlash® (Type I + II)


\* Requires Memory Stick Duo adapter

\*\* Requires miniSD adapter

Push the card in carefully until it stops (it won't go in all the way).

Insert just one card at a time.

When it is in, the memory card light comes on.



4. Close the memory card cover.

Now you can choose photos and layouts for printing from the LCD panel. See "Basic Photo Printing" on page 16.

## ***Removing Your Memory Card***

When you are ready to remove a memory card, make sure the memory card light is not flashing, then pull the card straight out of the slot.




***Caution:***

*Do not remove a card while the memory card light is flashing; you may lose photos on your card.*

## Basic Photo Printing

### Printing All Photos




1. Press the Mode button to select /📷.
2. Press the ▲ or ▼ button to select the number of copies.
3. Press the Layout button to select the layout.
4. Press the ◊ Start button to start printing.

#### Note:

If there is DPOF information on the memory card and /📷 is selected, PictureMate goes to DPOF print mode. See "Printing Camera-Selected DPOF Photos" on page 17 for details. To print all of the photos on the memory card, press the Cancel button and follow the steps above.

### Printing Selected Photos




1. Press the Mode button to select .

2. Press the ◀ or ▶ button to select the photo you want to print.
3. Press the ▲ or ▼ button to select the number of copies.
4. Repeat steps 2 and 3 for additional photos.
5. Press the Layout button to select the layout.
6. Press the ⬠ Start button to start printing.

---

## Printing an Index



1. Press the Mode button to select .
2. Press the ⬠ Start button to start printing.

---

## Printing Camera-Selected DPOF Photos

If your camera supports DPOF (Digital Print Order Format), you can use it to pre-select which photos and how many copies you want to print. See your camera's manual to choose photos for printing with DPOF, then insert your memory card in PictureMate. PictureMate automatically reads your pre-selected photos.

1. Load paper and a memory card that contains DPOF data. The screen below appears on the LCD panel.



2. Press the Layout button to select the layout.
3. Press the ⬠ Start button to start printing.

### **Note:**

*If you want to print all of the photos on the memory card, press the ⓧ Cancel button. See "Printing All Photos" on page 16.*

---

## Printing Options

---

### Printing Photos in Black and White or Sepia

You can print your photo in black and white or in a sepia tone without changing the original photo.

**Note:**

*A sepia print has a brownish tone, for an old-fashioned photo look.*

1. Press the Mode button to select .
2. Press the ◀ or ▶ button to select Color Effect, then press the ⬢ Start button.



3. Press the ▲ or ▼ button to select color, black and white, or sepia, these are indicated by the color of the icon, then press the ⬢ Start button.



4. See “Basic Photo Printing” on page 16 and print using the mode you want.

---

### Fixing Your Photos

PictureMate lets you correct the color and improve the image quality of your photos without using a computer.

- If your camera supports PRINT Image Matching, you can use the printer’s P.I.M. setting to automatically adjust your photos for the best results.

- ❑ If your camera doesn't support PRINT Image Matching, you can use PhotoEnhance to make adjustments for the type of environment in which your photos were taken.


**Note:**

*These settings affect only your printed pictures. They do not change your original image files.*

1. Press the Mode button to select .
2. Press the ◀ or ▶ button to select Auto Correct, then press the ⬡ Start button.



3. Press the ▲ or ▼ button to select one of the options, then press the ⬡ Start button.



- ❑ PhotoEnhance - Use this if a print does not look good; for example, this may correct images that are too dark, too bright, or backlit.
  - ❑ OFF - Prints photos as they are or bypasses P.I.M. data.
  - ❑ P.I.M. - PictureMate chooses this setting automatically if it detects P.I.M. information saved in your camera's digital files. This information helps ensure an accurate image reproduction.
4. See "Basic Photo Printing" on page 16 and print using the mode you want.

---

## ***Adding the Date or Time***


You can add the date and/or time your photo was originally taken to the bottom right corner of your print.

1. Press the Mode button to select .

2. To print the date, press the ◀ or ▶ button to select Date Stamp, then press the ⬇ Start button.



3. Press the ▲ or ▼ button to select one of the options, then press the ⬇ Start button.



- None (default, turns off the date stamp)
- yyyy.mm.dd (2005.09.01)
- mmm.dd.yyyy (Sep.01.2005)
- dd.mmm.yyyy (01.Sep.2005)

4. To print the time, press the ◀ or ▶ button to select Time Stamp, then press the ⬇ Start button.



5. Press the ▲ or ▼ button to select one of the options, then press the ⬇ Start button.



- None (default, turns off the time stamp)
- 12-hour system(03:00 for 3 pm)
- 24-hour system(15:00 for 3 pm)

6. See “Basic Photo Printing” on page 16 and print using the mode you want.

---

## ***Resetting the printing options***

You can reset the printing options to the original, default settings.

1. Press the Mode button to select .
2. Press the  Cancel button. The three lights next to the layout icons flash and the printing options are reset.

---

## ***Saving Your Photos to an External Device (Backup)***

You can save your photo files to one of the following devices by connecting the device directly to PictureMate:


- ❑ CD-R/RW drive (CD-R/DVD-R media only)
- ❑ MO drive
- ❑ Iomega<sup>®</sup> Zip<sup>®</sup> disk (100, 250, or 750MB)
- ❑ Flash memory (thumb) drive

***Note:***

*Epson cannot guarantee the compatibility of any drives.*

1. Make sure PictureMate is on.
2. Insert your memory card into PictureMate.
3. If you are using a CD-R/RW drive or Zip drive, plug it into an electrical outlet if required.
4. Connect the drive to PictureMate.

- ❑ For a CD-R/RW, MO or Zip drive, connect its USB cable to the EXT/IF port on the back of PictureMate. Then insert a CD-R/DVD-R, MO or Zip disk in the drive.



- ❑ For a flash memory drive, plug it into the EXT/IF port on the back of PictureMate.




5. Press the Mode button to select .
6. Press the ◀ or ▶ button to select Backup, then press the ⬢ Start button.




**Note:**

- ❑ If your media is not formatted, the screen below appears. Press the ⬢ Start button to format.



- ❑ If you see an error message, see “Error Display” on page 59.

7. When you see the screen below, press the ⬢ Start button to start backup.



8. When you see the screen below, press the ⬢ Start button to finish.



 **Caution**

Do not remove the drive or memory card while the photos are being saved, or you may lose photos on your card or drive. If you need to stop the backup, press the ⓧ Cancel button.

You can save photos multiple times to the same disk or drive until it is full. Each time you save photos on the same disk or drive, they are saved in a new folder. The first folder is named 001, the second folder is named 002, and so on. If you save on a CD-R/DVD-R, PictureMate names the CD-R/DVD-R Photo.


---

## Printing From an External Device

PictureMate can print stored photos on a device such as an external hard drive, a Bluetooth-enabled device, or a digital camera.

---

### Printing From an External Drive



If you saved your photos to a CD, DVD, MO, Zip disk, or flash memory (thumb) drive, you can connect the drive to the back of PictureMate and print just like you do when you insert a memory card.


You can also print photos from a CD that you get from a photo processing lab. (Images should be in JPEG file format. Some CDs may not work.)

1. Make sure PictureMate is on.
2. Make sure there are no memory cards in PictureMate's memory card slots. The memory card light should be off.

#### **Note:**

*If a memory card is inserted, the printer will read photos from the card, not from an external drive.*

3. If PictureMate is connected to a computer, disconnect it or turn off the computer.
4. Connect your CD, MO or Zip drive's USB cable, or plug your flash memory drive into the EXT/IF port on the back of PictureMate.



5. For a CD, MO or Zip drive, insert a CD/DVD, MO or Zip disk with photos into the drive.

If you used PictureMate to save photos on the same CD-R/DVD-R, MO, Zip disk, or flash memory drive more than once, it will have multiple folders. You see this screen:



Press the ▲ or ▼ button to choose the folder where your photos are stored, then press the ⬠ Start button. The most recently saved folder has the largest number.

6. Follow the same procedure as when printing from a memory card to perform printing. See “Basic Photo Printing” on page 16.

---

## Printing From a PictBridge-Enabled Camera

You can connect your PictBridge- or USB DP-enabled digital camera to the back of PictureMate and use the camera to control printing. (See your digital camera's documentation to see if it supports the PictBridge standard or USB DP.)


1. Make sure PictureMate is on.
2. Make sure there are no memory cards in PictureMate's slots. The memory card light should be off.

**Note:**

*If a memory card is inserted, the printer will read photos from the card, not from a camera.*

3. Use the printer's control panel to adjust the print settings. (For example Layout, Color Effect, and Auto Correct)

4. Connect your camera's USB cable to your camera and the EXT/IF port on the back of PictureMate.




5. Use the digital camera to select the photo you want to print. Be sure to make the desired print settings on the digital camera because the digital camera settings generally take precedence over the print settings of PictureMate. See your digital camera's documentation for information on more detailed settings.
6. Print from the digital camera.

---

## **Printing From a Bluetooth Device**

### **About the Bluetooth Photo Print Adapter**

The optional Bluetooth Photo Print Adapter is a wireless communication module used to print from digital cameras and other devices with Bluetooth wireless technology without cables when connected to the printer.



**Note:**

- ❑ *While this product complies with the Bluetooth Specification, it is not guaranteed to work with all devices enabled with Bluetooth wireless technology.*
  
- ❑ *The communication range of this product is approximately 10 meters; however, this may vary depending on conditions including obstacles between devices; signal quality; magnetic fields; static electricity and electromagnetic interference; software; operating system; reception sensitivity; and antenna performance.*

**Available Profile**

Basic Printing Profile (BPP)

Basic Imaging Profile (BIP)

Hardcopy Cable Replacement Profile (HCRP)

Object Push Profile (OPP)

## Connecting and Disconnecting the Bluetooth Photo Print Adapter


### Connecting

1. Insert the Adapter connector into the EXT /IF port as shown below.



**Caution:**


*Do not connect this product while the printer is operating. Doing so may cause the printer to malfunction.*



2. The Adapter's light comes on for one second. If the LED does not turn on, disconnect the Adapter from the printer, then reconnect it.

## Disconnecting

Remove the Adapter's connector from the EXT/IF port as shown below.



### Caution:

- Do not remove this product while communicating with another device.
- Do not disconnect this product while the printer is operating. Doing so may cause the printer to malfunction.
- Do not remove this product by pulling on its upper section. Doing so may damage the product.

## Bluetooth Settings

Use the LCD panel on the printer to make settings for Bluetooth wireless communication.

➔ See “Making settings” on page 29

### Outline of settings

Setting	Choices	Description
 BluetoothDevice Name	printer name-(number) (Default = 1)	If multiple printers enabled with Bluetooth are in the same communication range, distinguish them by assigning each number from 0 through 9.  To make the Device Name setting take effect, turn the printer off and then back on.

 Bluetooth Communication Mode	Public	This mode allows devices enabled with Bluetooth to freely discover the printer and print.
	Private	This mode prevents unknown devices from discovering the printer.  To print in Private mode, first search for the printer once in Public mode. After your device has discovered the printer in Public mode once, it will subsequently be able to communicate with and print from it in Private mode.
	Pairing	This mode requires that the four-digit Passkey be entered into a device before it can communicate with and print from the printer.
 Bluetooth Encryption	ON/OFF (Default = OFF)	Select ON to encrypt communication. Encryption requires that the four-digit Passkey be entered into a device before it can communicate with and print from the printer.

 Bluetooth Passkey	Any four-digit number (Default = 0000)	The Passkey setting allows you to set the four-digit Passkey that must be entered into a device before printing if Pairing is selected as the BT Comm. Mode or if BT Encryption is ON.
 Bluetooth Device Address	Set at the factory (Example) 11-11-11-11-11	Displays the unique Bluetooth Device Address of the printer.

## Making settings

1. Connect the Bluetooth Photo Print Adapter to your printer.  
➔ See “Connecting and Disconnecting the Bluetooth Photo Print Adapter” on page 27



### Caution:

*Be sure that the printer is not operating before connecting this product. Otherwise, the printer may malfunction.*

2. Press the Mode button to select .

3. Press the ◀ or ▶ button to select the desired bluetooth option.
4. Change the settings of each item. See “Outline of settings” on page 28 for information about Bluetooth settings.

### *The Bluetooth Passkey Setting (PIN Code Set)*


If you select Pairing as the BT Comm. Mode or ON as the BT Encryption setting, the Passkey must be entered into a Bluetooth wireless-capable device before it can communicate with and print from the printer. The default Passkey is 0000.

To change the Passkey, follow the instructions below.

1. Press the Mode button to select .
2. Press the ◀ or ▶ button to select Passkey, then press the ⬢ Start button.



3. Press the ▲ or ▼ button to select a number for the digit, then press the ◀ or ▶ button to change the digit.



4. Select numbers for the other digits in the same manner, then press the ⬢ Start button to activate the Passkey.

## **Printing**

1. Make sure the Bluetooth Photo Print Adapter is connected to PictureMate and Bluetooth settings have been made. For details on connecting the Bluetooth Photo Print Adapter, see “Connecting and Disconnecting the Bluetooth Photo Print Adapter” on page 27. See “Bluetooth Settings” on page 28 to set the Bluetooth settings.
2. Use the PictureMate’s control panel to adjust the print settings. (For example Layout, Color Effect, and Auto Correct)

3. Print the data from your Bluetooth enabled device.

**Note:**

*The settings available may vary among Bluetooth wireless-capable devices. For more information, refer to your device's documentation.*

For more information about printing from Bluetooth wireless-capable mobile phones, digital still cameras, digital video cameras, PDAs, mobile PCs and other Bluetooth wireless-capable device, refer to the documentation for both the device and the printer.


---

# Replacing the Photo Cartridge

---

## Checking the Photo Cartridge Status (Ink Level)

When the photo cartridge is low on ink, you see this icon in the upper-left corner of the LCD screen.



Ink low

You can check the approximate ink level in your photo cartridge at any time.

1. Press the Mode button to select .

2. Press the ◀ or ▶ button to select Check Ink Levels, then press the ⬢ Start button.



3. You see a screen showing the approximate ink level in your photo cartridge. Press the ⬢ Start button to close the screen.



---

## Replacing the Photo Cartridge

PictureMate uses photo cartridge equipped with an IC chip. The IC chip accurately monitors the amount of ink, so even if it is removed and later reinserted, all of its ink can be used. However, some ink is consumed each time the cartridge is inserted because PictureMate automatically checks reliability.



### **Warning:**

*Keep photo cartridges out of the reach of children. Do not allow children to drink from or handle the cartridges.*



### **Caution:**

- ❑ *Epson recommends the use of genuine Epson photo cartridges. Epson warranties do not cover damage to your printer caused by the use of photo cartridges not manufactured by Epson.*
- ❑ *Leave the old cartridge installed in the printer until you have obtained a replacement; otherwise, ink remaining in the print head nozzles may dry out.*
- ❑ *Do not refill photo cartridges. The printer calculates the amount of ink remaining using an IC chip on the photo cartridge. Even if the cartridge is refilled, the amount of ink remaining will not be recalculated by the IC chip and the amount of ink available for use will not change.*

### **Note:**

*In addition to the ink used during an image printing, ink is consumed during the print head cleaning operation, during the self-cleaning cycle which is performed when the printer is turned on, and during ink charging when the photo cartridge is installed in the printer.*

For more information about photo cartridges.

➔ See “When handling photo cartridges” on page 7


1. Make sure that PictureMate is on, but not printing.

**Note:**

*Check the ink status.*

➔ See "Checking the Photo Cartridge Status (Ink Level)" on page 32

2. Check that the screen below is displayed on the LCD panel. This screen is not displayed if there is some ink left.



3. Close the paper support.


4. Move the handle to the upright position.



5. Open the cartridge compartment cover on the back of PictureMate.



6. Set the cartridge lock lever in the Release position by sliding the lever to the right, then down and to the left. The photo cartridge will be ejected about halfway out of the holder. Pull the cartridge out of PictureMate and dispose of it properly.



**Note:**


- ❑ Do not take the used cartridge apart or try to refill it. Do not shake the used photo cartridge; otherwise, it may leak.
  - ❑ The photo cartridge must be replaced when any one of the colors is depleted. The rate that a specific color of ink is consumed depends on the images printed.
7. Remove the replacement photo cartridge from its package.



**Caution:**


- ❑ Do not touch the green IC chip on the bottom of the cartridge. This can damage the photo cartridge.

Do not touch this part.




- ❑ If you remove the photo cartridge for later use, be sure to protect the ink supply ports from dirt and dust; store it in the same environment as the printer. Note that there is a valve in the ink supply ports, making covers or plugs unnecessary, but care is needed to prevent the ink from staining items that the cartridge touches. Do not touch the ink supply ports or surrounding area.
- ❑ Be sure to always install a photo cartridge into the printer immediately following the removal of the current photo cartridge. If a photo cartridge is not installed promptly, the print head may dry out, rendering it unable to print.

- Place the cartridge properly into the cartridge holder, then push it in until you feel resistance and hear the cartridge faintly click into place.




**Note:**

After installing the cartridge, make sure the sides of the cartridge are even. If either side of the cartridge sticks out, push the side of the cartridge until it clicks.



- Set the lever to the LOCK position by sliding it in the direction shown.



- Close the cartridge compartment cover.

**Note:**

If you cannot close the cartridge compartment cover, the photo cartridge is not installed correctly. Go back to the Step 6 and eject the photo cartridge. Then install the photo cartridge again.

- Move the handle all the way down.

---

## Taking PictureMate With You

PictureMate's handle makes it easy to carry short distances. If your PictureMate is going to travel a longer distance, you should pack it carefully to protect it from getting damaged.




### Caution:

*Keep PictureMate out of the sun and don't leave it in your car or other location where it can get too hot.*



1. If PictureMate is on, turn it off.
2. Wait until the LCD screen goes blank, then unplug the power cord from the electrical outlet.
3. Remove paper from the paper support and output tray.

4. Push down the top of the paper support and close it against PictureMate. Then close the output tray.



5. Disconnect the power cord and any connected USB cable from the back of PictureMate.



6. Pack PictureMate along with its power cord and AC adapter in the box that PictureMate came.



**Caution:**

*Make sure the photo cartridge is installed before transporting. Don't place PictureMate on its side or upside down, or ink may leak.*

**Note:**

*If your prints don't look as good after PictureMate has been moved, try aligning the print head. See "Aligning the Print Head" on page 41.*

---

# Maintaining PictureMate

---

## Checking the Print Head Nozzles

If you find that the printout is unexpectedly faint or that dots are missing, you may be able to identify the problem by checking the print head nozzles.

1. Make sure that PictureMate is turned on and no warnings or errors are displayed on the LCD panel.
2. Load a sheet of paper. See “Loading Paper” on page 12.
3. Press the Mode button to select .
4. Press the ◀ or ▶ button to select Check Ink Nozzles.



5. Press the ◊ Start button to print the nozzle check pattern.
6. The nozzle check pattern is printed out. See the following illustration.

The printer will print a nozzle check pattern. Below are sample printouts.



The above sample may be shown in black and white, but the actual test prints in color (Black, Cyan, Magenta and Yellow).

If the nozzle check page does not print satisfactorily (for example, if any segment of the printed lines is missing), there is a problem with the printer. This could be a clogged ink nozzle or a misaligned print head.

See “Cleaning the Print Head” on page 40.

---

## Cleaning the Print Head

If your print quality is not as good as it used to be, if your photos are light or faint, or you are missing colors in your prints, your print head nozzles may be clogged.

### Note:

- ❑ *Print head cleaning consumes some ink. To avoid wasting ink, clean the print head only if print quality declines; for example, if the printout is blurry or the color is incorrect or missing.*
  - ❑ *Use the Nozzle Check function first to confirm that the print head needs to be cleaned. This saves ink.*
  - ❑ *If a message on the LCD screen tells you that the cartridge is empty or low on ink, you cannot clean the print head. You must first replace the photo cartridge.*
1. Make sure that PictureMate is turned on and no warnings or errors are displayed on the LCD panel.
  2. Press the Mode button to select .

3. Press the ◀ or ▶ button to select Clean Print Head.



4. Press the ⬠ Start button to start cleaning the print head.
5. The processing icon appears on the screen while cleaning is in progress.



6. When cleaning finishes, print a nozzle check pattern to check the results. See “Checking the Print Head Nozzles” on page 39.

---

## Aligning the Print Head


If you have moved PictureMate and print quality is not as good as it was before—for example, you see misaligned vertical lines or light or dark horizontal banding—you may need to align the print head.

1. Make sure that PictureMate is turned on and no warnings or errors are displayed on the LCD panel.
2. Load a sheet of photo paper. See “Loading Paper” on page 12.
3. Press the Mode button to select .
4. Press the ◀ or ▶ button to select Align Print Head.



5. Press the  Start button to print the alignment pattern.

6. The following alignment sheet is printed.



7. Look at the alignment pattern in each set and find the patch which is most evenly printed, with no noticeable streaks or lines.
8. Press the ▲ or ▼ button to highlight the number for the best pattern (1 to 9).



9. Press the  Start button to exit the alignment screen.

---

## ***Cleaning PictureMate***

To keep PictureMate operating at its best, clean it thoroughly several times a year as follows.

1. Turn off PictureMate and unplug the power cord.
2. Remove any paper from the paper support.
3. Use a soft brush to carefully clean away all dust and dirt from the paper support.
4. If the outer case or the inside of the paper support is dirty, wipe it with a soft, clean cloth dampened with mild detergent. Keep the output tray closed to prevent water from getting inside.



### ***Caution:***

- Never use alcohol or thinner to clean the printer, as these chemicals can damage the components as well as the case.*
- Be careful not to get water on the printer mechanism or electronic components.*
- Do not use a hard or abrasive brush.*
- Do not spray the inside of the printer with lubricants. Unsuitable oils can damage the mechanism. Contact your dealer or a qualified service person if lubrication is needed.*

---

## Troubleshooting

The solutions herein are for problems when printing directly from a memory card.

---

### Error/Warning Messages

You can identify many common printer problems using the display on your printer's LCD panel. See "Panel Icon List" on page 59.

---

### Printer Power Problems

#### LCD panel is off

- ❑ Press the  On button to make sure that the printer is on.
- ❑ Turn off the printer and make sure that the power cord is securely plugged in.
- ❑ Make sure that your outlet works and is not controlled by a wall switch or timer.

- ❑ If you are using the optional battery, it may be empty, or it may not be installed all the way into the compartment. See "Charging the battery" on page 51 for instructions on charging the battery. See "Installing the battery" on page 50 for instructions on installing the battery.

#### LCD panel came on and then went out

The printer's voltage may not match the outlet rating. Turn off the printer and unplug it immediately. Then, check the printer labels.



#### **Caution:**

*If the voltage does not match, DO NOT PLUG YOUR PRINTER BACK IN. Contact your dealer.*

#### Power light came on and then went out

If you are using the optional battery, it may be empty, or it may not be installed all the way into the compartment. See "Charging the battery" on page 51 for instructions on charging the battery. See "Installing the battery" on page 50 for instructions on installing the battery.

---

## ***Print and Noise Problems***

**PictureMate makes an unexpected noise after you install a photo cartridge.**

The first time you install the photo cartridge, PictureMate will charge its print head for about three and a half minutes. Wait until charging finishes before you turn it off, or it may charge improperly and use more ink the next time you turn it on.

**Your PictureMate makes an unexpected noise when you turn it on or after it has been sitting for awhile.**

PictureMate is performing routine maintenance.

**PictureMate sounds as though it is printing, but nothing prints.**

- ❑ PictureMate may be preparing to print.
- ❑ Make sure the print head nozzles are not clogged. To clean the print head, see “Cleaning the Print Head” on page 40.
- ❑ PictureMate won’t work properly if it’s tilted or at an angle. Place it on a flat, stable surface that extends beyond the printer base in all directions.

- ❑ Make sure paper is not jammed and is loaded correctly so it can feed into PictureMate. Make sure the handle is not resting on the paper. See “Loading Paper” on page 12 for paper loading instructions.

**Your memory card does not work correctly.**

- ❑ Make sure you are using a compatible memory card. See “Inserting Your Memory Card” on page 14.
- ❑ Make sure only one card is inserted at a time. PictureMate does not read from multiple cards at once.
- ❑ Photos must be in JPEG or Uncompressed TIFF format and taken with a DCF-compliant camera.
- ❑ PictureMate can recognize and print the first 999 photos on your memory card.

---

## Photo Quality Problems

**You see banding (light lines) in your prints.**



- ❑ The print head nozzles may need cleaning; see “Cleaning the Print Head” on page 40.
- ❑ Make sure the glossy side of the paper is face up.
- ❑ The photo cartridge may need replacing. To replace the cartridge, see “Replacing the Photo Cartridge” on page 33.
- ❑ The print head may need aligning; see “Aligning the Print Head” on page 41.

**Your printout is blurry or smeared.**



- ❑ Use the PictureMate Photo Paper to ensure proper saturation, absorption of ink, and quality.
- ❑ Make sure you load paper with the glossy side face up.
- ❑ Make sure your paper isn't damp or curled, or loaded face down (the glossy side should be face up). If it's damp or curled, load a new stack of paper.

**Your printout is faint or has gaps in the image.**



- ❑ The print head may need aligning; see “Aligning the Print Head” on page 41.
- ❑ The print head nozzles may need cleaning; see “Cleaning the Print Head” on page 40 for instructions.
- ❑ The photo cartridge may be old or low on ink. To replace the photo cartridge, see “Replacing the Photo Cartridge” on page 33.

- ❑ Make sure your paper isn't damaged, old, dirty, or loaded face down. If it is, reload a new stack of paper with the glossy side up.

### **Colors in your photo are wrong or missing.**

- ❑ Make sure the Color Effect setting is set to Color for color photos. See "Printing Photos in Black and White or Sepia" on page 18.
- ❑ The print head nozzles may need cleaning; see "Cleaning the Print Head" on page 40.
- ❑ The photo cartridge may be old or low on ink. To replace the cartridge, see "Replacing the Photo Cartridge" on page 33.

---

## ***Problems With Paper Feeding***

### **Paper doesn't eject fully or is wrinkled.**

If it's wrinkled when it ejects, the paper may be damp or too thin.

### **Paper doesn't feed correctly or jams in the printer.**

- ❑ Make sure the paper support is pulled up, all the way out, and is not leaning on the handle. The handle should be all the way down in back of PictureMate. Make sure the handle is not resting on the paper. See "Loading Paper" on page 12.
- ❑ If paper doesn't feed, remove it from the paper support, reload it against the right edge, then slide the left edge guide against the paper (but not too tightly).
- ❑ If multiple pages feed at once, remove the paper from the paper support, separate the sheets, and carefully reload it.
- ❑ If paper jams, remove the paper, then press the ⬠ Start button to clear the jam.
- ❑ Load paper glossy side up. Load up to a maximum of 20 sheets. Place the paper against the right edge and slide the edge guide against it, but not so tight that paper can't move.
- ❑ Don't load plain paper; this may damage PictureMate.
- ❑ Make sure you are using available paper for this printer (see "Consumable Products" on page 49). Store paper flat to help prevent curling.

---

## **Miscellaneous Printout Problems**

### **The printer prints blank pages.**

The print head may need cleaning. See “Cleaning the Print Head” on page 40.

### **The borders or layout are incorrect.**

- ❑ Check your Layout setting to see if it is correct. See “Basic Photo Printing” on page 16.
- ❑ If you have a border on one side of your photo but not the other, make sure the paper is positioned correctly in the paper support, all the way to the right. Slide the edge guide against the paper.
- ❑ If the subject of your photo is very close to the edge of the image, you may want to select Border as the Layout setting. This prevents the automatic enlargement of your photo (to eliminate the borders) which may be causing part of your image to be cut off.

### **The wrong photo is printed.**

- ❑ If your camera supports DPOF, you can pre-select photos so PictureMate will print only the ones you want. See “Printing Camera-Selected DPOF Photos” on page 17.
- ❑ If your camera is PictBridge- or USB DP-enabled, you can connect it to PictureMate and control printing from your camera. See “Printing From a PictBridge-Enabled Camera” on page 25.

---

# Contacting Customer Support

---

## Regional Customer Services

If your Epson product is not operating properly and you cannot solve the problem using the troubleshooting information in your product documentation, contact customer support services for assistance. Check your Pan-European Warranty Document for information on how to contact EPSON Customer support.

They will be able to help you much more quickly if you give them the following information:

- Product serial number  
(The serial number label is usually on the back of the product.)
- Product model
- Product software version  
(Click About, Version Info, or similar button in the product software.)
- Brand and model of your computer

- Your computer operating system name and version
- Names and versions of the software applications you normally use with your product

**Note:**

*For more information on Contacting Customer Support, see the Online User's Guide included in the software CD-ROM*

---

## Technical Support Web Site

Go to <http://www.epson.com> and select the Support section of your local EPSON web site for the latest drivers, FAQs, manuals and other downloadables.

Epson's Technical Support Web Site provides help with problems that cannot be solved using the troubleshooting information in your printer documentation. If you have a Web browser and can connect to the Internet, access the site at:  
<http://support.epson.net/>

---

# Options and Consumable Products

---

## Options

### Bluetooth Photo Print Adapter

Bluetooth unit C12C824\*\*\*

**Note:**

The asterisk is a substitute for the last digit of the product number, which varies by location.

➔ See “Printing From a Bluetooth Device” on page 26

### Lithium Ion Battery

An optional rechargeable battery means you can use PictureMate without the AC adapter.

Lithium Ion Battery C12C83107\*

**Note:**

The asterisk is a substitute for the last digit of the product number, which varies by location.

For details on using the optional battery, see “Using the Optional Battery” on page 50.

## Consumable Products

The following photo cartridge and Epson special paper are available for PictureMate.

PictureMate PicturePack (PictureMate Photo Cartridge and PictureMate Photo Paper)	T5730
PictureMate Photo Cartridge	T573
EPSON Premium Glossy Photo Paper 10 × 15 cm (4 × 6 in.)	S041692 S041730 S041750
EPSON Premium Semigloss Photo Paper 10 × 15 cm (4 × 6 in.)	S041925

**Note:**

- The availability of special paper varies by location.
- Please check your local EPSON customer support website where to buy or visit your local dealer.  
➔ See “Contacting Customer Support” on page 48

---

## Using the Optional Battery

### Note:

- ❑ *Install the battery after installing the first photo cartridge and after ink charging is finished.*
- ❑ *You cannot save data on the memory card to an external device when using the battery. Connect the AC adapter to PictureMate when you save data.*
- ❑ *When you copy data on a computer to your memory card, confirm that there is enough power in the battery. If the battery runs out, saving is canceled, and corrupted data may remain on the memory card.*


For safety instructions for the battery, see “When using the optional battery” on page 5.

## Installing the battery


Follow the steps below to install the battery.

1. Make sure that PictureMate is turned off.
2. Unplug the AC adapter from the printer.

3. Open the battery cover.




4. Insert the battery into the compartment in the direction shown below until it is fixed in place.



**Note:**

*Push the battery all the way into the compartment so that it locks into place as shown below.*




5. Close the battery cover.

## **Removing the battery**

1. Make sure that PictureMate is turned off.
2. Open the battery cover.

3. Move down the battery latch and pull out it.



4. Close the battery cover.

## **Charging the battery**

After installing the battery, charge the battery using the AC adapter.

1. Make sure that the battery is installed.
2. Connect the power cord and AC adapter, then plug in PictureMate.

When PictureMate is off, the power light blinks during charging. When the battery is fully charged, the power light turns off.

When PictureMate is on during charging,  icon blinks on the LCD panel. When the battery is fully charged,  icon appears.

**Note:**

*The battery may not be charged correctly if the temperature of the operation is not guaranteed.*

## Checking the battery status

The battery status is always displayed at the top left corner of the LCD panel.

Icon	Status
	Sufficient battery power
	When the icon is yellow, battery power is low. When the icon is red, battery power is almost empty.
	Battery power is running out.
	Battery is charging.
	Battery is fully charged.

## Battery performance

Charging Time	Approx. 2 hours at maximum
Continuous Print Time	Approx. 90 minutes
Number of Prints	Approx. 50 sheets (4 × 6 in.) *

\* When printing from a Memory Stick with a fully charged, fresh battery, at room temperature. The number of sheets varies depending on the memory card, data size, and other conditions.

## Auto Power Off

When the battery is used to power PictureMate, PictureMate will automatically turn off to save battery power if it is idle for about 15 minutes.

**Note:**

*When a memory card is inserted and PictureMate is connected to a computer, it will not turn off automatically.*

---

# Printer Specifications

## Printer

<b>Dimensions</b>	Storage Width: 256 mm (10.0 inches) Depth: 154 mm (6.1 inches) Height: 167 mm (6.6 inches)
	Printing Width: 256 mm (10.0 inches) Depth: 305 mm (12.0 inches) Height: 167 mm (6.6 inches)
<b>Printable area</b>	Border printing: 3 mm margin for all sides of paper Borderless printing: 0 mm margin
<b>Paper tray capacity</b>	20 sheets
<b>Weight</b>	2.7 kg (6.0 lb) without battery and photo cartridge

## Electrical

### Rating

#### Printer

	AC adapter operated	Optional battery operated
Input	DC 20 V, 1.6 A	DC 14.4 V, 1.4 A

#### AC Adapter

Model	A361H
Input	AC 100-240 V, 50-60 Hz, 0.8-0.4 A, 42 W
Output	DC 20 V, 1.68 A

## Printer Operated by AC Adapter

		When not charging an optional battery		When charging an optional battery	
		AC 100-120V Input	AC 220-240V Input	AC 100-120V Input	AC 220-240V Input
Power consumption using AC adapter	Continuous printing	Approx. 11.0 W	Approx. 11.5 W	Approx. 30 W	Approx. 30 W
	Sleep mode	Approx. 4.0 W	Approx. 4.5 W	Approx. 22 W	Approx. 23 W
	Stand-by mode	Approx. 0.7 W	Approx. 1.0 W	Approx. 22 W	Approx. 23 W
Input current using AC adapter (Continuous printing)		0.3 A	0.2 A	0.7 A	0.4 A

## Environmental

<b>Temperature</b>	Operation: 10 to 35°C (50 to 95°F)  Storage: -20 to 60°C (-4 to 140°F)  1 month at 40°C (104°F) 120 hours at 60°C (140°F)
<b>Humidity</b>	Operation:* 20 to 80% RH  Storage:* 5 to 85% RH

\* Without condensation

## Built-in card slots

<b>Card Slots</b>	CF Type II card slot	Compatible with "CF+ and CompactFlash Specification 1.4"
	SmartMedia card slot	Compatible with "SmartMedia Standard 2003"
	Memory Stick/ Memory Stick PRO card slot	Compatible with "Memory Stick Standard version 1.3"  Compatible with "Memory Stick Standard Memory Stick PRO Format Specifications version 1.0"
	SD/ MMC card slot	Compatible with "SD Memory Card Specifications / PART1. Physical Layer Specification Version 1.0"  Compatible with "MultiMediaCard Standard"
	xD-Picture Card Slot	Compatible with "xD-Picture Card™ Card Specification Version 1.20 Type M"

<b>Compatible memory cards</b>	CompactFlash SmartMedia* Memory Stick* Memory Stick PRO Memory Stick Duo** Memory Stick PRO Duo** MagicGate Memory Stick* MagicGate Memory Stick Duo** Microdrive SD (Secure Digital) Card MultiMediaCard miniSD card** xD-Picture Card xD-Picture Card Type M
<b>Voltage Requirements</b>	3.3 V 3.3 V/5 V Combined use Maximum current is 500 mA

\* Maximum capacity is 128 MB.

\*\* Adapter required.

## Photo Cartridge

PictureMate Photo Cartridge (T573)

<b>Color</b>	Black, Cyan, Magenta and Yellow
<b>Cartridge life</b>	Within 6 months of opening the package, at 25°C (77°F)
<b>Temperature</b>	Storage: -20 to 40°C (-4 to 104°F) 1 month at 40°C (104°F) Freezing:* -11°C (12.2°F)

\* Ink thaws and is usable after approximately 3 hours at 25°C (77°F).

## External Storage Devices

<b>Connectivity</b>	Universal Serial Bus Specifications Revision 1.1* Bit rate: 12 Mbps (Full speed device) Connector type: USB Series A Data Encoding: NRZI Recommended cable length: Less than 1.8 meters
---------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

\* Not all USB devices are supported. Contact your regional customer support for details.

## Standards and Approvals

### Printer

European model:

EMC      EMC Directive 89/336/EEC  
            EN 55022 Class B  
            EN 55024

### AC Adapter

European model:

Safety    Low Voltage Directive 72/23/EEC  
            EN60950-1  
EMC      EMC Directive 89/336/EEC  
            EN55024  
            EN61000-3-2  
            EN61000-3-3

---

# Index

## A

Align Print Head, 41  
All photos, 16  
Auto correct photo, 18

## B

Backup photos, 22  
Battery  
    buying, 49  
    using, 50 to 52  
Black and white printing, 18  
Blank pages, 47  
Bluetooth, 26, 49  
Blurry prints, 45

## C

Camera  
    printing from, 25  
    selected photos (DPOF), 17  
Care of PictureMate, 39  
Carrying PictureMate, 37  
CD  
    printing from, 24 to 25  
    saving files, 22  
Cell phone  
    printing from, 26  
Charging ink, 44  
Cleaning

    printer, 42  
    print head, 39  
Clogged nozzles, 39  
Color  
    effect, 18  
    problems, 46  
Consumables, 49  
Copying photos, 22

## D

Date Stamp, 20  
Device  
    external, 24 to 26  
DPOF (Digital Print Order Format), 17

## E

Edge guide, 13  
Error messages, 59  
External device  
    printing from, 24 to 25  
    saving files, 22

## F

Faint images, 45  
File formats, 11  
Fix photo, 18  
Flash memory drive  
    printing from, 24 to 25

    saving files, 22  
Folder, 24 to 25

## G

Gaps in image, 45

## I

Image  
    formats, 11  
    quality, 45 to 46  
Incorrect colors, 46  
Index sheet, 17  
Ink, see Photo cartridge

## J

Jams  
    paper, 46  
JPEG, 11

## L

Layout button, 16  
LCD screen  
    messages, 43, 59

## M

Maintenance, 39  
Manuals, 11

Margins  
  incorrect, 47  
Memory card  
  adapter, 14  
  compatibility, 14, 55  
  inserting, 14  
  problems, 43, 44  
  removing, 15  
Memory Stick, 14  
Microdrive, 14  
MiniSD card, 14  
Missing colors, 46  
MMC (MultiMediaCard), 14  
Mode button, 16

## **N**

Noise  
  PictureMate, 44  
Nozzle check, 39  
Nozzle cleaning, 40

## **O**

On button, 14  
Output tray, 12

## **P**

Packing PictureMate, 37  
Paper  
  buying types, 49  
  feeding problems, 46  
  jam, 46  
  tray, 12

PDA  
  printing from, 26  
Photo  
  formats, 11  
  quality, 45 to 46  
Photo cartridge  
  buying, 49  
  ink level, 32  
  replacing, 33 to 36  
  safety instructions, 7  
PhotoEnhance, 19  
PictBridge, 10, 25  
PictureMate PicturePack, 49  
PIM (PRINT Image Matching), 11, 18  
Power cable, 37  
Problems  
  memory card, 44  
  missing colors, 46  
  paper feeding, 46  
  paper jam, 46  
  print quality, 45 to 46

## **Q**

Quality, 45 to 46

## **R**

Removing  
  memory card, 15  
  photo cartridge, 33  
Resolution, 11

## **S**

Saving photo files, 22  
SD (Secure Digital) card, 14  
sepia, 18  
Setup problems, 44  
SmartMedia card, 14  
Smears, 45

## **T**

Technical support, 48  
Thumb drive  
  printing from, 24 to 25  
  saving files to, 22  
TIFF, 11  
Time Stamp, 20  
Transporting PictureMate, 37  
Troubleshooting, 43 to 47

## **U**

USB cable, 24 to 26, 37  
USB DP (USB Direct Print), 10, 25  
User's Guide, 11

## **X**

xD Picture Card, 14


## **Z**



Zip disk  
  printing from, 24 to 25  
  saving files to, 22



## Panel Icon List


Printer errors and conditions are displayed with image icons and numerical codes.

### Error Display

Display	Meaning
	<b>Ink out.</b> Replace the photo cartridge with a new one. ➔ See "Replacing the Photo Cartridge" on page 33
	<b>Paper out.</b> Load Paper. Then press the  Start button to continue or the  Cancel button to cancel. ➔ See "Loading Paper" on page 12
	<b>Paper is jammed.</b> Clear paper jam, then press the  Start button. ➔ See "Problems With Paper Feeding" on page 46


Display	Meaning
	<b>Not enough ink to perform the head cleaning.</b> Replace the photo cartridge with a new one. ➔ See "Replacing the Photo Cartridge" on page 33
	<b>Bluetooth module error.</b> Disconnect the Adapter, then reconnect to the printer. ➔ See "Connecting and Disconnecting the Bluetooth Photo Print Adapter" on page 27
	<b>External device is not connected or media is not inserted.</b> Connect an external device or insert media.
	<b>Insufficient space on the external device.</b> Use an external device with sufficient space.



Display	Meaning
	<b>No memory card is inserted.</b> Insert a memory card.
	<b>PC connected.</b> Disconnect a PC from the printer.
	<b>Cartridge compartment cover is open.</b> Close the cartridge compartment cover.
	<b>Photo cartridge is not inserted.</b> Install the photo cartridge.
	<b>Waste ink pad in the photo cartridge is saturated.</b> Replace the photo cartridge with a new one. ➔ See "Replacing the Photo Cartridge" on page 33

Display	Meaning
	<b>Photo cartridge cannot be recognized.</b> Reinstall the photo cartridge. The genuine EPSON photo cartridge (T573) is recommended for replacement.
	<b>The battery is empty.</b> Connect the AC adapter.
	<b>The battery temperature is abnormal.</b> Turn the power off, then wait until the battery temperature decreases.
	<b>The battery is defective.</b> Replace the battery with a new one. ➔ See "Using the Optional Battery" on page 50
	<b>Mechanical error.</b> Call for service. ➔ See "Contacting Customer Support" on page 48

Display	Meaning
	<p><b>Waste ink pad in the printer is saturated.</b></p> <p>Call for service.  ➔ See "Contacting Customer Support" on page 48</p>

## Warning Display

Display	Meaning
	<p><b>Waste ink pad almost full.</b></p> <p>Call for service.  ➔ See "Contacting Customer Support" on page 48</p>
	<p><b>Temperature inside the printer is too high.</b></p> <p>Move the printer to the shade or a cool place.</p>
	<p><b>No photo data on the memory card.</b></p> <p>Remove the memory card, then check the data on the memory card.  ➔ See "Supported Photo Formats" on page 11</p>

Display	Meaning
	<p><b>Memory card error.</b></p> <p>Remove the memory card, then insert a compatible memory card.  ➔ See "Inserting Your Memory Card" on page 14</p>
	<p><b>Cannot recognize the external device.</b></p> <p>Check connection.</p>
	<p><b>Error in the data.</b></p> <p>The print results may not be perfect. Check the data.</p>
	<p><b>The data is not supported.</b></p> <p>Check the data.</p>
	<p><b>The image is too large to print with Bluetooth.</b></p> <p>Print the data from a memory card or computer.</p>

Display	Meaning
	The image is too complex to print with Bluetooth. Check the data.




## Icon List

Display	Meaning
	Ink is low.

➔ See “Checking the battery status” on page 52 for the battery icons.

## Information

Display	Meaning
	No memory card.





Display	Meaning
	PictBridge Camera connected.
	USB Direct Print Camera connected.
	PC connected
	AC adapter not connected. Connect the AC adapter to install the first photo cartridge.


## Print Mode Display

Display	Meaning
	<p><b>Print all photos</b></p> <p>➔ See "Printing All Photos" on page 16</p>
	<p><b>Print an index</b></p> <p>➔ See "Printing an Index" on page 17</p>
	<p><b>Print DPOF photos.</b></p> <p>➔ See "Printing Camera-Selected DPOF Photos" on page 17</p>

## Setup/Utilities Mode Display

Display	Meaning
	<p><b>Check ink levels.</b></p> <p>Press the ◊ Start button to enter this mode.</p> <p>➔ See "Checking the Photo Cartridge Status (Ink Level)" on page 32.</p>
	<p><b>Clean print head.</b></p> <p>Press the ◊ Start button to enter this mode.</p> <p>➔ See "Cleaning the Print Head" on page 40.</p>
	<p><b>Check ink nozzles.</b></p> <p>Press the ◊ Start button to enter this mode.</p> <p>➔ See "Checking the Print Head Nozzles" on page 39.</p>
	<p><b>Align Print Head.</b></p> <p>Press the ◊ Start button to enter this mode.</p> <p>➔ See "Aligning the Print Head" on page 41.</p>

Display	Meaning
 Color Effect	<b>Color effect.</b> Press the ◊ Start button to enter this mode. ➔ See "Printing Photos in Black and White or Sepia" on page 18.
 Auto Correct	<b>Auto correct.</b> Press the ◊ Start button to enter this mode. ➔ See "Fixing Your Photos" on page 18.
 Date Stamp	<b>Date stamp.</b> Press the ◊ Start button to enter this mode. ➔ See "Adding the Date or Time" on page 19.
 Time Stamp	<b>Time stamp.</b> Press the ◊ Start button to enter this mode. ➔ See "Adding the Date or Time" on page 19.
 Backup	<b>Backup.</b> Press the ◊ Start button to enter this mode. ➔ See "Saving Your Photos to an External Device (Backup)" on page 22

Display	Meaning
 Select Folder	<b>Select folder.</b> Press the ◊ Start button to enter this mode.  Appears only when an external device is connected. ➔ See "Printing From an External Drive" on page 24.

See "Bluetooth Settings" on page 28 on the menus that appear when the optional Bluetooth Photo Print Adapter is connected.