

EPSON®

EPSON Stylus® Pro 10000
Printer Guide



EPSON Stylus® Pro 10000 Series

PRINTER GUIDE

EPSON®



Printed on recycled paper.

Copyright © 2001 by Epson America, Inc.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of SEIKO EPSON CORPORATION. The information contained herein is designed only for use with these EPSON printers. EPSON is not responsible for any use of this information as applied to other printers.

Trademarks

EPSON, EPSON Stylus, ESC/P, and Micro Piezo are registered trademarks of SEIKO EPSON CORPORATION.

DX3, PhotoEnhance, SelecType, and EPSON Archival are trademarks and EPSON Preferred is a service mark of Epson America, Inc.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. EPSON disclaims any and all rights in those marks.

The ENERGY STAR emblem does not represent EPA endorsement of any product or service.

Legal Notices

Neither SEIKO EPSON CORPORATION nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with SEIKO EPSON CORPORATION's operating and maintenance instructions.

SEIKO EPSON CORPORATION shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original EPSON Products or EPSON Approved Products by SEIKO EPSON CORPORATION.

Part Number: CPD-122085/01

FCC Compliance Statement

For United States Users

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING

The connection of a non-shielded equipment interface cable to this equipment will invalidate the FCC Certification of this device and may cause interference levels which exceed the limits established by the FCC for this equipment. It is the responsibility of the user to obtain and use a shielded equipment interface cable with this device. If this equipment has more than one interface connector, do not leave cables connected to unused interfaces. Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

For Canadian Users

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

For European Users

This product conforms to CE marking requirements in accordance with EC Directive 89/336/EEC.

WARNING

This is a Class A product. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures.

Contents

Introduction

Options and Accessories	2
How To Use Your Manuals	3
Using This Printer Guide	3
Warnings, Cautions, and Notes	4
Where To Get Help	4
Macintosh System Requirements	5
Windows System Requirements	6
ENERGY STAR Compliance	7
Important Safety Instructions	7
Ink Cartridge Safety Instructions	8

1 Setting Up the Printer

Installing the Ink Cartridges	1-1
Loading the Roll Paper	1-4
Attaching the Roll to the Paper Spindle	1-4
Inserting the Paper Spindle in the Printer	1-5
Loading the Roll Paper	1-6
Running a Nozzle Check	1-9
Connecting the Printer to Your Computer	1-11
Connecting to the USB Port	1-11
Connecting to a Parallel Port (Windows Only)	1-12
Connecting to the IEEE 1394 (FireWire) Port	1-12
Installing Printer Software for Macintosh	1-13
Installing Printer Software for Windows	1-15
Setting Up Your Printer for Sharing	1-16
Setting Up on a Macintosh Network	1-17
Setting Up on a Windows 95, 98, or Me Network	1-19
Setting Up on a Windows NT 4.0 or Windows 2000 Network	1-22
Aligning the Print Head	1-25
Running the Print Head Alignment Utility	1-25

2 Handling Paper and Other Media

Selecting Media That Meet Requirements	2-1
Printing on EPSON Media	2-2
Printing Tips for EPSON Media	2-6

Using Roll Paper	2-6
Guidelines for Using Roll Paper	2-7
Using the Roll Paper Belts	2-7
Removing Paper from the Spindle	2-8
Cutting Paper Manually with the Built-in Cutter	2-9
Printing Trim Lines	2-9
Using Cut Sheet Paper	2-10
Printing on Posterboard	2-11
Adjusting the Platen Gap for Heavy Stock	2-13
Using the Paper Hammock	2-14
Catching Printouts in Front of the Printer	2-14
Catching Printouts Under the Printer	2-16
Setting Paper Configurations	2-18
Registering Paper Thickness, Drying Time, and Suction	2-18
Selecting Registered Paper Settings	2-19

3 Printing with EPSON Drivers for Macintosh

Choosing Page Setup Options	3-2
Choosing Basic Print Options	3-3
Selecting the Correct Media Type	3-7
Choosing Advanced Print Options	3-9
Color Management Settings	3-12
Managing Print Jobs	3-13
Setting Up Background Printing	3-13
Using Monitor3	3-14
Cancelling Printing	3-16
Checking Printer Status	3-17
Selecting Configuration Options	3-18

4 Printing with EPSON Drivers for Windows

Choosing Basic Print Options	4-1
Selecting the Correct Media Type	4-4
Choosing Paper and Layout Options	4-6
Choosing Advanced Print Options	4-7
Color Management Settings	4-10

Managing Print Jobs	4-11
Using the Progress Meter	4-11
Using the Spool Manager	4-12
Using Status Monitor 3	4-12
Setting Monitoring Preferences	4-14
Optimizing Print Speed	4-16

5 Monitoring and Configuring the Printer

Using the Control Panel to Monitor the Printer	5-1
Monitoring Normal Printer Operation	5-2
Pausing and Resetting the Printer	5-2
Checking Printer Status	5-3
Printing a Status Check	5-3
Checking Ink Levels and Component Life	5-4
Responding to Control Panel Lights and Messages	5-5
Using the Control Panel to Configure the Printer	5-8
Setting Default Roll Paper Margins	5-8
Turning Off Paper Monitoring Features	5-9
Selecting the Printer's Interface	5-9
Configuring the Parallel Interface	5-10
Changing the Printer's Code Page Setting	5-11
Restoring Default Settings	5-11
Setting the Control Panel Language	5-12

6 Maintaining and Transporting the Printer

Running a Cleaning Cycle	6-1
Using the Head Cleaning Utility	6-1
Cleaning the Print Head Using the Control Panel	6-4
Aligning the Print Head	6-4
Aligning the Print Head from the Control Panel	6-5
Replacing Ink Cartridges	6-7
Replacing the Paper Cutter Blade	6-11
Removing the Used Cutter Blade	6-11
Installing the New Cutter Blade	6-13
Cleaning the Printer	6-14

Transporting or Storing the Printer	6-15
Preparing the Printer for Shipment	6-15
Moving the Printer on the Stand	6-17
Replacing the Waste Ink System	6-19

7 Resolving Problems

Diagnosing Problems	7-1
Using Hex Dump Mode	7-2
Improving Print Quality	7-2
Solving Operational Problems	7-5
Solving Miscellaneous Printing Problems	7-6
Solving Paper Problems	7-8
Solving Roll Paper Feed Problems	7-9
Clearing Paper Jams	7-11
Uninstalling and Reinstalling the Printer Software	7-12
Macintosh	7-12
Windows	7-13

A Specifications

Printing	A-1
Environmental	A-2
Mechanical	A-2
Electrical	A-3
Initialization	A-3
Safety Approvals	A-3
Paper	A-4
Printable Area	A-5
Ink Cartridges	A-5
Parallel Interface	A-7
Forward Channel	A-7
Reverse Channel	A-7
ECP Mode	A-7
USB Interface	A-8

Index

Introduction

Introducing a new era in wide-format color ink jet printing, the EPSON Stylus® Pro 10000 delivers a combination of richly detailed image quality, faster print speeds, and durable photographic output.

EPSON® offers the Stylus Pro 10000 in two models: Photographic Dye Ink (Stylus Pro 10000) and Archival Ink (Stylus Pro 10000CF). The Photographic Dye Ink model provides the widest color gamut at the lowest cost. However, EPSON Archival™ Ink technology gives you photographic images that will last up to 200 years, and provides a color gamut that rivals dye-based inks.*

The printer provides resolutions up to 1440 × 720 dpi using EPSON's variable size droplet, Micro Piezo® DX3™ print head for precise and consistent dot size. Individual, high-capacity ink cartridges with auto ink-level detection provide increased productivity, ease of use, and low per-print costs.

The EPSON Stylus Pro 10000 prints approximately 231 square feet per hour using the printer's fastest settings, and approximately 72 square feet per hour when printing high-resolution photographic output. And with EPSON's Photo Accelerator Technology, even slower computers can achieve full print engine performance.

The printer may also be equipped with an optional 44-inch auto take-up reel that is compatible with most lamination systems and lets you run long print jobs unattended. For complete flexibility, the EPSON Stylus Pro 10000 also supports many third-party RIPs and comes with custom EPSON drivers and utilities for photographs and other non-PostScript printing.

* Lightfastness rating is based on accelerated testing of prints on special media, displayed indoors, under glass. Actual print stability will vary according to image, display conditions, light intensity, humidity, and atmospheric conditions. EPSON does not guarantee the longevity of prints. For maximum print life, display all prints under glass or lamination or properly store them.

Options and Accessories

Your EPSON Stylus Pro 10000 printer offers these optional upgrades and accessories:

Optional equipment and software



If you purchase the optional 10/100 BaseT Ethernet Type B interface card, install it in the optional interface slot on the back of the printer. See the *EpsonNet Internal Print Server Administrator's Manual* for instructions.

For network connectivity, you must also install the EPSON Stylus Pro 10000 printer software on all client systems. See page 1-13 (Macintosh) or page 1-15 (Windows) in this manual.

Option	Part number
EpsonNet Internal Print Server (10/100 BaseT Ethernet™ Type B interface card)	C823632A
Automatic Take-Up Reel System	C815172
Paper Roller Spindle (High Tension) — 2-inch	C811134
Paper Roller Spindle (High Tension) — 3-inch	C811122
Replacement Media Cutter Blade*	C815131
Manual Media Cutting System**	C815182
Replacement Manual Cutter Blade (for Manual Media Cutting System)	C815192

* Replaces the blade for the printer's built-in cutter (see page 6-11 for details).

** Designed for use with heavy media, which can damage the printer's built-in cutter.

You can purchase optional equipment and software, ink cartridges, paper, and manuals from EPSON at (800) 873-7766, or you can visit the EPSON Store™ at www.epsonstore.com (U.S. sales only). In Canada, please call (800) 873-7766 for dealer referral.

Check the EPSON Pro Graphics web site at prographics.epson.com for new accessories and options, including RIP software, which may become available.

How To Use Your Manuals

This guide is part of a set, which also includes the documentation listed below:

- The EPSON Stylus Pro 10000/10000CF *Unpacking and Assembly Guide* describes how to unpack and assemble the printer.
- The EPSON Stylus Pro 10000 *Quick Reference Guide* provides a handy summary of procedures for daily use and printer maintenance—loading paper, replacing ink cartridges, running cleaning cycles, aligning the print head, and clearing paper jams. Attach it to your printer for easy reference.
- The electronic *Reference Guide* on the EPSON printer driver CD-ROM provides additional information about the printer, drivers, and utility software. You can read the guide using a web browser, such as Netscape® Navigator® or Microsoft Internet Explorer, versions 3.0 or later.

Using This Printer Guide

This guide contains the following information:

Chapter 1 describes how to install ink cartridges, load roll paper, install the printer software, and prepare for printing. It also explains how to set up the printer for sharing.

Chapter 2 gives instructions for loading and printing on various media, and for using the paper hammock.

Chapter 3 describes how to use the EPSON printer driver and the Monitor3 utility to print from a Macintosh.

Chapter 4 explains how to print from Windows using the EPSON printer driver and utilities.

Chapter 5 explains how to use the printer's control panel to monitor the printer's status and configure printer settings.

Chapter 6 gives instructions for cleaning and aligning the print head, replacing ink cartridges and the cutter blade, and cleaning and transporting the printer.

Chapter 7 provides troubleshooting tips and solutions for problems involving print quality, printer operation, and paper handling.

Appendix A provides the technical specifications for your printer, media, and ink cartridges.

An Index is included at the end of the book.

Warnings, Cautions, and Notes

You'll find this information throughout this guide:



Warnings must be followed carefully to avoid bodily injury.



Cautions must be observed to avoid damage to your equipment.



Notes contain important information about your printer.



Tips contain additional hints on how to get the most out of your printer.

Where To Get Help

EPSON provides technical support and information on the installation, configuration, and operation of professional graphics arts products through the EPSON PreferredSM Protection Plan. Dial (888) 377-6611, 6 AM to 8 PM, Pacific Time, Monday through Friday, and 7 AM to 4 PM, Pacific Time, Saturday.

Before you call, make sure you have your Unit ID number, which is included with the EPSON Preferred Protection Plan information that came with your printer. You'll also need your printer serial number and proof of purchase.

EPSON also provides technical assistance 24 hours a day through the World Wide Web. You can reach EPSON Support at <http://support.epson.com>. At this site, you can download drivers and other files, look at product documentation, access troubleshooting information, and receive technical advice through e-mail.

You can purchase ink cartridges, paper, and accessories from EPSON at (800) 873-7766, or visit the EPSON Store at www.epsonstore.com (U.S. sales only). In Canada, please call (800) 873-7766 for dealer referral.



If you are not using Photo Printing Accelerator in your driver (see page 3-4 for details), or if you are using a software or hardware RIP, you must have a Power Macintosh G4 with 500 MHz or higher processor and 512MB RAM to keep the printer running at full engine speed.

For optimum performance, we recommend the latest Macintosh system available with a FireWire connection.

If you are running System 8.5.1 on an iMac, Apple recommends that you download iMac Update 1.1 from their web site.

Macintosh System Requirements

To use your printer in either a standalone or peer-to-peer network environment, your system should include the requirements listed below:

- For USB connection: Power Macintosh® G3, G4, or iMac™ series (System 8.5.1 through 9.1; System 9.1 recommended)
 - For IEEE 1394 connection: iMac DV, G3, or G4 series (System 8.6 or later with FireWire® Update 2.1 or later)
 - For 10/100 BaseT Ethernet connection: iMac, G3, or G4 series (System 8.5.1 through 9.1)
- 350 MHz or higher processor
- 256MB of RAM
- At least 50MB of free hard disk space to install the software, and at least 150MB of free hard disk space for processing files (2GB or more available hard disk space recommended)
- Quad-speed (4×) or faster CD-ROM or DVD drive for installing the printer software
- For USB connection: a compliant USB port and a shielded USB “AB” cable from Series A (computer) to Series B (printer), up to 6.6 ft (2 meters) long
 - For IEEE 1394 (FireWire) connection: a compliant IEEE 1394 port and a shielded IEEE 1394 cable
 - For network connection: the optional EpsonNet Print Server (described on page 2) and compatible cable



If you are not using Photo Printing Accelerator in your driver (see page 4-3 for details), or if you are using a software or hardware RIP, you must have a Pentium III 700 MHz or higher processor with 512MB RAM to keep the printer running at full engine speed.



Using an improperly shielded USB cable—especially a cable more than 6.6 ft. (2 meters) long—may cause the printer to malfunction.

Windows System Requirements

To use your printer in either a standalone or peer-to-peer network environment, your system should include the requirements listed below:

- IBM®-compatible PC with a Pentium® II 400 MHz or higher processor recommended
- For parallel connection: Windows 95, 98, Me, NT 4.0, or 2000

For USB connection: PC with USB port running Windows 98 (factory installed), Me, or 2000

For IEEE 1394 connection: PC with FireWire port running Windows Me or 2000

For 10/100 BaseT Ethernet connection: Ethernet equipped PC running Windows 95, 98, Me, NT 4.0, or 2000

- 256MB of RAM
- At least 50MB of free hard disk space to install the software, and at least 150MB of free hard disk space for processing files (2GB or more available hard disk space recommended)
- Quad-speed (4x) CD-ROM or DVD drive for installing the printer software
- For parallel connection: a high-speed bidirectional, IEEE-1284 compliant parallel cable, 6 to 10 ft. (1.8 to 3 m) long, with a D-SUB, 25-pin, male connector for your computer and a 36-pin, Centronics® compatible connector for the printer

For USB connection: a computer running Windows 98, Me, or 2000 with a Windows compliant USB port and a shielded USB “AB” cable from Series A (computer) to Series B (printer), up to 6.6 ft. (2 meters) long

For IEEE 1394 (FireWire) connection: a compliant IEEE 1394 port and a shielded IEEE 1394 cable

For network connection: the optional EpsonNet Print Server (described on page 2) and compatible cable



ENERGY STAR Compliance

As an ENERGY STAR Partner, EPSON has determined that this product meets the ENERGY STAR guidelines for energy efficiency.

The EPA ENERGY STAR Office Equipment program is a voluntary partnership with the computer and office equipment industry to promote the introduction of energy-efficient personal computers, monitors, printers, fax machines, and copiers in an effort to reduce air pollution caused by power generation.



Always turn the printer off using the **Power** button. When you press this button, the **Operate** light flashes briefly, then goes out. Do not unplug the printer or turn off the power to the printer until the **Operate** light is off. This ensures that the print head is safely capped.

Important Safety Instructions

Before using your printer, read the following safety instructions to make sure you use the equipment safely and effectively.

- Turn off and unplug the printer before cleaning. Clean with a damp cloth only. Do not spill liquid on the printer.
- Do not place the printer on an unstable surface or near a radiator or heating vent. Avoid areas subject to rapid changes in temperature and humidity or shock and vibrations.
- Do not place the printer near a window or in direct sunlight. Bright light can interfere with the paper sensors, causing paper jams and related problems.
- Keep the entire system away from potential sources of electromagnetic interference, such as loudspeakers or the base units of cordless telephones.
- Place the printer on a flat surface. It will not operate properly if it is tilted or at an angle.
- Do not block or cover the openings in the printer case or insert objects through the slots.
- Use only the type of power source indicated on the label.
- Connect all equipment to properly grounded power outlets. Avoid using outlets on the same circuit as photocopiers or air control systems that regularly switch on and off. Do not use outlets controlled by wall switches or timers.

- Place the printer near a wall outlet where the plugs can be easily unplugged.

Placez l'imprimante près d'une prise de contact où la fiche peut être débranchée facilement.

- Do not let the power cords become damaged or frayed.
- If you use an extension cord with the printer, make sure the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating. Also, make sure the total ampere rating of all devices plugged into the wall outlet does not exceed the wall outlet's ampere rating.
- Except as specifically explained in the documentation, do not attempt to service the printer yourself. Opening or removing those covers that are marked "Do Not Remove" may expose you to dangerous voltage points or other risks. Refer all servicing in those compartments to service personnel.
- Power down the printer from the control panel, unplug the printer and refer servicing to qualified service personnel under the following conditions:

If the power cord or plug is damaged; if liquid has entered the printer; if the equipment has been dropped or the case damaged; if the printer does not operate normally or exhibits a distinct change in performance. Adjust only those controls that are covered by the operating instructions.

Ink Cartridge Safety Instructions

- Do not put your hand inside the printer or touch the cartridges during printing.
- To avoid damaging the printer, do not move the print head by hand.
- Under normal circumstances, ink will not come out of the cartridge. If it does get on your skin, wash it off with soap and water. If it gets in your eyes, flush them immediately with water.
- Keep ink cartridges out of the reach of children and do not drink the ink.
- Do not store ink cartridges at high or freezing temperatures. Keep cartridges away from direct sunlight.

- Do not dismantle the ink cartridges or try to refill them. This could result in damage to the print head.
- Install the ink cartridge immediately after you remove it from its package. Leaving the cartridge unpacked for a long time before use may result in reduced print quality.
- Do not use an ink cartridge beyond the date printed on the cartridge package. For best results, use cartridges within six months of installation.

Chapter 1: Setting Up the Printer



Before you begin this chapter, complete the instructions in the *Unpacking and Assembly Guide*.



The ink cartridges that came with your printer include a special chip that causes the printer to initialize as the correct ink model. Make sure you install these ink cartridges when you set up the printer.

Once you've assembled the printer, you're ready to finish setting it up. Even if you have no experience, you can easily complete this process. You should allow at least two hours so that you don't feel rushed.

This chapter covers the following information:

- Installing the ink cartridges
- Loading the roll paper
- Running a nozzle check
- Connecting the printer to your computer
- Installing the printer software and configuring it for network use, if necessary
- Aligning the print head from the printer software

Installing the Ink Cartridges


It's important that the first ink cartridges you install be the ones that came with the printer. The chips on these cartridges are programmed to cause the printer to initialize as the correct ink model: Archival Ink or Photographic Dye Ink. Ink cartridges that you later buy from EPSON do not have the same program on their chips.

Before you begin, make sure that the printer is plugged into a grounded outlet. Then locate the ink cartridges that came with the printer. Follow these steps to install the cartridges:


1. Press the  **Power** button on the control panel to turn the printer on.

1-2 | Setting Up the Printer

2. Push the indentation on the ink compartment cover to release the lock and open the cover. **INK COMPART. OPEN** appears on the display on the printer's control panel.




3. Push down on the top of the first cartridge clamp and pull it forward.



Be careful not to touch the green computer chip on one side of the cartridge. This may affect normal operation and printing.


4. Locate the package for the black ink cartridge and open it. Remove the cartridge. If you're installing Archival Ink cartridges, shake the cartridge gently, as shown.






If ink gets on your hands, wash them thoroughly with soap and water. If ink gets in your eyes, flush them immediately with water.

5. Hold the cartridge so the arrow mark on the left side of the cartridge is pointing to the rear of the printer. Insert the cartridge into the slot. Don't force it.



If you can't insert the cartridge smoothly, you may have the wrong cartridge.

6. Push the clamp back up into the locked position.



Never turn off the printer, change the position of the paper set lever, or open the lower cover or ink compartment cover while the **Pause** light is flashing.

7. Repeat steps 3 through 6 for the other ink cartridges. When you're done, close the ink compartment cover.

The printer begins charging the advanced ink delivery system. The **Pause** light on the control panel flashes and the printer makes various sounds.

Charging takes about 4 minutes. Do not turn off the printer or interrupt this important process or you'll use up more ink than necessary. When the **Pause** light stops flashing and **Paper Out** appears on the control panel display, you're ready to load the roll paper.


Loading the Roll Paper

Loading roll paper involves three steps: attaching the roll to the paper spindle, inserting the spindle in the printer, and loading the paper for printing. Before you begin, remove the paper from its box and remove the plastic cap and protective covering. Then locate one of the paper spindles that was packed in your printer box.


Attaching the Roll to the Paper Spindle

Follow these steps to attach the roll to the spindle:


1. Slide the movable paper stop (flange) off the left end of the spindle.




2. Position the roll so the paper unwinds as shown:



3. Slide the roll onto the spindle so it fits securely against the fixed paper stop.



4. Slide the movable paper stop back onto the spindle and insert it into the end of the roll. Make sure that it is firmly fixed into the left end of the paper roll.



Avoid touching the printable surface of the paper as much as possible. Oils from your skin can affect print quality.


Note

You can have two rolls of paper in the printer at the same time, and print on either one. If you have two rolls, make sure to wind one of the roll paper belts that came with your printer around the end of the roll you're not using. See page 2-7 for more information.


Inserting the Paper Spindle in the Printer

Follow these steps to insert the spindle in the printer:

1. Open the roll paper cover. Position the spindle so that the white end (with the wide fixed paper stop) is on the right.



2. Insert the white end into the right mounting bracket inside the printer. You can use either the upper or lower bracket.




1-6 | Setting Up the Printer



When you remove the spindle, lift the left end out first. See page 2-8 for details on removing paper from the spindle.

3. Place the black end of the spindle into the corresponding left mounting bracket inside the printer.




Loading the Roll Paper

Follow these steps to load the roll paper for printing:



To avoid feeding excess paper, make sure you don't select **Sheet** when you're using roll paper.


1. Press the **Paper Source** button on the control panel until the **Roll Auto Cut** light comes on.






To avoid damaging the printer, never move the paper set lever while the **Operate** or **Pause** light is flashing.

2. Pull the paper set lever out, to the released position. The **Paper Out** light on the control panel comes on and **LOAD PAPER** appears on the control panel display.




3. Feed the paper into the paper slot.




1-8 | Setting Up the Printer

4. Pull the paper down so it extends all the way through the slot.




5. Turn the roll back to remove the slack. Then align the paper with the two rows of holes at the paper exit.





To avoid damaging the printer, never move the paper set lever while the **Operate** or **Pause** light is flashing.

6. Push the paper set lever all the way in, then close the roll paper cover. **PRESS PAUSE BUTTON** appears briefly on the control panel display.



7. Press the **Pause** button. The print head moves and the paper feeds into printing position automatically. **READY** appears on the control panel display. (Even if you don't press **Pause**, the paper and printer will move into printing position automatically after 10 seconds.)

Running a Nozzle Check

The nozzle check prints a pattern of dots that lets you see if any print head nozzles are clogged. You can also use the nozzle check at this point to make sure the printer is operating correctly before you connect it to your computer.

There are two ways to run a nozzle check.


- Using the printer's control panel buttons, as described below
- Using the Nozzle Check utility from your printer software, as described on page 6-1 (not available if you're accessing the printer over a network)

Follow these steps to print a nozzle check using the control panel buttons:


1. Make sure the printer is turned on but not printing, and paper is loaded.

2. Press the **SelecType** button on the control panel until you see **TEST PRINT MENU** on the display.
3. Press the **Item** button. You see **NOZZLE CHECK=PRINT** on the display.
4. Press the **Enter** button. The nozzle check prints as shown below.

If all the lines on the check pattern are complete, with no gaps in the pattern, the print head doesn't need cleaning:



If dots are missing from the pattern, as shown below, you need to run a cleaning cycle. See page 6-1 for instructions.



If the nozzle check fails to print, make sure your ink cartridges are correctly installed. Then run a cleaning cycle, as described on page 6-1. If this doesn't work, turn off the printer and make sure that the interface cable is securely plugged in and that it meets the required specifications, as described on page 5 or 6.

If the nozzle check still fails to print, check the control panel display for any error messages and contact your dealer, or contact EPSON as described on page 4.

Connecting the Printer to Your Computer



Check the system requirements on page 5 or 6 before connecting your printer to make sure your system meets or exceeds the minimum requirements.

Depending on your system, you can connect the printer to your computer using any of the following:


- USB interface—for Windows 98, Me, 2000, and Macintosh
- Parallel interface—for Windows
- IEEE 1394 (FireWire) interface—for Windows Me, 2000, and Macintosh
- EpsonNet Print Server—network connectivity for all systems (with purchase of the optional 10/100 BaseT Ethernet Type B interface card)

For instructions on connecting the printer using EpsonNet Print Server, see the documentation that came with your card. For all other interfaces, see the appropriate section below.

Connecting to the USB Port

To connect the printer to a USB port, you need a standard shielded USB cable. Follow the steps below to connect the printer to your computer:

1. Make sure both the printer and your computer are turned off.
2. Connect the  end of the USB cable to the USB port on the back of your printer.




If the printer doesn't work when you attach it to a first tier USB hub port, connect it directly to the USB port on your computer.

3. Connect the  end of the USB cable to your computer's USB port or a first tier USB hub port.

Connecting to a Parallel Port (Windows Only)

To use the printer's built-in parallel interface, you need a shielded, bidirectional, parallel cable. Follow the steps below to connect the printer to your computer:

1. Make sure both the printer and your computer are turned off.
2. Plug the cable connector securely into the printer's interface. Then squeeze the wire clips together until they lock into place on both sides.




3. Plug the other end of the cable into the computer's parallel port.

Connecting to the IEEE 1394 (FireWire) Port

To connect the printer to the IEEE 1394 port, you need a standard shielded IEEE 1394 cable. Follow the steps below to connect the printer to your computer.

1. Make sure both the printer and your computer are turned off.

2. Connect one end of the IEEE 1394 cable to the IEEE 1394 port on the back of your printer.



3. Connect the other end of the IEEE 1394 cable to your computer's IEEE 1394 port.




Turn off all virus protection programs before you install your printer software.

Installing Printer Software for Macintosh

After connecting the printer to your Macintosh, you need to install the printer driver and utilities included on your printer software CD-ROM. Follow these steps:

1. Turn on your Macintosh and your printer.
2. Insert the printer software CD-ROM in a CD-ROM or DVD drive. Double-click the **EPSON** CD-ROM to open its window.
3. Double-click the  icon for your model: **Printer Driver Installer Photographic Dye** or **Printer Driver Installer EPSON Archival Ink**.
4. Double-click the **Installer** icon.

- At the first screen, click **Continue**. The following dialog box appears:



- Click the **Install** button, then click **Continue** on the next screen.
- Follow the instructions to install your software and select a default paper size. When you see a message informing you that installation is complete, click **Restart** to restart your Macintosh.
- After your Macintosh restarts, select **Chooser** from the Apple menu.

If you're going to be sharing the printer on an AppleTalk® network, skip the rest of these steps. Instead see "Setting Up on a Macintosh Network" on page 1-17 to finish configuring the printer.


- Click the **SPro 10000** or **SPro 10000CF** icon, then click the icon for your USB port.



Note

If you're on an AppleTalk network and the AppleTalk setting in the Chooser is **Active**, you may see an alert message when you click the USB port icon. Make the AppleTalk setting **Inactive**, then select the USB port icon. If you're using your Macintosh in an Ethernet environment, you can leave the AppleTalk setting **Active**.

SPro 10000 identifies the driver for the Photographic Dye Ink model, and **SPro 10000CF** identifies the driver for the Archival Ink model.



10. Select the appropriate **Background Printing** radio button to turn background printing on or off.

With background printing on, you can use your Macintosh while it's preparing a document for printing, and use the EPSON Monitor3 utility to manage print jobs.

11. Close the Chooser.

For instructions on using your printer software, see Chapter 3.

Installing Printer Software for Windows

After connecting the printer to your computer, you need to install the printer driver and utilities on your printer software CD-ROM. Follow these steps:

1. Make sure your printer is turned off.
2. Turn on your computer and start Windows.
3. Insert the printer software CD-ROM in a CD-ROM or DVD driver. The installer starts automatically:



If it doesn't start, double-click **My Computer**. Then double-click your CD-ROM icon.



SPro 10000 identifies the driver for the Photographic Dye Ink model, and **SPro 10000CF** identifies the driver for the Archival Ink model.

If you're using Windows 2000 and have connected your printer with a parallel cable or network interface card, click the **Stop Searching** button at step 6 and go to step 7.

4. Double-click the driver installation for your printer model. If you have the Photographic Dye Ink model, double-click **Install Stylus Pro 10000 With Photographic Dye Technology**. If you have the Archival Ink model, double-click **Install Stylus Pro 10000 With Archival Ink Technology**.
5. Click **OK** in the next window to start printer software installation. You see windows opening on your screen during driver installation. On Windows 95 and NT, the Status Monitor 3 utility is also installed now.
6. **Windows 95 or NT:** Turn on your printer and go to step 7.
Windows 98, Me, or 2000: You see a window asking you to turn on your printer. Press the **Power** button until the **Operate** light comes on. After a few moments, the software configures your printer port and installs the Status Monitor 3 utility.
7. When you see a message informing you that installation is complete, click **OK**.
8. Click the  icon to exit the installer.
9. If you're using Windows 95 or NT, or if the final installation completion screen asked you to do so, restart your computer now.

If you want to share the printer with other computers, see the next section for configuration instructions.

For instructions on using your printer software, see Chapter 4.

Setting Up Your Printer for Sharing

Follow the steps in the appropriate section to configure your computer to share the printer on a network:

- “Setting Up on a Macintosh Network” on page 1-17
- “Setting Up on a Windows 95, 98, or Me Network” on page 1-19
- “Setting Up on a Windows NT 4.0 or Windows 2000 Network” on page 1-22



This section tells you how to configure your printer as a shared printer on a network. To connect your printer directly to a network without setting it up as a shared printer, consult your network administrator.

Setting Up on a Macintosh Network


This section explains how to set up the Stylus Pro 10000 as a shared printer on an AppleTalk network. First install the printer software on every computer that will need to access the printer, as described on page 1-13.

Then configure the host Macintosh (the computer to which you connected the printer) to share the printer, and configure the client Macintosh computers to connect to it, as described in the next two sections.

Configuring the Host Macintosh


Perform these steps on the Macintosh to which you connected the printer:

1. Turn on the printer, open the Chooser, and click the printer's icon. Then select the icon for the USB port your printer is connected to.



Turning background printing on allows you to use Monitor3 to manage the print queue on the host computer. See page 3-14 for details.

2. Click the **On** radio button to turn **Background Printing** on.
3. Click the **Setup** button. You see the following dialog box.




4. Check **Share this Printer**, then type a name for the printer and password information as needed.
5. Click **OK**. The name of the shared printer appears in the port list in the Chooser.
6. Close the Chooser.

Configuring the Client Macintosh Computers

Perform these steps on every Macintosh that will need to access the printer:

1. Open the Chooser, click the printer's icon, and then select the shared printer name on the right. You can only select from the printers connected to your current AppleTalk zone.



Note

To avoid unnecessary spooling, background printing should be turned off for all client computers.

2. If you're prompted for a password, enter the password for the printer and click **OK**.
 3. Make sure **Background Printing** is turned off. Then close the Chooser.
- For instructions on using your printer software, see Chapter 3.

**Note**

This section tells you how to configure your printer as a shared printer on a network. To connect your printer directly to a network without setting it up as a shared printer, consult your network administrator.

Setting Up on a Windows 95, 98, or Me Network

This section tells you how to set up your printer so that computers on the network can share it. First install the printer software on every computer that will need to access the printer, as described on page 1-15.

Then configure the host computer (the computer to which you connected the printer) to share the printer, and configure the client computers to connect to it.

Configuring the Host Computer

Perform these steps on the computer to which you connected the printer:

1. Click **Start**, point to **Settings**, then click **Control Panel**.
2. Double-click the **Network** icon.
3. Click the **File and Print Sharing** button. You see this dialog box:




4. Select the **I want to be able to allow others to print to my printer(s)** check box and click **OK**.
5. In the **Network** window, click **OK**.
6. In the **Control Panel**, double-click **Printers**.

**Note**

If you see a dialog box requesting the Windows CD-ROM, insert the CD-ROM and follow the screen prompts. If you see a message asking you to restart your computer, do so. Then continue with step 6.

7. Select your printer, then choose **Sharing** on the File menu (**Properties** for Windows 95). You see a dialog box similar to the following:




8. Select **Shared As**, enter the printer information as needed, then click **OK**.

Configuring the Client Computers

Perform these steps on every computer that will need to access the printer:

1. Click **Start**, point to **Settings**, and click **Printers**.
2. Double-click the **Add Printer** icon.

3. The Add Printer Wizard screen appears. Click Next. You see a window like the following:



4. Click Network printer, then click Next.
5. Click Browse.



6. Double-click the icon of the host computer (directly connected to the printer). Then click the printer's icon.
7. Click OK and follow the messages on the screen to complete configuration.

For instructions on using your printer software, see Chapter 4.



This section tells you how to configure your printer as a shared printer on a small network. To connect your printer directly to a network without setting it up as a shared printer, or to set it up for sharing on a large network, consult your network administrator.

Setting Up on a Windows NT 4.0 or Windows 2000 Network


This section tells you how to set up your printer so that computers on the network can share it. First install the printer software on every computer that will need to access the printer, as described on page 1-15.

Then configure the host computer (the computer to which you connected the printer) to share the printer, and configure the client computers to connect to it.

Configuring the Host Computer

Perform these steps on the computer to which you connected the printer:

1. Click **Start**, point to **Settings**, and click **Printers**.
2. Select your printer icon, then select **Sharing** from the File menu. You see a window like the following:




3. Click the **Shared** (Windows NT) or **Shared as** (Windows 2000) button and enter a share name for the printer. Don't select any drivers from the **Alternate Drivers** (Windows NT) or **Additional Drivers** (Windows 2000) list.
4. Click **OK**.


Configuring the Client Computers

Perform these steps on every computer that will need to access the printer:


1. Click **Start**, point to **Settings**, and click **Printers**.
2. Right-click your printer icon, then click **Properties** (**Document Defaults** for Windows NT).
3. Click the **Ports** tab to display the following window:



4. Click **Add Port**. You see the Printer Ports dialog box:



5. Select **Local Port**, then click **New Port**. The following dialog box appears:



6. In the text box, type the appropriate information for your system using the syntax below, then click **OK**:
\\name of computer connected to the printer\name of the shared printer
7. In the Printer Ports dialog box, click **Close**.
8. On the Ports screen, make sure the new port is added and its checkbox is selected. Then click **OK**.

For instructions on using your printer software, see Chapter 4.



It's a good idea always to run a nozzle check before you align the print head. This ensures that the print head alignment patterns print correctly.

Aligning the Print Head

Before you use the printer, you should align the print head to ensure accurate, clean printouts. You can run the Print Head Alignment utility at this point to check software installation and make sure your printer is set up correctly.

You may have to run the Print Head Alignment utility several times before your printer is ready to use. Make sure that you've run a nozzle check, as described on page 1-9, before you begin. If the print nozzles are clogged, the print head alignment patterns won't print correctly and your print head alignment won't be accurate.

There are two ways to align the print head:

- Using the Print Head Alignment utility in your printer software, as described below (not available if you're accessing the printer over a network)
- Using the printer's control panel buttons, as described on page 6-5

Both procedures align the print head for all modes and resolutions.

Running the Print Head Alignment Utility

1. Make sure the printer is turned on but not printing, and roll paper at least 24 inches wide is loaded.
2. Access the printer settings dialog box, as described on page 3-3 (Macintosh) or page 4-1 (Windows).


Or, with Windows, click **Start**, point to **Settings**, and select **Printers**. Right-click your printer icon, then select **Properties** (Windows 95, 98, or Me), **Document Defaults** (Windows NT), or **Printing Preferences** (Windows 2000).

3. **Macintosh:** Click the  utility button.
Windows: Click the Utility tab.
4. Click the **Print Head Alignment** button.
5. Follow the messages on your screen. The printer prints the head alignment patterns. Two rows consisting of sets of 15 bars are printed across the width of the paper.




If bar #8 (the current alignment setting) shows the smallest gaps for both rows, the print head is aligned. Click **Finish** to exit the Print Head Alignment utility.

6. Examine the first row. You see a series of alignment patterns similar to the pattern below across the width of the paper. Determine which bar in the first pattern has the smallest gaps. In the example below, #8 has the smallest gaps.



7. Look at the other patterns in the first row to see if the same bar consistently has the smallest gaps. If not, choose the bar that generally has the smallest gaps.

8. Use the arrow keys for row #1 to select the number for the best aligned bar.



You may have to realign the print head several times before you use the printer for the first time.

9. Repeat steps 6 through 8 for row #2.
10. If you chose a bar that did not consistently have the smallest gaps, click the **Realignment** button and repeat from step 4. Repeat this step until you can choose a bar that is consistently the best aligned in every pattern in the row.
11. When your alignment printout shows that bar #8 consistently has the smallest gaps for both rows, click **Finish**.

Chapter 2: Handling Paper and Other Media

The EPSON Stylus Pro 10000 prints on a variety of media, including roll paper and cut sheets up to 44 inches wide. You can also use heavy stock, including posterboard up to 59 mil (1.5 mm) thick.

This chapter includes the following information:

- Selecting media that meet your printer's requirements
- Printing on EPSON media
- Using roll paper
- Using cut sheet paper
- Using the paper hammock
- Setting paper configurations for non-EPSON media

Selecting Media That Meet Requirements

You can print on most types of coated, glossy, plain paper, and other media. The printer comes with two 2-inch spindles, so you can have two types of roll paper available for printing at all times (with manual switching). High-tension spindles are also available (in both 2-inch and 3-inch diameters), recommended for media such as EPSON Synthetic Paper and Fine Art Paper.

The following table shows the paper requirements for your printer:

Paper requirements

	Roll paper	Cut sheets
Size	8.3 to 44.02 in. wide (210.8 to 1118 mm)	8.5 × 11 in. to 44 × 62.2 in. (up to 1118 × 1580 mm)
Maximum external roll diameter	2 in. core: 4 in. (103 mm) when using 2 rolls 3 in. core: 5.9 in. (150 mm) when using 1 roll	—
Thickness	3.15 to 19.7 mil (0.8 to 0.5 mm)	3.15 to 59 mil (0.8 to 1.5 mm)

Always test samples of paper stock in the printer before purchasing large quantities or printing large jobs. When you use non-EPSON papers or other media, you may need to “profile” their thickness and ink drying time. See page 2-18 for instructions.



You can purchase roll paper spindles and other accessories or options from the EPSON Pro Graphics web site (<http://prographics.epson.com>) or your authorized EPSON dealer.



Check the EPSON Pro Graphics web site (<http://prographics.epson.com>) or your authorized EPSON dealer for new papers and other media that may be available.

Printing on EPSON Media

EPSON papers, which are specially formulated for the inks used in the printer, ensure high-quality results. The following tables list the product codes for the EPSON media available for your printer.

Stylus Pro 10000 Photographic Dye Ink model media product codes

Paper type	Roll sizes	Sheet sizes
Presentation Matte Paper	44-inch roll: S041220	—
	36-inch roll: S041221	
	24-inch roll: S041295	
Glossy Paper Heavyweight	44-inch roll: S041226	—
	36-inch roll: S041227	
	24-inch roll: S041291	
Semigloss Paper Heavyweight	44-inch roll: S041228	—
	36-inch roll: S041229	
	24-inch roll: S041292	
Photo Glossy Paper	44-inch roll: SP91002	—
	36-inch roll: SP91001	
	24-inch roll: SP91021	
Photo Semigloss Paper	44-inch roll: SP91004	—
	36-inch roll: SP91003	
	24-inch roll: SP91022	
Premium Glossy Photo Paper	13-inch roll: S041378	11 × 17" (B): S041290
	8.3-inch roll: S041376	11.7 × 16.5" (A3): S041288
		13 × 19" (SB): S041289
Premium Semigloss Photo Paper	—	Letter: S041331 13 × 19" (SB): S041327
Backlight Film	44-inch roll: S041484	11.7 × 16.5" (A3): S041131
	36-inch roll: S041483	16.5 × 23.4" (A2): S041130
	24-inch roll: S041482	
Photo Quality Glossy Film	—	Letter: S041072
		8.3 × 11.7" (A4): S041071
		11 × 17" (B): S041075
		13 × 19" (SB): S041074
Posterboard Semigloss	—	20.25 × 28.75": S041237 28 × 40": S041236

Stylus Pro 10000 Photographic Dye Ink model media product codes (cont.)

Paper type	Roll sizes	Sheet sizes
Premium Luster Photo Paper*	44-inch roll: S041463 36-inch roll: S041462 24-inch roll: S041461 13-inch roll: S041409 8.3-inch roll: S041408	Letter: S041405 11.7 × 16.5" (A3): S041406 13 × 19" (SB): S041407
Doubleweight Matte Paper	44-inch roll: S041387 36-inch roll: S041386 24-inch roll: S041385	—
Matte Paper-Heavyweight	—	Letter: S041257 11.7 × 16.5" (A3): S041260 13 × 19" (SB): S041263
Photo Paper	13-inch roll: S041233	Letter: S041141, S041271, S041272 8.3 × 11.7" (A4) S041140 11.7 × 16.5" (A3): S041142 11 × 17" (B): S041156 13 × 19" (SB): S041143 8.3 × 23.4" (Panoramic): S041145
Photo Quality Ink Jet Paper	—	11 × 17" (B): S041070 13 × 19" (SB): S041069 16.5 × 23.4" (A2): S041079 17 × 22" (C): S041171 16.5" × 49.21" (Banner): S041102
360 dpi paper	—	13 × 19" (SB): S041066

* Requires optional 3-inch high tension spindle

2-4 | Handling Paper and Other Media



Check the EPSON Pro Graphics web site (<http://prographics.epson.com>) or your authorized EPSON dealer for new papers and other media that may be available.

Stylus Pro 10000 Archival Ink model media product codes

Paper type	Roll sizes	Sheet sizes
Doubleweight Matte Paper	44-inch roll: S041387 36-inch roll: S041386 24-inch roll: S041385	—
Glossy Paper Photo Weight	44-inch roll: S041389 22-inch roll: S041388	13 × 19" (SB): S041456
Smooth Fine Art Paper*	44-inch roll: S041433 36-inch roll: S041432 24-inch roll: S041431	24 × 30": S041434 36 × 44": S041435
Backlight Film	44-inch roll: S041484 36-inch roll: S041483 24-inch roll: S041482	—
Synthetic Paper**	44-inch roll: S041401 36-inch roll: S041400 24-inch roll: S041399	—
Adhesive Synthetic Paper	44-inch roll: S041404 36-inch roll: S041403 24-inch roll: S041402	—
Photo Glossy Paper	44-inch roll: SP91002 36-inch roll: SP91001 24-inch roll: SP91021	—
Photo Semigloss Paper	44-inch roll: SP91004 36-inch roll: SP91003 24-inch roll: SP91022	—
Premium Glossy Photo Paper*	13-inch roll: S041378 8.3-inch roll: S041376	Letter: S041286 11.7 × 16.5" (A3): S041288 13 × 19" (SB): S041289 11 × 17" (B): S041290
Premium Semigloss Photo Paper	—	Letter: S041331 13 × 19" (SB): S041327
Adhesive Vinyl	44-inch roll: S041438 36-inch roll: S041437 24-inch roll: S041436	—
Canvas	44-inch roll: S041533 36-inch roll: S041532 24-inch roll: S041531	—

Stylus Pro 10000 Archival Ink model media product codes (cont.)

Paper type	Roll sizes	Sheet sizes
Premium Luster Photo Paper*	44-inch roll: S041463 36-inch roll: S041462 24-inch roll: S041461 13-inch roll: S041409 8.3-inch roll: S041408	Letter: S041405 11.7 × 16.5" (A3): S041406 13 × 19" (SB): S041407
Posterboard for Archival Ink	—	***
Textured Fine Art Paper*	44-inch roll: S041449 36-inch roll: S041448 24-inch roll: S041447	24 × 30": S041450 36 × 44": S041451
Tyvek® Brillion™	44-inch roll: S041496 36-inch roll: S041495 24-inch roll: S041494	—
Scrim Vinyl	***	—
Archival Matte	***	Letter: S041341 11.7 × 16.5" (A3): S041343 13 × 19" (SB): S041339
Watercolor Paper-Radiant White	—	13 × 19" (SB): S041351

* Requires optional 3-inch high tension spindle

** Requires optional 2-inch high tension spindle

*** Not available at time of printing. For product codes and availability, visit the EPSON Pro Graphics web site at <http://prographics.epson.com>.

Printing Tips for EPSON Media

Follow these tips for using and storing printing materials:

- Avoid touching the printable surface of the paper or other media with bare hands. Fingerprints may affect print quality. Handle media by the edges or use cotton gloves.
- Always choose the correct Media Type setting in your printer software before you send your job. See page 3-7 (Macintosh) or page 4-4 (Windows) for instructions.
- Always select the correct paper source (roll or sheet) in both the printer software and on the printer's control panel. See page 3-2 (Macintosh) or page 4-6 (Windows) for instructions on selecting the paper source in your printer software.
- Keep unused media in its original packaging and store it in a cool, dry place to avoid a decline in quality. Avoid storing media or printouts where they will be exposed to high temperature, humidity, or direct sunlight.



You can purchase roll paper spindles and other accessories or options from the EPSON Pro Graphics web site (<http://prographics.epson.com>) or your authorized EPSON dealer.

Using Roll Paper

The printer comes with two 2-inch spindles, so you can have two types or sizes of roll paper available for printing. You can use any roll paper with a 2-inch core, up to 44 inches wide. With the optional high-tension 3-inch spindle, you can also use roll paper that has a 3-inch core (one roll at a time). Manually switching from one paper roll to another is a simple process.

For instructions on attaching roll paper to a spindle and loading it in the printer, see page 1-4 through 1-9. This section covers the following:

- Guidelines for using roll paper
- Using the roll paper belts
- Removing paper from the spindle
- Cutting paper manually with the built-in cutter
- Printing trim lines


Guidelines for Using Roll Paper

Follow these guidelines when you print on roll paper:


- When both spindles have roll paper on them, wrap one of the roll paper belts around the roll you're not using. This keeps the paper out of the way.
- To avoid feeding excess paper, make sure the **Sheet** light on the control panel is off. Press the **Paper Source** button until one of the **Roll** lights comes on.
- Choose **Roll Auto Cut** if you want the paper to be cut automatically after each page is printed.
- Choose **Roll Cutter Off** if you're printing on canvas, vinyl, or other heavy media. Media that is too thick may damage the cutter. Also choose this setting if you're using the optional auto take-up reel, or if you want to print a series of pages and keep them together for later cutting.
- To protect it, always store unused roll paper in its original package—including the bag, end caps, and box.
- Avoid touching the printable surface of the paper. Oils from your skin can affect print quality.

Using the Roll Paper Belts

To keep the paper wound when you're not printing, use one of the roll paper belts included with your printer.



When you're not using the roll paper belt, keep it wound around the end of the spindle.



Removing Paper from the Spindle

If you need to remove the paper roll from the spindle, follow these steps:

1. Open the roll paper cover and lift out the roll and spindle. Lift out the left end of the spindle and roll first, and then the right end.


If the paper is loaded for printing, pull the paper set lever out to the released position, then roll up the paper before you remove the spindle.

2. Lay the roll down on a flat surface.
3. Loosen the movable paper stop by tapping it with your hand.
4. Slide the paper stop off the end of the spindle.
5. Remove the roll from the spindle.



To avoid damaging the printer, never move the paper set lever while the **Operate** or **Pause** light is flashing.

To avoid damaging the spindle, do not tap the end of the spindle on the floor.





For information on how to attach and use the optional utility cutter, see the documentation that came with the cutter.

See page 2 for details on ordering the manual media cutting system.

Cutting Paper Manually with the Built-in Cutter

When you're not using the Auto Cut setting, you need to cut the paper manually after your print job is finished. If you're printing on canvas, vinyl, or other heavy media, you should use scissors or the optional utility cutter rather than the built-in cutter. Heavy media can damage the built-in cutter.

Follow these steps to cut manually with the built-in cutter:

1. If the paper is not positioned correctly, press one of the **Paper Feed** buttons to adjust the paper position. Normally, you don't need to do this after a print job is finished.
2. Press the **Paper Source** button until the **Roll Auto Cut** light comes on.
3. Press the **Cut/Eject** button. The paper is cut.

Printing Trim Lines

You can have trim lines printed on the right edge of your images or pages (if you're using Auto Cut) or on the right and bottom edge (if you're not using Auto Cut). Follow these steps:

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.
2. Press the **Item** button until **PAGE LINE=OFF** appears on the display.
3. Press the **+** button. **PAGE LINE=ON** appears on the display.
4. Press the **Enter** button to save the new setting.
5. Press the **SelecType** button to exit the Printer Setting menu.

If you're using the EPSON printer driver, you can also specify trim lines through your print options. See page 3-3 (Macintosh) or page 4-7 (Windows) for more information.

Using Cut Sheet Paper

You can print on many types of cut sheet paper and other media. The printer accepts sheets ranging from letter-size (8.5 × 11 inches) to 44 × 62.2 inches. You can leave your roll paper in the printer when you print on cut sheets; make sure it is rolled up and fastened with the roll paper belt(s), as described on page 2-7.


If you're using stock more than 19 mil (0.5 mm) thick, see page 2-11 for instructions. You will not be able to follow the “autoload” procedure described in this section.

Before you start, make sure the printer is on and roll paper is not loaded for printing. Then follow these steps:

1. Make sure the roll paper cover is closed.
2. Press the **Paper Source** button until the **Sheet** light comes on.
3. Make sure the paper set lever is pushed all the way in, in the secured position.
4. Feed the sheet into the paper slot until it meets resistance. Make sure the right edge of the paper is straight and aligned with the scale on the roll paper cover. **PRESS PAUSE BUTTON** appears on the control panel display.



To avoid damaging the printer, never move the paper set lever while the **Operate** or **Pause** light is flashing.



5. Press the **Pause** button. The print head moves and the sheet feeds into printing position automatically. **READY** appears on the control panel display. (Even if you don't press **Pause**, the paper and printer will move into printing position automatically after 10 seconds.)
6. Print your page. After it is finished, the sheet stays in the printer.
7. To remove your print, hold it while pressing the **Paper Feed (-)** button.

Printing on Posterboard

You can print on heavy stock up to 28 × 40 inches (B1), such as EPSON Posterboard Semigloss. Follow these instructions when you print on posterboard or other media more than 19 mil (0.5 mm) thick.



Note


You can't run a cleaning cycle when posterboard is loaded for printing.

1. Set the paper hammock to catch your printouts in front of the printer. See page 2-14 for instructions.
2. Make sure that no other paper is loaded in the printer. If you have inserted roll paper on a roll paper spindle(s), wind the roll paper belt(s) around the end of the spindle to keep the roll paper in place.
3. Press the **Paper Source** button until the **Sheet** light comes on.
4. Pull the paper set lever out, to the released position. Then open the lower cover.



Caution

To avoid damaging the printer, never move the paper set lever while the **Operate** or **Pause** light is flashing.




2-12 | Handling Paper and Other Media




If you're using stock more than 39 inches long, load it long edge first (in landscape orientation).

5. Feed the posterboard into the paper slot until the bottom edge of the board rests behind the open lower cover.
6. Align the board with the scale on the roll paper cover.




7. Align the board with the vertical row of holes at the paper exit.





To avoid damaging the printer, never move the paper set lever while the **Operate** or **Pause** light is flashing.

8. Push the paper set lever all the way in, then close the lower cover. **PRESS PAUSE BUTTON** appears on the control panel display.



9. Press the **Pause** button. The print head moves and the board feeds into printing position automatically. **READY** appears on the control panel. (Even if you don't press **Pause**, the board and printer will move into printing position automatically after 10 seconds.)
10. Run your print job. After it is finished, the posterboard stays in the printer.
11. To remove the print, hold it and pull the paper set lever all the way out.

Adjusting the Platen Gap for Heavy Stock

When you print on heavy stock, you may need to adjust the platen gap setting. Normally, the **AUTO** setting allows the printer to adjust automatically. However, if print quality is not satisfactory when you use heavy stock, change this setting to **WIDE**. Follow these steps:

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.
2. Press the **Item** button. **PLATEN GAP=AUTO** appears on the display.
3. Press the **+** button. **PLATEN GAP=WIDE** appears on the display.

4. Press the **Enter** button to save the new setting.
5. Press the **SelecType** button to exit the Printer Setting menu.

The letter **W** appears on the right side of the control panel display to remind you of the wide setting. When you switch media, don't forget to change this setting back to **AUTO**.

Using the Paper Hammock




When you print on posterboard, set the hammock to catch printouts in front of the printer.

The paper hammock (also called the paper basket) is a cloth sheet that attaches to your printer and catches your printouts as they come out. This keeps the printouts from getting dirty or wrinkled. You can set up the hammock either to catch the paper under the printer or let it feed straight out in front of the printer.

Catching Printouts in Front of the Printer

Follow these steps to set up the hammock in front of the printer:


1. Unhook the hammock rings from the upper hammock hooks.






Make sure the surface of the hammock is stretched tight. If there is any slack, the paper may not slide properly to the floor.

2. Slide the upper hammock guides all the way in. Then fully extend the lower hammock guides, so that they rest on the floor.




3. Locate the rear side hammock rings. Bring the rings up in back of the rod and hook them on the upper hammock hooks.




Catching Printouts Under the Printer

Follow these steps to set up the hammock under the printer:

1. Unhook the hammock rings from the upper hammock hooks.




2. Extend the upper hammock guides all the way out. Then extend the lower hammock guides out to their full length.




Catching Printouts Shorter Than 40 Inches

If you're printing on sheets shorter than 40 inches, you can set up your hammock so that it takes up less space. Follow these steps:

1. Slide the lower hammock guides all the way in, and extend the upper hammock guides out to their full length.



2. Hook the hammock rings on the upper hammock hooks to take up any slack.



5. Examine the printed pattern to determine which set of lines is the straightest (shows the smallest gap), and note the corresponding number.

In the sample pattern, the lines under number 4 are the straightest.

6. Press the + or – button to select the number noted in step 5. Then press **Enter**.
7. Press the **Item** button. **DRYING TIME=0 MIN** appears on the display. Press the + or – button to select the time in minutes, then press **Enter**. Start with one minute. If ink still smears, increase the drying time.

This is how long the print head will pause between pages (or before cutting) to let the ink dry.
8. Press the **Item** button. **SUCTION=NORM*** appears on the display. If you're registering very thin paper, press the + or – button to select the **LOW** setting. Then press **Enter**.
9. Press the **Pause** or **SelecType** button to exit the Paper Configuration menu.

Selecting Registered Paper Settings

Once you have registered the drying time (and thickness) for a type of paper or other media, you can select it whenever you print on that paper.

1. Press the **SelecType** button until **PAPER CONFIG. MENU** appears on the display.
2. Press the **Item** button. You see **PAPER NUMBER=1**.
3. Press the + or – button to select the registered number you want to use, or select the standard setting, **STD**. Then press the **Enter** button.
4. Press the **Pause** or **SelecType** button to exit the Paper Configuration menu.

When you change media, make sure you select the correct setting or change it back to **STD**.

Chapter 3: Printing with EPSON Drivers for Macintosh

Your EPSON Stylus Pro 10000 comes with drivers and utilities that let you print and manage print jobs in non-PostScript mode without a RIP. ICC profiles for ColorSync® 3.x are included, so you can use advanced color management features from your applications or the driver itself.

The driver CD-ROM also includes an electronic *Reference Guide* to your printer and EPSON printer software. You can read the guide using a web browser, such as Netscape Navigator or Microsoft Internet Explorer, versions 3.0 or later.

This chapter includes the following information:

- Choosing page setup options
- Choosing basic print options
- Choosing advanced print options
- Managing print jobs
- Checking printer status



Note

Many application settings override the printer's page setup options. Always verify settings to get the results you expect.


If you need more information about print options, click the ? on any dialog box.

Creating a custom paper size lets you make the best use of roll paper. You can also use the customize dialog box to change the margins on your paper.

Choosing Page Setup Options

Many of the page setup options correspond to paper handling features that you can also set through the control panel. Software options give you additional settings and override control panel settings. Follow these steps to choose page setup options:

1. Start an application, open a file, and choose **Page Setup** from your application's File menu. You see the page setup dialog box:



2. For **Paper Size**, determine the size of your image. Then select the paper size you want. If you prefer a custom paper size, click **Customize** and enter the size in hundredths of an inch (or centimeters).



Don't select **Landscape** unless you want to rotate your image 90°.



These settings override settings made through the control panel.

3. Select the type of paper you loaded in the printer from the **Paper Source** list.

If your image is more than 62 inches long, select **Roll Paper (Banner)**. You can also use this setting to print a series of continuous images without any “margin space” between them.

4. If you're using roll paper, you can set the following options:
 - **Auto Rotate**
Saves paper if your document length is shorter than the printable width of the paper roll. Your image will be turned automatically by 90 degrees and printed crosswise.
 - **Auto Cut**
Choose this option if you want the paper to be cut automatically after each page is printed.
 - **Print Page Line**
Prints trim lines on the right and bottom edges of your pages.
 - **Save Roll Paper**
Saves paper by not feeding the blank portion of the last page of your document. Applicable in **Roll Paper (Banner)** mode only.
5. Make the settings you want for **Orientation**, **Reduce or Enlarge**, and **Printable Area** (available when **Paper Source** is set to **Sheet**).
6. After making your settings, click **OK**.


Choosing Basic Print Options

Once you have selected your page setup options, you need to select printing options. The EPSON driver offers automatic settings that optimize print quality and speed when you're using EPSON media. You can also choose advanced settings for more control over your printer and color management options, as described on page 3-9.

Follow these steps to make basic settings for automatic printer adjustments:

1. Choose **Print** from the File menu of your application. A dialog box like the following appears:

This area shows the current settings, but you can't change them from here.



2. Choose the number of **Copies** and indicate which **Pages** you want to print.
3. Select a **Media Type** setting appropriate for the media you're printing on, as listed in the table on page 3-7 (Photographic Dye Ink model) or 3-8 (Archival Ink model).
4. Select **Color** or **Black** ink.
5. Make sure **Photo Printing Accelerator** is selected. This option speeds up transmission of data from your Macintosh to the printer.



Do not turn off **Photo Printing Accelerator** unless you see poor image quality and want to test whether this setting has an effect.

6. Set the **Mode** option as follows:

- Click **Automatic** to have the printer driver analyze the contents of your image or file and make the appropriate printing adjustments. If a **Quality/Speed** slider appears in the Mode box, set it according to the priorities of your print job. (Depending on the Media Type setting, this slider may not appear.) Then choose from the color control modes listed below.

Color control modes

Setting	Usage
Photo-realistic	Produces sharper images and more vivid colors by automatically adjusting the contrast, saturation, and brightness. Corrects for overall under- or over-exposure of the original image.
Vivid	Intensifies colors and lightens the midtones and highlights. Best for print jobs with non-photographic images.

- Click **Custom** and then choose one of the print job types from the custom settings list, as described below.

Custom print job settings

Setting	Usage
Advanced Photo	Prevents the misprinting of ink dots that may occur because of the movement of the print head and paper. Available only when you choose photo or photo-quality media types.
Text/Graph	Intensifies colors and lightens the midtones and highlights. Best for print jobs with non-photographic images.
ColorSync	Adjusts colors based on your printer's ICC profile, using the perceptual rendering intent.



Note

You can also create your own settings and add them to this list. See page 3-11 for more information.

7. Choose from the following buttons to access additional features:
 - Click  to access the printer monitoring and maintenance utilities. See page 3-17 for more information about the Status Monitor utility. See Chapter 6 for details about the maintenance utilities.
 - Click  if you want to reduce your image to fit on the page.
 - Click  to turn on background printing. This lets you work on your Macintosh while you're printing and use the Monitor3 utility. See page 3-13 for more information.
 - Click  and then click the **Preview** button to preview your print.
 - Click  to check your ink levels.
8. When you're finished choosing print options, click **Print**.

Selecting the Correct Media Type



Check the EPSON web site (<http://prographics.epson.com>) or your authorized EPSON dealer for new papers and other media that may be available. Some media may not be available in your location.

The table below lists the settings designed to produce the best results on EPSON media when you print on an EPSON Stylus Pro 10000 Photographic Dye Ink model. If you are using paper or other media not listed in the table below, check the instructions included with the paper. If you are using non-EPSON media, choose the closest setting. You may have to experiment with different settings to determine which one is best for the media you're using.

Media Type settings for the Stylus Pro 10000 Photographic Dye Ink model

Product name	Media Type setting
Presentation Matte Paper	1440 dpi printing: Photo Quality Ink Jet Paper Lower resolution printing: Presentation Matte Paper
Doubleweight Matte Paper	Presentation Matte Paper
Matte Paper-Heavyweight	Presentation Matte Paper
Photo Glossy Paper	Photo Glossy Paper
Photo Semigloss Paper	Photo Semigloss Paper
Premium Luster Photo Paper	Premium Luster Photo Paper
Glossy Paper Heavyweight	Photo Paper
Semigloss Paper Heavyweight	Semigloss Photo Paper
Posterboard Semigloss	Semigloss Photo Paper
Premium Glossy Photo Paper	Premium Luster Photo Paper
Premium Semigloss Photo Paper	Premium Luster Photo Paper
Photo Quality Glossy Film	Glossy Film
360 dpi paper	Photo Quality Ink Jet Paper
Photo Quality Ink Jet Paper	Photo Quality Ink Jet Paper
Photo Paper	Photo Paper



If the paper or other material you're using is not listed in the tables, check the instructions included with the paper. If you're using a non-EPSON printing material, choose the closest setting. You may have to experiment to determine which setting is best for the media you're using.

The table below lists the settings to use with the Stylus Pro 10000 Archival Ink model. In addition to settings for specific EPSON media, the driver includes five media types designed for the user who needs higher color density:

- **Media-1, Media-2, and Media-3** allow you to use higher ink duty when printing on outdoor media. The results are a richer, brighter color gamut for your prints. Each of these media types is optimized for use with certain EPSON media.
- **High-Duty Media-1 and High Duty Media-2** let you print with higher ink duty on indoor media. Compared to other media types, **High-Duty Media-1** increases the ink duty by 25%, and **High Duty Media-2** increases the duty by 50%. You may have to experiment to test the effects on different media.



Check the EPSON web site (<http://prographics.epson.com>) or your authorized EPSON dealer for new papers and other media that may be available.



If the paper or other material you're using is not listed in the tables, check the instructions included with the paper. If you're using a non-EPSON printing material, choose the closest setting. You may have to experiment to determine which setting is best for the media you're using.

Media Type settings for the Stylus Pro 10000 Archival Ink model

Paper type	Media Type setting
Doubleweight Matte Paper	Doubleweight Matte Paper
Glossy Paper Photo Weight	Glossy Paper - Photo Weight
Premium Glossy Photo Paper	Premium Glossy Photo Paper
Premium Semigloss Photo Paper	Premium Semigloss Photo Paper
Photo Glossy Paper	Photo Glossy Paper
Photo Semigloss Paper	Photo Semigloss Paper
Premium Luster Photo Paper	Premium Luster Photo Paper
Watercolor Paper - Radiant White	Watercolor Paper - Radiant White
Smooth Fine Art Paper	Smooth Fine Art Paper
Textured Fine Art Paper	Textured Fine Art Paper
Synthetic Paper	Synthetic Paper For higher color density: Media-1
Adhesive Synthetic Paper	Adhesive Synthetic Paper For higher color density: Media-2
Adhesive Vinyl	Adhesive Vinyl For higher color density: Media-3
Tyvek® Brillion™	Tyvek Brillion For higher color density: Media-3
Backlight Film	Backlight Film

Media Type settings for the Stylus Pro 10000 Archival Ink model (cont.)


Paper type	Media Type setting
Canvas	Canvas
Archival Matte	Doubleweight Matte Paper
Posterboard for Archival Ink*	Doubleweight Matte Paper
Scrim Vinyl*	Adhesive Vinyl
Various indoor media	High Duty Media-1
Various indoor media	High Duty Media-2

* Not available at time of printing. Check the EPSON Pro Graphics web site at <http://prographics.epson.com> for media availability.

Choosing Advanced Print Options

The advanced print options give you complete control over your printing environment. Use these settings to experiment or to fine-tune a range of options to meet your individual needs. Follow these steps to print with advanced settings:

1. Follow steps 1 through 4 on page 3-4.
2. Click Custom and then click Advanced. You see a dialog box like the following:



These three configurations give you different options on the lower part of the screen.

3. If necessary, you can change your Media Type and Ink settings.

4. Choose one of the following **Print Quality** settings:

- **Economy**
To save ink
- **Normal - 360dpi**
For faster printing and everyday needs
- **Fine - 720dpi**
For high-quality photos and other prints
- **Superfine - 1440dpi**
For highest quality photos and prints

The available print quality settings are limited by the **Media Type** setting. Choose lower print quality for faster printing, or **Superfine - 1440dpi** for best quality.

5. Choose any of the following:

- **MicroWeave and Super MicroWeave**
Eliminate unwanted banding effects. One of these settings is automatically selected for all media types except plain paper.
- **High Speed**
For fast, bidirectional printing at lower quality. If vertical lines in your printout are misaligned when you use the **High Speed** setting, you may need to turn it off or realign the print head.
- **Flip Horizontal**
For printing a mirror image of your file. Use with backlight film.
- **Photo Printing Accelerator**
Enables faster transfer of data from your Macintosh to the printer. This setting takes advantage of special hardware in your printer.



When you print on EPSON backlight film, choose **Vivid mode** and **+10 Saturation**.

6. Choose one of the following Color Management configurations:
 - **Color Controls**
Lets you specify individual values for adjusting brightness, contrast, saturation, and CMY inks, or choose from the three Color Adjustment modes. You can also choose from three Gamma settings, which control image contrast by modifying the midtones and midlevel grays. For descriptions of the available settings, see the table on page 3-12.
 - **PhotoEnhance4**
Lets you see a sample image that reflects the settings you choose. Also allows you to correct noise and other problems common to digital camera images. See page 3-12 for a description of the available settings.
 - **ColorSync**
Lets you select from three Rendering Intent settings for mapping colors to your printer's **Epson Standard** profile, created specifically for the EPSON Stylus Pro 10000. (See page 3-12 for descriptions of the available settings.) You can also use this option to select custom ICC profiles that you have created.
 - **No Color Adjustment**
Disables color management in the printer driver. Choose this mode if you want to use a standalone color management mode.
7. Click **Save Settings** if you want to have your advanced settings available for reuse. Then type a name for the group of settings and click **Save**. The name is added to your list of custom settings.
8. When you're finished setting advanced printer options, click **OK**.

Color Management Settings

Notice: Output Viewing Conditions

Due to the nature of all pigment inks, lighting conditions can affect the appearance of printer output. For example, a print viewed under daylight may appear to have a slightly different color balance when viewed under tungsten lighting. Care should be taken that the prints are produced for the lighting conditions in which they will be displayed.

The EPSON printer driver was designed to represent color accurately when prints are illuminated with a D50 (daylight) light source. For optimum results, understand your output display conditions before printing.

The following tables list the color management settings available when you choose either Color Controls, PhotoEnhance4, or ColorSync.

PhotoEnhance4 is designed to enhance images captured using video cameras, digital cameras, or scanners. Depending on your system and the size of the image, printing with PhotoEnhance4 may take longer.

Color control modes and Gamma settings

Automatic	Analyzes the color information in your image and optimizes color correction accordingly.
Photo-realistic	Produces sharper images and more vivid colors by automatically adjusting the contrast, saturation, and brightness. Corrects for overall under- or over-exposure of the original image.
Vivid	Intensifies colors and lightens the midtones and highlights. Best for print jobs with non-photographic images.
1.5 Gamma	Produces the same contrast values as earlier EPSON ink jet printers.
1.8 Gamma	Increases contrast.
2.2 Gamma	Matches image colors with sRGB devices.

PhotoEnhance4 settings

Tone	Lets you choose from Normal for standard tone correction, Hard for high contrast, Vivid for more intense colors (as defined above), Sepia , and Monochrome .
Effect	Lets you choose from four special effects (and set the intensity using the Low/High slider): Sharpness , Soft Focus , Canvas , and Parchment .
Digital Camera Correction	Corrects noise and other flaws common to digital camera images.

ColorSync Rendering Intent settings

Perceptual	For photographic images. Maintains the relationship between colors as it scales them to fit within your printer's color gamut.
Saturation	For charts and business graphics. Maintains the relative saturation of colors from one gamut to another.
Colorimetric	For projects with known colors, such as labels and packaging. Maintains colors that fall within the gamut of both your monitor and printer.


Managing Print Jobs

Your printer comes with several utilities that let you check on your print jobs and schedule, cancel, pause, or restart them. First you need to set up background printing, so you can continue to work on your Macintosh while a file is being printed. Note that background printing is slower and may also slow down your system.

Setting Up Background Printing

You can set up background printing from the Chooser, as described on page 1-14, or you can use the background printing button on the print dialog box. Follow these steps to set up background printing:

1. Start an application, open a file, and choose **Print** from the File menu.
2. Click the background printing button . You see the following dialog box:



3. To turn background printing on, click the **On** button.

4. To select a priority for your print job in the queue of jobs waiting to print, click one of the following:
 - Urgent to print before any Normal priority job
 - Normal to print in the order the job is received
 - Print at: to print at the specific time you enter in the day and time in the fields to the right
 - Hold to hold the print job in the print queue until you're ready to release it using Monitor3; see the following section for details.
5. Click OK to save your settings and return to the printer settings dialog box.
6. Click Print to print your document.

If you selected **Print at:** or **Hold**, your document is spooled, but held in the print queue until the print time specified or until released using Monitor3, as described in the following section.

Using Monitor3

The Monitor3 utility lets you prioritize and control your print jobs as well as monitor their progress.



You must turn on background printing to view the EPSON Monitor3 window. See page 3-13 for instructions.

After you send a print job, click the current application icon at the right end of the menu bar and select **EPSON Monitor3**. You see a window like the following:

Document Name	Priority	Paper Size	Media Type	Copies
SS13004.JPG	Hold	US C 17 ...	Photo GL...	1

Current print job

Jobs waiting to print

Click to set priorities or print times for waiting print jobs.

The progress bar tracks the current print job. To cancel, pause, or restart a print job, click the document's name, then click one of the following buttons:

- Click  to delete
- Click  to restart
- Click  to pause


You can also do the following:

- Double-click a file in the list to preview it
- Double-click **Copies** to change the number of copies to be printed
- Click  to check your ink levels
- Click  to start the print head cleaning utility. See page 6-1 for more information about the cleaning utility.

If you want to view details of a print job, click the job, then click the **Show Details** arrow. The **Priority** list becomes active.



If you see a stop sign icon and the message **Print queue on hold** in the EPSON Monitor3 dialog box, select **Start print queue** from the Printer menu to release the queue and resume printing.



Priority list box

Settings selected for the highlighted print job

Click the print job whose priority you want to change. Then click the **Priority** list box and select one of the following settings:

- **Normal** prints the job in the order it is received
- **Urgent** moves the job before Normal priority jobs in the print queue
- **Hold** holds the job in the print queue until you're ready to release it for printing by clicking  restart
- **Print Time** opens the Set Print Time dialog box. Enter the date and time you want to print the document, then click **OK**.



Cancelling Printing

If you need to cancel a print job, follow these steps:

1. Press the **Power** button to turn off the printer.
2. Do one of the following, depending on whether you're using background printing:
 - If background printing is turned off, hold down the **⌘** key on your keyboard and press the (.) period key to cancel the print job.
 - If background printing is turned on, select **EPSON Monitor3** from the application menu and click **Stop Print Queue**. Or, click the  button, then click the stop button  to cancel the print job.


Checking Printer Status

The Status Monitor utility lets you check the levels of ink in your printer and configure error messages and other features of printer operation.


Follow these steps to check ink levels:

1. Click the utility button  on the print or page setup dialog box. You see the utility menu:

Click to open the Status Monitor utility.



2. Click the **EPSON StatusMonitor** icon. The software checks the amount of ink remaining in the printer and displays the Status Monitor window:



Click to recheck ink levels.


3. To recheck the ink level check, click the **Update** button. To close the Status Monitor, click **OK**.

Selecting Configuration Options

You can configure the way you want the printer to handle error and warning messages, ink level checks, and print file handling in the Configuration Settings dialog box. Follow these steps:

1. Click the utility button  on the print or page setup dialog box. You see the utility menu.
2. Click the **Configuration** button.

You see the Configuration Settings dialog box:



Click here to return to the default settings.

3. Select from the following configuration options:



Note

Warning messages allow printing to continue. Error messages are more serious and cause printing to stop.

- **Error notification** lets you choose whether you want your system to beep and display error message text or just display text if your printer encounters an error.
- **Warning** lets you choose whether warning messages beep and display text or display text only.
- **Temporary Spool folder** and **Temporary High Speed Copies folder** let you select the folders on your hard disk that store the temporary files created when you send a job to the printer. Click the **Select** button to change the folder from the default folder shown.

- Data will be sent to the printer after being stored on your disk prevents print head pausing. Normally, graphics are sent in rectangular bands. When you select this option, your Macintosh stores the entire image on its hard drive and then sends it to the printer as a whole (recommended only for older Macintosh systems).
 - The last two checkboxes let you choose to have your software check for errors or low ink levels before starting your print job.
4. When you're finishing changing your configuration options, click OK to return to the utility menu.

Chapter 4: Printing with EPSON Drivers for Windows

Your EPSON Stylus Pro 10000 comes with drivers and utilities that let you print and manage print jobs without a RIP. ICC profiles are included, so you can use advanced color management features of your applications or the driver itself.

The driver CD-ROM also includes an electronic *Reference Guide*, which includes more detailed information about the printer and printer software. You can read the guide using a web browser, such as Netscape Navigator or Microsoft Internet Explorer, versions 3.0 or later.

This chapter includes the following information:

- Choosing basic print options
- Choosing paper and layout options
- Choosing advanced print options
- Managing print jobs
- Checking printer status
- Optimizing print speed

Choosing Basic Print Options

Before you print, you need to set basic printing properties. The EPSON driver offers automatic settings that optimize print quality and speed when you're using EPSON media. You can also choose advanced settings for more control over your printer and color management options, as described on page 4-7.

Follow these steps to make basic settings:


1. Start an application, open a file, and choose **Print** from the File menu. You see the Print dialog box.
2. Make sure your printer is selected, and then click the **Properties** button. (If you see a **Setup**, **Printer**, or **Options** button, click it instead. Then click **Properties** on the next dialog box.)

A dialog box like the following appears:



If you need more information about print options, you can click the **Help** button on any dialog box.

This box shows you the current settings, but you can't change them from here.



3. Select a **Media Type** setting appropriate for the media you're printing on, as listed in the table on page 4-4 (Photographic Dye Ink model) or 4-5 (Archival Ink model).
4. Select **Color** or **Black** ink.
5. Set the **Mode** option as follows:
 - Click **Automatic** to have the printer driver analyze the contents of your image or file and make the appropriate printing adjustments. If a **Quality/Speed** slider appears in the Mode box, set it according to the priorities of your print job. (Depending on the Media Type setting, this slider may not appear.)
 - Click **Custom**, and then choose one of the print job types from the custom settings list, as described in the table below.



You can also create your own settings and add them to this list. See page 4-9 for more information.

Custom print job settings

Setting	Usage
Text/Graph	Intensifies colors and lightens the midtones and highlights. Best for print jobs with non-photographic images.
ICM	Adjusts colors based on your printer's ICC profile, using the Image Color Matching system (effective in Windows 98/Me/2000 only). If you're using an ICM-compatible monitor, adjusts printed colors to closely match screen colors.
sRGB	Adjusts colors using the small-gamut sRGB (standard red green blue) color space. Best for color matching with other sRGB devices, or for images designed for the Web.



Do not turn off **Photo Printing Accelerator** unless you see poor image quality and want to test whether this setting has an effect.

6. Select one of the following from the pull-down menu:
 - **Photo-realistic** if you are printing photographic images. This setting produces sharper images and automatically corrects under- or over-exposure of the original image.
 - **Vivid** if you are printing non-photographic images. This setting intensifies colors and lightens the midtones and highlights.
7. For faster printing, make sure the **Photo Printing Accelerator** checkbox is selected. This setting speeds up data transfer between your computer and the printer.
8. When you're finished choosing print options, click the **Paper** tab and follow the instructions on page 4-6 for choosing paper and layout options.

Selecting the Correct Media Type

The table below lists the settings designed to produce the best results on EPSON media when you print on an EPSON Stylus Pro 10000 Photographic Dye Ink model. If you are using paper or other media not listed in the table below, check the instructions included with the paper. If you are using non-EPSON media, choose the closest setting. You may have to experiment with different settings to determine which one is best for the media you're using.

Media Type settings for the Stylus Pro 10000 Photographic Dye Ink model



Check the EPSON web site (<http://prographics.epson.com>) or your authorized EPSON dealer for new papers and other media that may be available.

Product name	Media Type setting
Presentation Matte Paper	1440 dpi printing: Photo Quality Ink Jet Paper Lower resolution printing: Presentation Matte Paper
Doubleweight Matte Paper	Presentation Matte Paper
Matte Paper-Heavyweight	Presentation Matte Paper
Photo Glossy Paper	Photo Glossy Paper
Photo Semigloss Paper	Photo Semigloss Paper
Premium Luster Photo Paper	Premium Luster Photo Paper
Glossy Paper Heavyweight	Photo Paper
Semigloss Paper Heavyweight	Semigloss Photo Paper
Posterboard Semigloss	Semigloss Photo Paper
Premium Glossy Photo Paper	Premium Luster Photo Paper
Premium Semigloss Photo Paper	Premium Luster Photo Paper
Photo Quality Glossy Film	Glossy Film
360 dpi paper	Photo Quality Ink Jet Paper
Photo Quality Ink Jet Paper	Photo Quality Ink Jet Paper
Photo Paper	Photo Paper



Check the EPSON web site (<http://prographics.epson.com>) or your authorized EPSON dealer for new papers and other media that may be available.

The table below lists the settings to use with the Stylus Pro 10000 Archival Ink model. In addition to settings for specific EPSON media, the driver includes five media types designed for the user who needs higher color density:

- **Media-1, Media-2, and Media-3** allow you to use higher ink duty when printing on outdoor media. The results are a richer, brighter color gamut for your prints. Each of these media types is optimized for use with certain EPSON media.
- **High-Duty Media-1 and High Duty Media-2** let you print with higher ink duty on indoor media. Compared to other media types, **High-Duty Media-1** increases the ink duty by 25%, and **High Duty Media-2** increases the duty by 50%. You may have to experiment to test the effects on different media.

Media Type settings for the Stylus Pro 10000 Archival Ink model

Paper type	Media Type setting
Doubleweight Matte Paper	Doubleweight Matte Paper
Glossy Paper Photo Weight	Glossy Paper - Photo Weight
Premium Glossy Photo Paper	Premium Glossy Photo Paper
Premium Semigloss Photo Paper	Premium Semigloss Photo Paper
Photo Glossy Paper	Photo Glossy Paper
Photo Semigloss Paper	Photo Semigloss Paper
Premium Luster Photo Paper	Premium Luster Photo Paper
Watercolor Paper - Radiant White	Watercolor Paper - Radiant White
Smooth Fine Art Paper	Smooth Fine Art Paper
Textured Fine Art Paper	Textured Fine Art Paper
Synthetic Paper	Synthetic Paper For higher color density: Media-1
Adhesive Synthetic Paper	Adhesive Synthetic Paper For higher color density: Media-2
Adhesive Vinyl	Adhesive Vinyl For higher color density: Media-3
Tyvek® Brillion™	Tyvek Brillion For higher color density: Media-3
Backlight Film	Backlight Film



If the paper or other material you're using is not listed in the tables, check the instructions included with the media. If you're using a non-EPSON printing material, choose the closest setting. You may have to experiment to determine which setting is best for the media you're using.

Media Type settings for the Stylus Pro 10000 Archival Ink model (cont.)

Paper type	Media Type setting
Canvas	Canvas
Archival Matte	Doubleweight Matte Paper
Posterboard for Archival Ink*	Doubleweight Matte Paper
Scrim Vinyl*	Adhesive Vinyl
Various indoor media	High Duty Media-1
Various indoor media	High Duty Media-2

* Not available at time of printing. Check the EPSON web site for driver updates, product codes, and media availability.




Many application settings override settings in the printer driver. Always verify settings to get the results you expect.

Choosing Paper and Layout Options

Many paper options correspond to paper handling features that you can also set through the control panel. Software options give you additional settings and override control panel settings. Follow these steps to choose paper and layout options:

1. On the Properties dialog box, click the **Paper** tab. You see this window:





Creating a user-defined paper size generally lets you make the best use of your roll paper.

2. Select the type of paper you loaded in the printer from the **Paper Source** list.
3. For **Paper Size**, determine the size of your image. Then select the paper size you want from the Paper Size list. If your size is not listed, select **User Defined**. Then enter the size in hundredths of an inch (or centimeters).
4. When you're using roll paper, set the following options:
 - **Auto Rotate**
Saves paper if your document length is shorter than the printable width of the roll. The document will be turned automatically by 90 degrees and printed crosswise.
 - **Auto Cut**
Choose this option if you want the paper to be cut automatically after each page is printed.
 - **Print Page Line**
Prints trim lines on the right and bottom edges of your pages.
 - **Save Roll Paper**
Saves paper by not feeding the blank portion of the last page of your document. Applicable in Roll Paper (Banner) mode.
5. Make the settings you want for **Orientation**, **Copies**, and **Printable Area**.
6. If you want to reduce or enlarge your image, click the **Layout** tab.
7. Choose the appropriate settings, then click **OK**.




Don't select **Landscape** unless you want to rotate your image 90°.

Choosing Advanced Print Options

The advanced print options give you complete control over your printing environment. Use these settings to experiment or to fine-tune a range of options to meet your individual needs. Follow these steps to print with advanced settings:

1. Follow steps 1 through 4 beginning on page 4-1.
2. Click **Custom** and then click **Advanced**.

You see a dialog box like the following:



When you choose PhotoEnhance4, you see a different set of options on the lower part of the screen.

3. If necessary, you can change your **Media Type** and **Ink** settings.
4. Choose one of the following **Print Quality** settings (these are limited by the **Media Type** setting):
 - **Economy**
To save ink
 - **Normal - 360dpi**
For faster printing and everyday needs
 - **Fine - 720dpi**
For high-quality photos and other prints
 - **Superfine - 1440dpi**
For highest quality photos and prints
5. Choose any of the following:
 - **Super MicroWeave** or **MicroWeave**
Eliminate unwanted banding effects. These settings are automatically selected for all media types except plain paper.
 - **High Speed**
For fast, bidirectional printing at lower quality. If vertical lines in your printout are misaligned when you use the **High Speed** setting, you may need to turn it off or align the print head.

- **Flip Horizontal**
For printing a mirror image of your file. Use with backlight film.
 - **Photo Printing Accelerator**
Enables faster transfer of data from your computer to the printer.
6. Choose one of the following Color Management configurations:
- **Color Controls**
Lets you specify individual values for adjusting brightness, contrast, saturation, and CMY inks, or choose from the two Color Control modes, described in the table on page 4-10. You can also choose from three Gamma settings, which control image contrast by modifying the midtones and midlevel grays.
 - **PhotoEnhance4**
Lets you see a sample image that reflects the photographic tone and special effect settings you choose. Also allows you to correct noise and other problems common to digital camera images. See page 4-10 for a description of the available settings.
 - **No Color Adjustment**
Disables color management in the printer driver. Choose this mode if you want to use a standalone color management module.
 - **sRGB**
Adjusts colors using the small-gamut sRGB (standard red green blue) color space. Best for color matching with other sRGB devices, or for images designed for the Web.
 - **ICM**
Adjusts colors based on the printer's ICC profile, using the Image Color Matching system (Windows 98/Me/2000 only). If you have an ICM-compatible monitor, adjusts printed colors to closely match screen colors.
7. Click **Save Settings** if you want to have your advanced settings available for reuse. Then type a name for the group of settings and click **Save**. The name is added to your list of custom settings.
8. When you're finished setting advanced printer options, click **OK**.

Color Management Settings

Notice: Output Viewing Conditions

Due to the nature of all pigment inks, lighting conditions can affect the appearance of printer output. For example, a print viewed under daylight may appear to have a slightly different color balance when viewed under tungsten lighting. Care should be taken that the prints are produced for the lighting conditions in which they will be displayed.

The EPSON printer driver was designed to represent color accurately when prints are illuminated with a D50 (daylight) light source. For optimum results, understand your output display conditions before printing.

The following tables list the color management settings available when you choose either **Color Controls** or **PhotoEnhance4**.

PhotoEnhance4 is designed to enhance images captured using video cameras, digital cameras, or scanners. Depending on your system and the size of the image, printing with PhotoEnhance4 may take longer.

Color control modes and Gamma settings

Photo-realistic	Produces sharper images and more vivid colors by automatically adjusting the contrast, saturation, and brightness. Corrects for overall under- or over-exposure of the original image.
Vivid	Intensifies colors and lightens the midtones and highlights. Best for print jobs with non-photographic images.
1.5 Gamma	Produces the same contrast values as earlier EPSON ink jet printers.
1.8 Gamma	Increases contrast.
2.2 Gamma	Matches image colors with sRGB devices.

PhotoEnhance4 settings

Tone	Lets you choose from Normal for standard tone correction, Hard for high contrast, Vivid for more intense colors (as defined above), Sepia , Monochrome , and None (no tone adjustment).
Effect	Lets you choose from four special effects (and set the intensity using the Low/High slider): Sharpness , Soft Focus , Canvas , and Parchment .
Digital Camera Correction	Corrects noise and other flaws common to digital camera images.


Managing Print Jobs

Your printer comes with several utilities that let you check on your print jobs and schedule, cancel, pause, or restart them. The Progress Meter opens each time you send a print job. The Spool Manager (not available with Windows NT) appears on the taskbar when you print.

Status Monitor 3, which also appears on the taskbar, also lets you check the printer's status and monitor print jobs. See page 4-12 for more information about Status Monitor 3.

Using the Progress Meter

After you send a print job, the Progress Meter window appears on your screen:



You can use the buttons to cancel, pause, or restart your print job. You also see how much ink you have left and view printing tips.


If you don't want the Progress Meter to appear, you can turn it off. See page 4-14 for instructions.

Using the Spool Manager

The Spool Manager (not available with Windows NT) displays the status of your print job files and lets you control them.

To open the Spool Manager while you're printing, click the EPSON Stylus Pro 10000 or 10000CF icon that appears on the taskbar at the bottom of the screen.

You see the Spool Manager window:




To cancel, pause, resume, or restart a print job, click the job to highlight it; then click the corresponding command button on the bottom of the window.

Using Status Monitor 3

The Status Monitor 3 utility lets you check individual levels of ink in your printer and warns you when errors occur.

You can open Status Monitor 3 either from the Windows Printers utility or from an application.


1. Do one of the following:
 - Click **Start**, point to **Settings**, then select **Printers**. Right-click your printer icon and select **Properties** (Windows 95, 98, or Me), **Document Defaults** (Windows NT), or **Printing Preferences** (Windows 2000)
 - From an application, access the Properties dialog box, as described on page 4-1.
2. Click the **Utility** tab. You see the Utility menu:



Note

If there's a printing problem, such as low ink or jammed paper, Status Monitor 3 displays a **How To** button that you can click for instructions on solving the problem.

3. Click the **EPSON Status Monitor 3** button. The following window appears. (It also opens automatically when an error occurs.)



Setting Monitoring Preferences


You can choose when and how you want to be notified of problems, whether you want a Status Monitor 3 icon to appear on your Windows taskbar, and whether you want to allow monitoring by other users who share the printer. Follow these steps:

1. Click **Start**, point to **Settings**, and click **Printers**. Make sure your printer icon appears in the Printers window.
2. Right-click your printer icon, then click **Properties** (Windows 95, 98, or Me), **Document Defaults** (Windows NT), or **Printing Preferences** (Windows 2000).
3. Click the **Utility** tab, then click the **Speed & Progress** button. You see the Speed & Progress dialog box. (See page 4-16 for more information about using the Speed & Progress utility.)




Note

If you want, you can click the **Show Progress Meter** checkbox to deselect it and disable display of the progress meter during printing.



The screenshot shows the 'Speed & Progress' dialog box. It has a title bar 'Speed & Progress'. Inside, there are two checked checkboxes: 'High Speed Copies' and 'Show Progress Meter'. Below these, there are two radio buttons: 'EPSON Printer Port' (selected) and 'Monitoring Preferences'. A note points to 'Monitoring Preferences' saying 'Not available with Windows NT'. Below the radio buttons, it says 'High speed (DMA) transfer enabled.'. There is a section titled 'High Speed Copy Folder' with a file explorer view showing 'c:\windows\temp' selected. A note points to this section saying 'Appears only if you have more than one hard drive'. At the bottom, there are 'OK', 'Cancel', and 'Help' buttons. A note points to the 'EPSON Printer Port' radio button saying 'Appears only if you are connected to a parallel port'.

- Click the **Monitoring Preferences** button. You see the Monitoring Preferences dialog box:



- Select the Notification options you want to use.
- If you want to have the Status Monitor 3 icon appear in your Windows taskbar, click the **Shortcut Icon** checkbox. Then select the icon you want to use.

After you enable the shortcut, you can simply double-click the icon to open the Status Monitor 3 window (shown on page 4-13) or right-click it to display the Monitoring Preferences dialog box.


- Select **Allow monitoring of shared printers** if your printer is shared and you want to let other users monitor it.
- Click **OK** to save your settings.

Optimizing Print Speed

Using the Speed & Progress utility, you can optimize your printer's parallel port for the fastest data transfer rate and speed up the way your printer driver processes multiple-copy print jobs.

1. Click **Start**, point to **Settings**, then click **Printers**.
2. Right-click the **EPSON Stylus Pro 10000** or **10000CF** printer icon and select **Properties** (Windows 95, 98, or Me), **Document Defaults** (Windows NT) or **Printing Preferences** (Windows 2000).
3. Click the **Utility** tab, then click the **Speed & Progress** button.

You see a dialog box similar to the following:



If you have more than one hard disk drive, you can select a folder for storing multiple copy print jobs here. You don't see this box if you have only one hard disk drive.

4. Select from the following options:
 - **High Speed Copies** speeds up printing of multiple copies of the same document using hard disk space as a cache. If you have multiple hard drives, you can select a high speed copy folder for storing copies.
 - **Show Progress Meter** lets you control whether or not the Progress Meter is displayed when you send a print job.

- **EPSON Printer Port** (Windows 95, 98, or Me only) lets you optimize the transfer rate of your printer port for EPSON printers instead of using the Windows default printer port. You may see one of these messages beneath the **EPSON Printer Port** option:

High speed (DMA) transfer enabled tells you that you're already using fast DMA transfer mode.

For higher data transfer rates, use DMA transfer lets you know that you can speed up printing by enabling DMA transfers on your system. See your electronic *Reference Guide* for instructions on using DMA transfers, if your computer supports them. For more information, see your computer documentation or contact your computer manufacturer's technical support. If you see no message, you cannot enable DMA transfers.

- **Always spool RAW datatype** (Windows 2000 and NT only) lets you spool documents using the RAW format instead of the EMF (metafile) format. Because the RAW format requires fewer resources, printing is faster and you can avoid certain problems, such as insufficient memory or disk space.
5. Click **OK** to close the Speed & Progress dialog box and return to the Utility menu. Then click **OK** again to exit the Printers utility.

Chapter 5: Monitoring and Configuring the Printer



You can also use your printer software utilities to monitor ink levels and alert you to problems. See Chapter 3 (Macintosh) or Chapter 4 (Windows) for more information.


The EPSON Stylus Pro 10000 printer includes a number of monitoring utilities. The control panel displays status messages and error messages, and the lights alert you when a problem occurs or your ink runs out.

In addition, the control panel includes a series of SelecType™ menus that you can use to configure the printer's default settings and perform maintenance operations. This chapter tells you how to respond to the lights and messages and how to configure the printer using the control panel. The following information is included:

- Using the control panel to monitor the printer
- Checking printer status
- Responding to control panel lights and messages
- Using the control panel to configure the printer

Using the Control Panel to Monitor the Printer

The printer's control panel includes buttons, lights, and a liquid crystal display (LCD):



Monitoring Normal Printer Operation

Messages appear on the control panel display and lights come on or flash to indicate various phases of printer operation. The following table explains the status messages and lights:

Status messages

Message	Light	Explanation or response
READY	Operate light on	Printer is ready to print.
PRINTING	Operate light flashing	Printer is receiving data.
INK DRY <number> MIN	Pause light flashing	Printer is paused to let ink dry. Wait for the number of minutes shown.
INK CHARGING <number> %	Pause light on or flashing	Printer is charging ink.
RESET	All lights flash briefly	Printer is resetting.
PRESS PAUSE BUTTON	Pause light on	Press the Pause button to continue.
WAIT	Pause light on or flashing	Printer is warming up, performing maintenance, or charging ink.
PAUSE	Pause light on	Printer is paused. To resume printing, press the Pause button.
NO INK CARTRIDGE		Appears when the ink cartridge is being replaced.
PAT PRINTING	Operate light flashing and Pause light on	Print head alignment pattern is printing.
POWER OFF	Operate light flashing	Printer is shutting down.

Pausing and Resetting the Printer

If you need to stop the printer during a print job, press the **Pause** button. Press the **Pause** button again to resume printing.

If you decide to cancel a job after the printer has started processing it, you can reset the printer. Press the **Pause** button and hold it down for 3 seconds. This clears all data in the printer's memory.



See page 1-9 for instructions on using the printer's control panel to print a nozzle check.

Checking Printer Status

You can use the control panel to print a status check or nozzle check. These prints allow you to test the printer without sending a print job. You can also check the amount of ink remaining, total number of prints, and the status of your cutter blade and other printer parts.

Printing a Status Check

The status check shows the current default settings, amount of ink remaining in each cartridge, page count, and the status of various printer parts. To display this information on the control panel instead of printing it out, see page 5-4.

Follow these steps to print the status check:

1. Load a sheet of paper in the printer, following the instructions on page 2-10. (You can print the status check on roll paper, but you will use more paper.)
2. Press the **SelecType** button on the control panel until you see **TEST PRINT MENU** on the display.
3. Press the **Item** button until you see **STATUS CHECK=PRINT** on the display.
4. Press the **Enter** button. The status check prints. The amount of ink left or component life is indicated as follows:
 - E*****F = full (or full life remaining)
 - E**** F = 3/4 full (or 3/4 life remaining)
 - E*** F = 1/2 full (or 1/2 life remaining)
 - E** F = 1/4 full (or 1/4 life remaining)
 - E* F = nearly empty (or service life near end)
 - E F = empty (or service life ended)
5. Press the **SelecType** button to exit the Test Print menu.

Checking Ink Levels and Component Life

You can view printer status information on the control panel display without printing a status check. Follow these steps:

1. Press the **SelectType** button on the control panel. Press it several times until you see **PRINTER STATUS MENU** on the display.
2. Press the **Item** button. You see **VERSION <number>** on the display. This indicates the firmware version installed in your printer.
3. Continue pressing the **Item** button to display the amount remaining for each of the 6 inks or service life remaining for a number of printer parts. The indicators read as follows:

E***F** = full (or full life remaining)
E** F** = 3/4 full (or 3/4 life remaining)
E* F** = 1/2 full (or 1/2 life remaining)
E F** = 1/4 full (or 1/4 life remaining)
E* F = nearly empty (or service life near end)
<nn>% F = less than 10% of ink (or service life) remaining

Following is a list of the items displayed. Note that all parts on the list (except the ink cartridges and paper cutter) need to be replaced by authorized EPSON service centers.

INK LEFT-K (black)	TOTAL PRINTS
INK LEFT-C (cyan)	WASTE INK (waste ink system)
INK LEFT-M (magenta)	CR MOTOR (carriage motor)
INK LEFT-LC (light cyan)	PF MOTOR (paper feed motor)
INK LEFT-LM (light magenta)	HEAD UNIT (print head)
INK LEFT-Y (yellow)	CLEANER (cleaning unit)
CUTTER LIFE (paper cutter)	

4. Press the **SelectType** button to exit the Printer Status menu.

Responding to Control Panel Lights and Messages

When your ink or paper runs out or a problem occurs, a message appears on the display. The lights on the control panel come on or flash. The following table lists the messages alphabetically and includes an explanation and instructions for correcting the problem.

Error messages

Message	Light	Explanation	Response
COVER OPEN	Pause light on	Lower cover is open.	Close the lower cover.
INK COMPART.OPEN	Pause light on	You are replacing the ink cartridge(s) and the ink compartment cover is open.	Close the ink compartment cover when you are finished replacing the ink cartridge(s).
CLOSE INK CART. COVER	Pause light on	The ink compartment cover is open.	Close the ink compartment cover.
INK LOW	Ink Out light(s) flashing	Ink cartridge(s) are nearly empty (printing continues).	Replace ink cartridge(s) indicated by Ink Out light(s). See page 6-7 for instructions.
INK OUT	Ink Out light(s) on	Ink cartridge(s) are empty (printing stops).	Replace the ink cartridge(s) indicated by Ink Out light(s). See page 6-7 for instructions.
LOAD PAPER	Paper Out light on	Paper set lever is in the released position (all the way out) while loading paper.	After you finish loading paper, push the paper set lever all the way in, to the secured position.
LOAD ROLL PAPER LOAD SHEET PAPER	Paper Out light on	Paper source setting in printer software is different from control panel.	Make sure the right paper is loaded and the paper source setting is the same on the control panel and printer software.
MAINTENANCE REQ. <error number>	—	A printer part will need to be replaced soon.	Note the error number and contact EPSON as described on page 4.
MAINTENANCE REQ 0100	—	The waste ink system is almost full.	Call an authorized EPSON servicer to schedule replacement of the waste ink system.
NO INK CARTRIDGE	Ink Out light(s) on	Ink cartridge(s) not installed.	Install ink cartridges as indicated by the lights. See page 6-7 for instructions.
OPTION I/F ERROR	—	Wrong interface card installed.	Turn off the printer and remove the card. See the documentation that came with the card.

5-6 | Monitoring and Configuring the Printer

Error messages (continued)

Message	Light	Explanation	Response
PAPER JAM	Paper Out light flashing	Paper has jammed in the printer.	Remove the jammed paper. See page 7-11 for more information.
PAPER NOT CUT	Paper Out light flashing	Roll paper was not cut completely.	Cut the paper manually, then remove the cut paper from the printer. Reload paper, as described on page 1-4.
		Cut paper did not fall off.	Remove the cut paper from the printer. Reload paper.
PAPER NOT STRAIGHT	Paper Out light flashing	Paper slipped and fed into the printer at an angle.	Reload paper, making sure the edges are straight and aligned with the vertical row of holes at the paper exit.
PAPER OUT	Paper Out light on	No paper is loaded.	Load paper.
		Paper ran out.	Remove any printouts or paper remaining in the printer and load more paper. If the message appears during a print job, reset the printer by pressing the Pause button for 3 seconds. Then load paper and resend the job.
LOWER PAPER SET LVR	Paper Out light on	Paper set lever was released during the printing process or another operation.	Push the paper set lever all the way in, to the secured position. Start printing again from the beginning for best results.
RELOAD PAPER	Paper Out light on	Paper could not be reversed into the printing position.	Remove the paper. Reload it so that the bottom edge is straight and aligned with the vertical row of holes at the paper exit.
		Image is too wide for the paper loaded in the printer.	Resize your image or load wider paper.
		Paper is not fully ejected.	Cut the paper at the paper insertion slot, then reload paper.
		PAPER NOT CUT error was cleared.	Reload paper.
REMOVE PAPER	Paper Out light on	Paper is too thick for head cleaning.	Pull the paper set lever out to remove the paper. Head cleaning automatically starts. After cleaning, reload paper.
SERVICE REQ. <error number>	All lights flashing	An error has occurred.	Note the error number, and turn the printer off and then on. If the message remains, contact EPSON as described on page 4.

Error messages (continued)

Message	Light	Explanation	Response
SERVICE REQ. <00000100>	All lights flashing	The waste ink system is full.	Contact EPSON to have the waste ink system replaced.
TURN PWR OFF AND ON	—	This message appears after you clear a paper jam.	Press the Power button to turn the printer off and back on again.
UNABLE TO PRINT	—	You tried to print while an error condition was present or the ink compartment cover was open.	After 3 seconds the message disappears. Press the Pause button to exit SelectType mode. If the message appears again, clear the error before you print.
WRONG CARTRIDGE INVALID CARTRIDGE	Ink Out light(s) on	You tried to install the wrong ink cartridge.	If you are installing ink cartridges for the first time, you must install the cartridges that came with your printer. If you are replacing ink cartridges, check the package and product code. You must use the ink cartridges designed for your printer. Other cartridges will not work.
NOZZLE CHECK ERROR		The nozzle check pattern did not print correctly.	Press and hold the Cleaning button on the control panel for at least 3 seconds to begin cleaning the print head.
COMMAND ERROR		You're using the wrong printer driver.	Make sure you installed the Stylus Pro 10000 driver if your printer is the Photographic Dye Ink model, or the Stylus Pro 100000CF driver if your printer is the Archival Ink model.
		Damaged data was sent to the printer.	To clear the data, press the printer's Power button to turn the printer off. Wait for about a minute, then turn the printer on again.

Using the Control Panel to Configure the Printer

In addition to testing the printer and checking the status of various components, you can use the SelecType menus to configure printer settings and perform maintenance operations. The following table lists the menus, their functions, and where to find additional information:

SelecType menus

Menu	Description	For more information, see
Printer Setting	Configure the printer	page 2-9, page 2-13, page 5-8
Test Print	Print a nozzle check or status check	page 1-9, page 5-3
Printer Status	Check ink levels and component life	page 5-4
Paper Configuration	Register paper thickness and drying time, and select registered configurations	page 2-18
Cutter Replacement	Replace the paper cutter blade	page 6-11
Head Alignment	Align the print head	page 6-4

Setting Default Roll Paper Margins

The default margins for roll paper are 0.12 inches or 3 mm (left and right) and 0.59 inches or 15 mm (top and bottom). You can use the Printer Settings menu on the control panel to set all margins to 3 mm or 15 mm.



Print quality may be affected near the cut edges if you change the top and bottom margins to 3 mm.

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.
2. Press the **Item** button repeatedly until **ROLL MARG=T/B15MM*** appears on the display. This is the default setting.
 - Press the **+** button once to set all margins to 3 mm. **ROLL MARG=3MM** appears on the display.
 - Press the **+** button again to set all margins to 15 mm. **ROLL MARG=15MM** appears on the display.

You can use the + or – button to cycle through all three settings.

3. When you select the setting you want, press the **Enter** button to save it. Then press the **SelecType** button to exit the Printer Setting menu.

Turning Off Paper Monitoring Features

The printer normally stops and displays an error message if you try to print an image wider than the paper, or if paper is fed at an angle. You can turn off the paper size check and/or paper alignment check if you don't want to use these monitoring features. However, ink may be sprayed on the platen if you print an image that is too wide for the paper. Follow these steps to turn off paper monitoring:

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.
2. Press the **Item** button repeatedly until **PAPER SIZE CHK=ON** or **PAPER ALIGN CHK=ON** appears on the display.
3. Press the + button. **PAPER SIZE CHK=OFF** or **PAPER ALIGN CHK=OFF** appears on the display.
4. Press the **Enter** button to save your new setting.
5. Press the **SelecType** button to exit the Printer Setting menu.

Selecting the Printer's Interface

The printer includes three interfaces: parallel, USB, and FireWire. You can also install an optional interface card for networking. By default, the printer automatically switches to whichever interface is receiving data.

You can use the control panel to select an individual interface for sending data to the printer. Follow these steps:

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.

2. Press the **Item** button repeatedly until **INTERFACE=AUTO*** appears on the display. This is the default setting.
 - Press the **+** button once to select the parallel interface. **INTERFACE=PARALLEL** appears on the display.
 - Press the **+** button again to select the USB interface. **INTERFACE=USB** appears on the display.
 - Press the **+** button again to select the FireWire interface. **INTERFACE=OPTION1** appears on the display.
 - Press the **+** button again if you have installed the optional Ethernet Type B interface card for network connectivity. **INTERFACE=OPTION2** appears on the display.

You can use the **+** or **-** button to cycle through all four settings.

3. When you have selected the setting you want, press the **Enter** button to save it. Then press the **SelectType** button to exit the Printer Setting menu.

Configuring the Parallel Interface

You can use the control panel to change the parallel interface to ECP mode for faster printing. To use this mode, you must connect a computer directly to the printer's parallel interface (without a RIP), and the computer must support ECP mode. See your computer's documentation for details.

Follow these steps to configure the parallel interface:

1. Press and hold the **Pause** button while you press the **Power** button to turn on the printer. **HEX DUMP = PRINT** appears on the display.
2. Press the **Item** button repeatedly until **PARA. I/F=COMPAT*** appears on the display. The asterisk (*) indicates that compatible mode (the default) is selected.
3. Press the **+** button. **PARA. I/F=ECP** appears on the display. This sets the parallel interface to ECP mode.
4. Press the **Enter** button to save your setting. Then press the **Power** button to turn the printer off and exit maintenance mode.



If you experience any problems using ECP mode, switch back to compatible mode. Only a parallel connection can be configured to use ECP mode.

Changing the Printer's Code Page Setting

The printer uses the PC437 code page (U.S. and standard European character sets) by default. You can use the control panel to change it to the PC850 code page (multilingual character sets) if necessary. Follow these steps:

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.
2. Press the **Item** button repeatedly until **CODE PAGE=PC437*** appears on the display.
3. Press the **+** button. **CODE PAGE=PC850** appears on the display.
4. Press the **Enter** button to save your setting.
5. Press the **SelecType** button to exit the Printer Setting menu.

Restoring Default Settings

You can erase all **SelecType** settings you have made and restore them to their default values. Follow these steps:

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.
2. Press the **Item** button repeatedly until **INIT. PANEL=EXEC.** appears on the display.
3. Press the **Enter** button to erase all settings and restore the defaults.
4. Press the **SelecType** button to exit the Printer Setting menu.



The maintenance mode also includes a **MW7=A** setting, for use by an authorized EPSON servicer only.

Setting the Control Panel Language

All control panel messages are displayed in English. However, you can use a special printer maintenance mode to change to any of the following languages:

- French
- Italian
- German
- Spanish
- Portuguese

Make sure the printer is turned off, then follow these steps to change the language for control panel messages:

1. Press and hold the **Pause** button while you press the **Power** button to turn on the printer. **HEX DUMP=PRINT** appears on the display.
2. Press the **Item** button until **LANGUAGE=ENGLISH*** is displayed.
3. Press the **+** or **-** button until the language you want is displayed.
4. Press the **Enter** button to select the language.
5. Press the **Power** button to turn the printer off and exit maintenance mode.

Chapter 6: Maintaining and Transporting the Printer

The EPSON Stylus Pro 10000 printer requires very little maintenance to keep working at its best. This chapter describes the following routine procedures:

- Running a cleaning cycle
- Aligning the print head
- Replacing ink cartridges
- Replacing the paper cutter blade
- Cleaning the printer
- Transporting or storing the printer
- Replacing the waste ink system

Running a Cleaning Cycle

If your printed image is unexpectedly light or faint or dots are missing from the image, you may need to run a cleaning cycle. This unclogs the print head nozzles so they can deliver ink properly.

The cleaning cycle uses ink, so you should run it only if print quality declines. To determine whether a cleaning cycle is necessary, print a nozzle check first. You should also print a nozzle check after cleaning the print head to see if the cleaning cycle was successful.

There are two ways to run a cleaning cycle:

- Using the Head Cleaning utility in your printer software, as described below (not available if you are accessing the printer over a network)
- Using the printer's control panel buttons, as described on page 6-4

Using the Head Cleaning Utility

Follow these steps to run the Head Cleaning utility:

1. Make sure the printer is turned on but not printing and that all of the Δ Ink Out lights on the printer's control panel are off.

If an Δ Ink Out light is flashing or on, you need to replace the corresponding ink cartridge instead. See page 6-7 for instructions.



You can also use the printer's control panel to print a nozzle check. See page 1-9 for details.


2. If you have an application running, access the printer settings dialog box as described on page 3-3 (Macintosh) or page 4-1 (Windows).

Or, with Windows, click **Start**, point to **Settings**, and select **Printers**. Right-click your printer icon, and then select **Properties** (Windows 95, 98, or Me), **Document Defaults** (Windows NT) or **Printing Preferences** (Windows 2000).

3. **Macintosh:** Click the  utility button.

Windows: Click the **Utility** tab.

You see the Utility menu:



4. Click the **Nozzle Check** button and follow the instructions on the screen to print a nozzle check pattern.
5. When the pattern prints, check it for problems (see page 6-3 for details). If dots are missing from the pattern, continue with step 6.

If no dots are missing, your print quality problems are not caused by clogged print nozzles and you do not need to run a cleaning cycle. Click **OK** to close the Utility menu, then check the solutions under “Improving Print Quality” on page 7-2.



To avoid damaging the printer, don't turn it off until the cleaning cycle is finished and the **Pause** light has stopped flashing.

6. Click the **Head Cleaning** button and follow the instructions on the screen to clean the print head. Cleaning takes about 60 seconds, during which the printer makes some noise and the **Pause** light flashes.
7. When the **Pause** light goes off, make sure paper is loaded in the printer, then:

Macintosh: Click **Confirmation**, then click **Next**.

Windows: Click **Print nozzle check pattern**, then click **Print**.

The nozzle check pattern prints (see the next section for details).

8. If the nozzle check pattern has no gaps in its dots, click **Finish**.

If the pattern is missing dots, click **Clean** to clean the print head again. If you don't see any improvement after cleaning three or four times, check the solutions in "Improving Print Quality" on page 7-2.

If the lines on the pattern still appear broken after several cleaning cycles, turn the printer off and leave it overnight, then clean the print head again the following morning. If you still see no improvement, contact EPSON for assistance.

Examining the Nozzle Check Pattern

Examine the nozzle check pattern you print. Each staggered horizontal and straight vertical line should be complete, with no gaps in the dot pattern.



If dots are missing from the pattern, as shown below, clean the print head again.



Cleaning the Print Head Using the Control Panel

Follow these steps to run the cleaning cycle from the printer's control panel:

1. Print a nozzle check to make sure the print head needs cleaning. See page 1-9 for instructions.
2. Make sure that all of the Δ Ink Out lights on the printer's control panel are off.

If an Δ Ink Out light is flashing or on, you need to replace the corresponding ink cartridge instead. See page 6-7 for instructions.

3. Press the **Cleaning** button and hold it for at least 3 seconds. The **Pause** light flashes as the printer cleans its print head. The cleaning cycle takes about 60 seconds and does not use any paper.
4. When the **Pause** light goes off, print the nozzle check again to confirm that the head is clean.

You may need to run the cleaning cycle several times to get a clean nozzle check pattern. For effective cleaning, always run a nozzle check between cycles.

If the lines on the pattern still appear broken after several cleaning cycles, turn the printer off and leave it overnight, then clean the print head again the following morning. If you still see no improvement, contact EPSON for assistance.



To avoid damaging the printer, don't turn it off until the cleaning cycle is finished and the **Pause** light has stopped flashing.

Also, don't run a cleaning cycle while thick media is loaded in the printer.



It's a good idea always to run a nozzle check before you align the print head. This ensures that the print head alignment patterns print correctly.

Aligning the Print Head

If banding appears on your prints, or vertical lines are not straight, you need to align the print head. There are two ways to align the print head:

- Using the printer's control panel buttons, as described in the next section
- Using the Print Head Alignment utility in the printer software, as described on page 1-25

Both procedures align the print head for all modes and resolutions.

Aligning the Print Head from the Control Panel

You can use EPSON roll paper to print the alignment patterns. Two rows consisting of sets of 15 bars are printed across the width of the paper. It takes about 10 minutes to print both rows.

Follow these steps to align the print head using the control panel:

1. Load roll paper that is at least 24 inches wide in the printer.
2. Press the **SelecType** button until **HEAD ALIGNMENT MENU** is displayed.
3. Press the **Item** button. **PAPER THICK=STD** appears on the display.

If you're using EPSON paper, leave this setting on **STD**.


If you're using other media, enter the thickness value of the paper in 0.1-mm increments by pressing the **+** or **-** button.

4. Press the **Enter** button to save the setting. **ADJUST. PATT.= ALL** appears on the display.
5. Press the **Enter** button to print both rows of alignment patterns.
If you want to print a single row of alignment patterns, press the **+** or **-** button until the row number appears. Then press the **Enter** button.
6. Examine the first row. You see a series of patterns similar to the pattern below across the width of the paper. Determine which bar in the first pattern has the smallest gaps. In the example below, #8 has the smallest gaps.



Note

If bar #8 (the current alignment setting) shows the smallest gaps for both rows, the print head is aligned. Press **Pause** to exit head alignment mode.



6-6 | Maintaining and Transporting the Printer



Press **Enter** to cycle through the rows until you reach the one you want to repeat.

7. Look at the other patterns in the first row to see if the same number consistently has the smallest gaps. If not, choose the number that generally has the smallest gaps.
8. Check the control panel display. Use the + or – button to select the best aligned bar for row #1. Then press the **Enter** button to register the setting.
9. Repeat steps 6 through 8 for the second row of patterns.
10. If you chose a bar that generally, but not consistently, had the smallest gaps, print the row again. Then repeat steps 6 through 8 for that row. Repeat this step until you can choose a bar that consistently has the smallest gaps in every pattern in the row.
11. The print head is aligned when your printout shows that bar #8 (the current alignment setting) shows the smallest gaps for both rows. Press the **Pause** button to exit head alignment mode and return to normal printer operation.



You must use the EPSON ink cartridges designed for your printer. Other ink cartridges will not work and may cause damage not covered by your warranty. When you install the ink cartridges that came with the printer, your printer is initialized as either a Photographic Dye Ink model or Archival Ink model. If you fail to use the correct cartridges for your model, you will see an error message.

Replacing Ink Cartridges

When one of the Ink Out lights is flashing (and INK LOW is displayed on the control panel), the corresponding cartridge is almost out of ink. Make sure you have a replacement cartridge. When the light stays on and INK OUT is displayed, the cartridge is empty. You must replace the cartridge before you can continue printing. Use only the following EPSON ink cartridges:

EPSON Stylus Pro 10000 Photographic Dye Ink

- | | | | |
|-----------|---------|-----------------|---------|
| • Black | T499201 | • Light cyan | T504201 |
| • Cyan | T502201 | • Light magenta | T503201 |
| • Magenta | T501201 | • Yellow | T500201 |

EPSON Stylus Pro 10000 Archival Ink

- | | | | |
|-----------|---------|-----------------|---------|
| • Black | T511201 | • Light cyan | T516201 |
| • Cyan | T514201 | • Light magenta | T515201 |
| • Magenta | T513201 | • Yellow | T512201 |

To order EPSON ink cartridges, contact your dealer or call EPSON at (800) 873-7766. You can also visit the EPSON Store at www.epsonstore.com (U.S. only). In Canada, please call (800) 873-7766 for dealer referral.

Before you start, make sure the printer is on. Then follow these steps to replace an ink cartridge:


1. Note the color of the Ink Out light that is on or flashing. This is the cartridge that you need to replace.




Leave the empty cartridge in the printer until you are ready to replace it.

6-8 | Maintaining and Transporting the Printer

2. Push the indentation on the ink compartment cover to release the lock and open the cover. **INK COMPART. OPEN** appears on the display.



3. Locate the slot containing the empty ink cartridge (corresponding to the **INK OUT** light). Press down on the top of the clamp and pull it forward.






If ink gets on your hands, wash them thoroughly with soap and water. If ink gets into your eyes, flush them immediately with water.



Don't shake cartridges that have been installed previously. Doing so may cause ink to leak.


Be careful not to touch the green computer chip on the cartridge. This may affect normal operation and printing.

4. Carefully pull the empty cartridge straight out of the printer.



5. Make sure the replacement cartridge is the correct color, and remove it from its package.

If you're using Archival ink, shake the cartridge gently before installing it.







If you can't insert the cartridge smoothly, you may have the wrong cartridge. Check the package and product code.

If the **Ink Out** light remains on, the cartridge may not be installed correctly. Remove the cartridge and then reinsert it as described in step 6.

6. Hold the ink cartridge with the arrow mark on the left side and pointing to the rear of the printer. Then insert the ink cartridge into the slot. Don't force the cartridge.



7. Push the cartridge clamp back up. Make sure the corresponding **Ink Out** light goes off. Then close the ink compartment cover.



Replacing the Paper Cutter Blade

If you notice that your paper isn't cut cleanly, the cutter blade may need to be replaced. If you use the blade to cut heavy stock or non-EPSON media, you may need to replace it more often. You can also check the status of your cutter by printing the status check sheet or using the Printer Status menu on the control panel. See page 5-3 or 5-4 for instructions.

You can obtain a new cutter blade (part number C815131) from EPSON at (800) 873-7766, or visit the EPSON Pro Graphics web site at <http://prographics.epson.com>.

To replace the cutter blade, you first need to remove the used blade, as described in the following section.




Be careful not to cut yourself while replacing the paper cutter blade.

Removing the Used Cutter Blade

Make sure the printer is on, then follow these steps to remove the blade:


1. Press the **SelecType** button repeatedly until **CUTTER REPLACE MENU** appears on the display.




To avoid damaging your printer, never move the paper cutter holder by hand.

2. Press the **Item** button. **CUT. REPLACE=EXEC.** appears on the display.
3. Press the **Enter** button. The paper cutter holder moves to the replacement position.

4. When the holder stops moving and **OPEN LOWER COVER** appears on the display, open the lower cover.



5. When **REPLACE CUTTER** appears on the display, you can open the casing. Push the side pin toward the back while pushing the front half of the paper cutter cover up.




6. Slowly take your finger off the side pin. The paper cutter rises so it can be removed.



Be careful not to let the cutter or the spring coil pop out of the casing.


7. Carefully remove the cutter blade from the printer.




Installing the New Cutter Blade

After you have removed the used cutter blade, you're ready to install the new one. Follow these steps:

1. Remove the new blade from its package.
2. Make sure the spring coil is inside the cutter holder. If necessary, reinstall the coil.
3. Fully insert the new blade into the paper cutter holder in the direction shown below.



4. Push the side pin toward the back while pushing the front half of the paper cutter cover down to close the casing. Then release the side pin. **CLOSE LOWER COVER** appears on the display.



Be careful not to touch the gears inside the printer.

To avoid damaging the components as well as the case, never use alcohol or thinners to clean the printer.

Be careful not to get water on the printer mechanism or electronic components.

Don't use a hard or abrasive brush.

Don't spray the inside of the printer with lubricants; unsuitable oils can damage the mechanism. Contact your dealer or a qualified servicer if your printer needs lubrication.

5. Close the lower cover. The cutter holder moves to the home (far right) position and **READY** appears on the display.

Cleaning the Printer

To keep your printer working at its best, you should clean it thoroughly several times a year.

1. Make sure the printer is turned off and all the lights on the control panel are off. Then unplug the power cord and disconnect the printer from the computer.
2. Open the roll paper cover and remove the roll paper spindles. Remove any sheet media from the printer. Then use a soft brush to carefully clean away any dust or dirt.
3. Close the roll paper cover.
4. Open the lower cover and use a soft brush to carefully clean away any dust or dirt inside the lower cover. Then close the cover.
5. Remove the paper hammock. Then clean away any dust or dirt around the leg assembly using a soft brush.

6. If the outer case is dirty, clean it with a soft, clean cloth dampened with mild detergent. Keep the ink cartridge compartment closed to prevent water from getting inside.
7. If the area under the roll paper cover accidentally gets soiled with ink, wipe it off with a damp cloth.
8. To wash the paper hammock, remove the shafts, then machine wash with mild detergent and air dry.

Transporting or Storing the Printer

Follow these guidelines for transporting or storing the printer:

- Contact EPSON if you need to store your printer for an extended period (two years for the Photographic Dye Ink model, or six months for the Archival Ink model). See page 4 for contact information. A service technician must drain all ink from the printer before it is stored.
- To ship your printer, you should repack the printer using the original box and packing materials, and you may need to drain the ink from the printer. Follow the instructions below to prepare the printer for shipment.
- If you are moving the printer a short distance (for example, in the same building), you can move the printer on its stand. Follow the instructions on page 6-17.

Preparing the Printer for Shipment

Follow the steps below to prepare the printer for shipment:

1. First turn off the printer and make sure the print head is in the home (far right) position. If not, turn the printer back on, wait until the print head moves to the home position, then turn off the printer.

6-16 | Maintaining and Transporting the Printer



Be sure that the printer is off before you remove the ink cartridges. Otherwise the ink valves may not close properly.


2. Remove the following parts:

- Ink cartridges
- Power cord
- Interface cable
- Paper hammock
- Roll paper spindles
- All paper or other media
- Optional auto take-up reel (if installed)
- Optional manual cutter (if installed)

After you remove the ink cartridges, store them in separate, resealable plastic bags.

3. Make sure the ink cartridge clamps and cover are closed.


4. Make sure the casters on the leg assembly are locked, and that the two stabilizer knobs are touching the floor.



5. Remove the two wing nuts underneath the printer. Keep them in a safe place.



The printer unit weighs approximately 291 lb (132 kg). Always have four people lift it, using the hand grip areas as shown.



6. Have four people lift the printer unit off of the leg assembly, using the hand grips located at the four corners of the printer. Lift the back of the printer first, tilt it slightly to the front, then slide it back to remove it.

7. Keep the printer level while you move it.

Setting Up the Printer After Transporting It

Setting up the printer after transporting it is almost identical to setting it up for the first time. Whenever you set up the printer, see the *Unpacking and Assembly Guide*, and note the following points:

- Don't forget to remove any protective material (such as tape from the ink cartridge clamps).
- The first time you start printing after moving the printer, the print head nozzles may be clogged. You may need to run a cleaning cycle (see page 6-1) and realign the print head (see page 6-4) to ensure good print quality.

Moving the Printer on the Stand


When you need to move the printer a short distance, such as within the same building or facility, you can roll the printer on its casters. Follow these steps:

1. Make sure that the power cord, interface cable, roll paper spindles and sheet media are removed, and the roll paper cover and lower cover are closed.




Do not roll the printer on angled or uneven surfaces.

2. Fully insert the upper and lower hammock guides, then roll up the paper hammock.



3. Release the front casters and retract the stabilizer knobs.



4. Carefully roll the printer to its new location. Relock the casters and extend the stabilizer knobs after moving.

The first time you start printing after moving the printer, the print head nozzles may be clogged. You may need to run a cleaning cycle (see page 6-1) and realign the print head (see page 6-4) to ensure print quality.

Replacing the Waste Ink System

Approximately every two years of normal usage (25% duty cycle) or after 12,000 B1-size prints, you should have your authorized EPSON servicer replace the waste ink system. This is necessary to prevent damage to the print head and maintain print quality. Parts and labor for this service are not covered under the terms of the limited warranty.

You can monitor the status of the waste ink system through the control panel (see page 5-4) or through the Ink Pad number displayed on the nozzle check print (see page 5-3).

The printer will display the following message on the control panel when the waste ink system is almost full:

MAINTENANCE REQ. 0100

You should call to schedule service at this point. When the waste ink system is at full capacity, the printer will stop and display the following message:

SERVICE REQ. 00000100

Chapter 7: Resolving Problems

As you use your printer, you may occasionally experience a problem. The first thing you should do is diagnose the problem following the guidelines in this chapter. Then try the most likely solutions until the problem is fixed.

This chapter provides instructions for the following:

- Diagnosing problems
- Improving print quality
- Solving operational problems
- Solving miscellaneous printing problems
- Solving paper problems, including clearing paper jams
- Uninstalling and reinstalling printer software

Diagnosing Problems

The EPSON Stylus Pro 10000 printer includes a number of ways to help you diagnose problems:

- To identify the most common problems, check the messages and lights on the printer's control panel. See page 5-5 through 5-7 for more information.
- If you're using the EPSON printer driver and Monitor3 (Macintosh) or Status Monitor (Windows) utility, check your software for error messages. See Chapter 3 or 4 for more information.
- To determine whether the problem is caused by the printer itself, disconnect the printer from your computer and run a nozzle check from the control panel. See page 1-9 for instructions.
- You can use the printer's hex dump mode to pinpoint communication problems. Then you can fax the printout to a technical support representative or interpret it yourself. See the following section for instructions.
- If none of the suggested solutions in this chapter solve your problem, contact EPSON as described under "Where To Get Help" on page 4.

Using Hex Dump Mode

You can use the printer's hex dump mode to identify problems if you know how to interpret hex code, or you can fax the hex printout to a technical support representative.

Make sure the printer has paper loaded and is turned off. Then follow these steps:

1. Press and hold the **Pause** button while you press the **Power** button to turn on the printer. **HEX DUMP=PRINT** appears on the display.
2. Press the **Enter** button.
3. Send your problem file to the printer.

The data in the print buffer is printed with 16-byte hex data in the left column and corresponding ASCII characters in the right column. If the last data is less than 16 bytes, you need to press the **Pause** button to print it.

4. After you're finished using hex dump mode, press the **Power** button to turn the printer off and exit maintenance mode.

Improving Print Quality

You can often improve print quality by doing the following:

- Run a nozzle check and cleaning cycle. See page 6-1 for instructions.
- Align the print head. See page 6-4 for instructions.
- When you send a print job, make sure your print options are set correctly. For more information, see Chapter 3 (Macintosh) or 4 (Windows).

If none of these suggestions help, try the solutions on the following page.

Print quality problems

Problem	Solution
Your print has banding or vertical misalignment.	<ul style="list-style-type: none"> • Run a nozzle check and cleaning cycle. See page 6-1 for instructions. • Align the print head, as described on page 6-4. • To eliminate banding, choose 1440 dpi as your resolution. • Deselect the High Speed setting in your printer software's Advanced dialog box. • Make sure the Media Type setting in the printer software is correct for the media you're printing on. • If you're using roll paper, make sure it's correctly attached to the spindle. See page 2-8 for instructions. If you're using cut sheet media, make sure the printable side is face up. • The paper configuration setting is too thick (for non-EPSON media). Use the control panel to select thinner paper. See page 2-18 for instructions. • Check the Ink Out lights to see if you are low on ink. Replace ink cartridges if necessary, as described on page 6-7.
Colors are incorrect or missing.	<ul style="list-style-type: none"> • Make sure the Media Type setting in the printer software is correct for the media you're printing on. • If you're using roll paper, make sure it's correctly attached to the spindle. See page 2-8 for instructions. If you're using cut sheet media, make sure the printable side is face up. • Run a nozzle check and cleaning cycle (see page 6-1). • Make sure color settings in your application or printer software are correct.
Your print has gaps or appears faint.	<ul style="list-style-type: none"> • Check the expiration date printed on each of the ink cartridges. If the cartridge is too old, replace it as described on page 6-7. • Make sure the Media Type setting in the printer software is correct for the media you're printing on. • Run a nozzle check and cleaning cycle (see page 6-1). • Check the Ink Out lights and replace ink cartridges if your ink supply is low, as described on page 6-7. • The paper configuration setting is too thick (for non-EPSON media). Use the control panel to select thinner paper. See page 2-18 for instructions. • The platen gap setting is too wide. Use the control panel to change the setting from WIDE to AUTO. See page 2-13 for instructions.

7-4 | Resolving Problems

Print quality problems (continued)

Problem	Solution
Your print appears blurry or smeared.	<ul style="list-style-type: none">• Make sure the Media Type setting in the printer software is correct for the media you're printing on.• You're using the wrong paper configuration setting (for non-EPSON media). Use the control panel to register and select your paper thickness and dry time. See page 2-18 for instructions.• Your paper doesn't meet the required specifications or contains too much moisture. Load new paper.• If you're using roll paper, make sure it's correctly attached to the spindle. See page 2-8 for instructions. If you're using cut sheet media, make sure the printable side is face up.• Ink has leaked into the paper path. Wipe the paper path area of the printer with a soft, clean cloth. See page 6-14 for cleaning instructions.• Deselect the High Speed setting in your printer software's Advanced dialog box.• The paper configuration setting for your non-EPSON media is too thin. Use the control panel to select thicker paper. See page 2-18 for instructions.• The platen gap setting is too narrow. Use the control panel to change the setting from AUTO to WIDE. See page 2-13 for instructions.• Run a nozzle check and cleaning cycle (see page 6-1).

Solving Operational Problems

If you can't turn the printer on, if it stops printing unexpectedly, or if nothing prints, check the following:

- The printer is turned on and the **Operate** light is on.
- Paper is loaded in the printer
- The printer is plugged securely into a working electrical outlet that's not controlled by a switch or timer.
- The interface cable is securely connected to the printer and your computer.
- The voltage supplied by the electrical outlet matches the voltage on the printer's rating label. If not, turn off the power and unplug the power cord immediately. Contact EPSON for assistance. (See page 5 for details.)



To avoid damaging the printer, never plug it into an outlet with the wrong voltage.

If none of these suggestions help, try the solutions below:

Operational problems

Problem	Solution
The printer stops printing unexpectedly.	<ul style="list-style-type: none"> • If the Pause light is flashing, the printer is performing a maintenance procedure or waiting for ink to dry. Check the display message and lights on the control panel. Wait until the Pause light stops flashing. • Check the display message and lights on the control panel to see if an error has occurred. Follow the instructions for the messages beginning on page 5-5.
The printer sounds like it's printing, but nothing prints.	<ul style="list-style-type: none"> • Follow the instructions beginning on page 6-1 to clean the print head.
Nothing prints.	<ul style="list-style-type: none"> • Turn off the printer and computer. Make sure the interface cable is securely plugged in. • Make sure the interface cable meets the required specifications. See page 5 or 6. • Make sure the interface cable is directly connected to the computer without passing through a printer switching device, Zip™ drive, or extension cable. • If you are using Windows NT 4.0, try uninstalling the EPSON Printer Port. Click Start, point to Programs and EPSON Printers, then click EPSON Printer Port Uninstall. Follow the messages on the screen.

Operational problems (continued)

Problem	Solution
Nothing prints (cont.)	<ul style="list-style-type: none"> <li data-bbox="376 284 1292 572"> <p>• The printer port setting doesn't match the printer connection port (Windows). Windows Me, 98, or 95: Click Start, point to Settings and select Printers. Right-click the EPSON Stylus Pro 10000 or 10000CF icon, then select Properties. Click the Details tab. Make sure your printer driver is selected in the Print using the following driver list. Then select the port to which your printer is connected in the Print to the following port list.</p> <p>Windows 2000 or NT 4.0: Click Start, point to Settings, and select Printers. Right-click the EPSON Stylus Pro 10000 or 10000CF icon, then select Properties. Click the Ports tab and make sure your printer port is selected.</p> <li data-bbox="376 583 1292 703"> <p>• The printer driver doesn't have enough available memory (Macintosh). Quit all unnecessary applications. To increase the available memory in your Macintosh, select Control Panel from the Apple menu and double-click the Memory icon. You can increase the size of virtual memory to increase total available memory.</p> <li data-bbox="376 713 1292 772"> <p>• Follow the directions beginning on page 7-12 to uninstall your printer software. Then locate your printer software CD-ROM and reinstall the software.</p>

Solving Miscellaneous Printing Problems

If your printouts are not what you expected, try the suggestions below:

Miscellaneous printing problems

Problem	Solution
Your print has incorrect or garbled characters.	<ul style="list-style-type: none"> <li data-bbox="419 1050 1292 1085">• Make sure your software is installed correctly and the printer is selected. <li data-bbox="419 1095 1292 1182">• If you are using Windows NT 4.0, try uninstalling the EPSON Printer Port. Click Start, point to Programs and EPSON Printers, then click EPSON Printer Port Uninstall. Follow the messages on the screen. <li data-bbox="419 1192 1292 1262">• Clear any stalled print jobs from Monitor3 (Macintosh) or Spool Manager (Windows). <li data-bbox="419 1272 1292 1329">• Turn off the printer and computer. Make sure the interface cable is securely plugged in at both ends.

Miscellaneous printing problems (continued)

Problem	Solution
Your print has incorrect margins.	<ul style="list-style-type: none"> • Check the page size or paper size settings in your application. Make sure they are within the printer's printable area. • Make sure the Paper Size setting in your printer software is correct for the paper you're using. • Paper is loaded incorrectly. Follow the instructions in Chapter 1 or 2 to reload the paper. • The ROLL MARG (roll paper margin) setting on the control panel is incorrect. If you're using roll paper, check the setting for ROLL MARG on the Printer Setting Menu in your SelecType menus. See page 5-8 for more information.
Your image is inverted.	<ul style="list-style-type: none"> • Turn off the Flip Horizontal setting in your printer software. See page 3-10 (Macintosh) or 4-9 (Windows) in this manual for instructions.
Blank paper is printed.	<ul style="list-style-type: none"> • Make sure your software is installed correctly and the printer is selected. • Make sure the Paper Size setting in your printer software is correct for the paper you're using. • Make sure the Paper Source setting in your printer software is correct.
A ruled line on your print appears to shift.	<ul style="list-style-type: none"> • Align the print head as described on page 6-4.
The bottom edge of your print is smeared.	<ul style="list-style-type: none"> • The paper is curled toward the printable side. Flatten the paper or curl it toward the other side. • Make sure the Media Type setting in your printer software is correct for the media you're printing on. • You're using the wrong paper configuration setting (for non-EPSON media). Use the control panel to register and select your paper thickness. See page 2-18 for instructions. • The platen gap setting is incorrect. Use the control panel to change the setting from AUTO to WIDE. See page 2-13 for instructions.
Color images print in black only.	<ul style="list-style-type: none"> • Make sure your software is installed correctly and the printer is selected. • Make sure color printing is selected in your printer software.
The printer continues to feed paper after you have cancelled a job.	<ul style="list-style-type: none"> • Press the Pause button on the printer to clear any print job data in the printer's buffer. Then press and hold the Pause button to reset the printer.

Miscellaneous printing problems (continued)

Problem	Solution
Roll paper cannot be cut.	<ul style="list-style-type: none">• The paper cutter blade may be dull. Follow the instructions on page 6-11 to replace the blade.• The paper may be too thick to cut with the built-in cutter. Cut the paper by hand with scissors or the optional utility cutter.• The paper may not be ejecting properly. Make sure the Roll Auto Cut light on the control panel is on. Press the Paper Source button if necessary, and then press the Cut/Eject button.
Printing is too slow.	<ul style="list-style-type: none">• Choose a lower resolution in your printer software for faster printing.• Clear space on your hard drive or run a defragmentation utility.• Don't run too many applications at the same time.• Turn off virtual memory.• Add RAM to your system.• If you have a Macintosh, turn off background printing. If you want to continue using background printing, select EPSON Monitor3 and increase its memory requirements.• If you're running Windows and your computer supports ECP or Enhanced mode and/or DMA transfers, turn them on to speed up printing. See your computer documentation and page 4-16 for more information.

Solving Paper Problems

If paper feed or paper jam problems occur frequently, try one or more of the following solutions:

- When you're loading roll paper, make sure you line up the edge with the vertical row of holes at the printer's paper exit. Always turn the roll back to remove the slack. See page 1-4 for more information.
- If you're not using a roll of paper that's installed in the printer, secure it with the roll paper belt. See page 2-7 for more information.
- For cut sheet paper, let the printer automatically load your paper so that it feeds correctly. Follow the instructions on page 2-10.
- For posterboard, follow the instructions on page 2-11 to load the media correctly.
- Make sure the paper is not folded, wrinkled, or damp.


- Make sure the printer's environment falls within the required temperature and humidity range.
- Make sure the paper is not too thick or too thin. See pages 2-1 and A-4 for paper specifications.
- Make sure no foreign objects are inside the printer.
- Make sure the printer isn't located in a brightly lit area. The paper sensor may not be able to operate correctly.
- Make sure the **Media Type** and **Paper Source** settings in the printer software are correct.
- Make sure the platen gap setting is correct for the paper or media you're printing on. See page 2-13 for more information.
- If you're not using EPSON media, make sure you register and select your paper's thickness. See page 2-18 for more information.

Solving Roll Paper Feed Problems

If your roll paper is curled too tightly and doesn't feed out of the printer, you can use the three paper guides. Extend the guides as shown below:




Use the paper guides only if paper is curled and doesn't feed properly. Otherwise, the paper guides may damage your prints.




7-10 | Resolving Problems

- If you have the paper hammock set up in front of the printer, extend the paper guides out so they rest on the front of the hammock.



- If you have the paper hammock set up below the printer, extend the paper guides so that they rest on the back of the hammock.




Clearing Paper Jams

When paper gets jammed in the printer, printing stops and you see a **PAPER JAM** message on the control panel display. Follow these steps to clear paper jams:


1. If roll paper is jammed, open the roll paper cover and cut it by hand slightly above the paper insertion slot.
2. Pull the paper set lever out to release the jammed paper.




To avoid damaging the printer, never move the paper set lever while the **Operate** or **Pause** light is flashing.



3. Open the lower cover if necessary.



- Carefully pull down the jammed paper. **TURN PWR OFF AND ON** is displayed on the control panel.



If you have two rolls of paper installed, make sure you secure the roll that you are not using with the roll paper belt. See page 2-7 for more information.

- Close the lower cover, if necessary, then press the **Power** button to turn the printer off. Press it again to turn it back on.
- Make sure the **Paper Out** light is on and **LOAD PAPER** is displayed on the control panel. Then reload your paper.

Uninstalling and Reinstalling the Printer Software

If you need to uninstall and then reinstall the printer software for any reason, follow the instructions in the appropriate section below.

Macintosh

- Insert your printer software CD-ROM. Then double-click the CD-ROM icon to open it, if necessary.
- Double-click one of the following icons:
 - Printer Driver Installer Photographic Dye**, if your printer is the Photographic Dye Ink model.
 - Printer Driver Installer EPSON Archival Ink**, if your printer is the Archival Ink model.

3. Double-click the **Installer** icon.
4. Click **Continue** on the next screen.
5. On the installer screen, click the arrow in the Easy Install list at the top and select **Uninstall**. Then click the **Uninstall** button at the bottom and follow the on-screen instructions.
6. Restart your Macintosh. Then follow the instructions beginning on page 1-13 to reinstall your printer software.

Windows

1. Double-click  **My Computer**, then double-click the **Control Panel** icon.
2. Double-click **Add/Remove Programs**. Click **EPSON Printer Software** in the program list, then select your printer icon.
3. Click the **Add/Remove** button (**Change/Remove** button in Windows 2000) and follow the on-screen instructions.
4. If you're using the USB port in Windows 98 or Me, click **EPSON USB Printer Devices** in the program list; then click the **Add/Remove** button.
5. Restart your computer. Then follow the instructions beginning on page 1-15 to reinstall your printer software.

Appendix A: Specifications

Printing

Printing method	On-demand ink jet
Nozzle configuration	Black: 180 nozzles Color: 180 nozzles for each color (cyan, magenta, yellow, light cyan, light magenta)
Printable columns	
Character mode	10 characters per inch, 437 columns
Raster graphics mode	360 dpi: 15,762 available dots 720 dpi: 31,524 available dots 1440 dpi: 63,048 available dots
Maximum print speed	231 ft ² /hour
Maximum printable width	43.78 inches on 44-inch paper
Maximum resolution	1440 dpi × 720 dpi
Acoustic Noise Level	Approximately 50 dB(A) based on ISO 7779
Engine reliability	
Total print volume	20,000 B0 images, 30% coverage
Print head life	28 billion dots per nozzle
Periodic maintenance	Waste ink system requires replacement approximately every 2 years based on 25% duty cycle
Cutter blade life	Approximately 2,000 B0+ sheets (EPSON media up to 4.33 mil thick) Approximately 1,000 B0+ film sheets
RTC backup battery	Approximately 8 years
Print direction	Bidirectional
Control code	ESC/P® Raster
Paper feed method	Friction
Paper feed speed	215 ± 10 milliseconds per 1/6-inch line
Paper path	Roll paper or cut sheets with manual insertion

Line spacing	1/6 inch or programmable in 1/720-inch increments
RAM	128MB (fixed)
Character sets	EPSON Courier 10 characters per inch
Character tables	PC 437 (US, Standard Europe) PC 850 (Multilingual)

Environmental

	Operation	Storage	Transit (stored in shipping container)
Temperature	50 to 95 °F (10 to 35 °C)	-4 to 104 °F (-20 to 40 °C) (1 month at 104 °F)	-4 to 140 °F (-20 to 60 °C) (120 hours at 140 °F)
Humidity (without condensation)	20 to 80% RH	20 to 85% RH	5 to 85% RH

Mechanical

Height	48.2 inches (1225 mm)
Width	73.4 inches (1865 mm)
Depth	26.5 inches (673 mm)
Weight	291 lb (132 kg), with stand
Paper feed method	Friction
Paper path	Roll paper or cut sheets with manual insertion

Electrical

	120 V model	220/240 V model
Input voltage range	90 to 132 V	208 to 264 V
Rated frequency range	50 to 60 Hz	50 to 60 Hz
Input frequency range	49 to 61 Hz	49 to 61 Hz
Rated current	1.4 A	0.7 A
Power consumption	Approx. 130.5 W (ISO 10561 letter pattern) 29 W or less in standby mode	

This product is also designed for IT power systems with phase to phase voltage 220–240 V. Check the label on the back of the printer for voltage information.

Initialization

Hardware initialization at power on:

- The printer mechanism is set to its initial state.
- The input data buffer and print buffer are cleared.
- The printer returns to the last default settings.

Software initialization when the ESC@ (initialize the printer) command is received:

- The print buffer is cleared.
- The printer returns to the last default settings.

Panel button initialization by pressing the **Pause** button on the control panel for 3 seconds or more:

- The print head is capped.
- Any paper in the printer is ejected.
- The input data buffer and print buffer are cleared.
- The printer returns to the last default settings.

Safety Approvals

Safety standards UL 1950, CSA 22.2 No. 950

EMC FCC part 15 subpart B, class A, CSA C108.8 class A

Paper

Cut sheet paper specifications

Size	Dimensions in inches (approximate)	Dimensions in millimeters	Thickness
Super B0	44 × 62.2	1118 × 1580	3.15 to 19.7 mil (0.08 to .5 mm)
B0	40.5 × 57.3	1030 × 1456	
Super A0	36 × 50.9	914 × 1292	
A0	33 × 46	841 × 1189	
US E	34 × 44	864 × 1118	
B1	28.7 × 40.5	728 × 1030	3.15 to 59 mil (0.08 to 1.5 mm)
Super A1	24 × 36	610 × 914	
US D	22 × 34	559 × 864	
A1	23.4 × 33	594 × 841	
B2	20.25 × 28.75	515 × 728	
A2	16.5 × 23.4	420 × 594	
Super A3/B	13 × 19	329 × 483	
US C	17 × 22	432 × 559	
B3	14.3 × 20.25	364 × 515	
US B (ledger)	11 × 17	279 × 432	
A3	11.7 × 16.5	297 × 420	
A4	8.3 × 11.7	210 × 297	
Letter	8.5 × 11	216 × 279	

Roll paper specifications

	Maximum roll diameter	Width	Thickness
When using 2 rolls	4 in. (103 mm)	8.3 to 44.02 in. (210 to 1118 mm)	3.15 to 19.7 mil (0.08 to 0.5 mm)
When using 1 roll	5.9 in. (150 mm)		


Depending on the media, feed and print quality are guaranteed on paper thicknesses of 3.15 to 4.33 mil (0.08 to 0.11 mm), 64 to 90 gsm.

Poor quality paper may reduce print quality and cause paper jams or other problems. If you encounter problems, switch to a higher grade of paper.

Do not use curled, folded, or deckle-edge paper.

Printable Area

Minimum margins for roll paper and cut sheets:



* Default roll paper top and bottom margins are 0.59 inches (15 mm). You can set all margins to 0.12 inches (3 mm) or 0.59 inches (15 mm) using the control panel. See page 5-8 for instructions.

Ink Cartridges

Print yield

Photographic Dye	Approx. 28 pages/A0 (720 dpi, 40% duty) Approx. 6,400 pages/A4 (360 dpi, 5% duty)
Archival	Approx. 30 pages/A0 (720 dpi, 40% duty) Approx. 7,400 pages/A4 (360 dpi, 5% duty)

Cartridge life

Photographic Dye	2 years from production date
Archival	2 years from production date if unopened; within 6 months after opening package, at 77 °F (25 °C)

Temperature

Storage (uninstalled)	-22 to 104 °F (-30 to 40 °C); 1 month at 104 °F
Storage (installed)	-4 to 104 °F (-20 to 40 °C); 1 month at 104 °F
Transit	-22 to 140 °F (-30 to 60 °C); 1 month at 104 °F, 120 hours at 140 °F
Freezing	5 °F (-15 °C); ink thaws and is usable after at least 3 hours at 77 °F (25 °C)

Dimensions

Height	6.6 in. (168 mm)
Depth	13.54 in. (344 mm)
Width	1.19 in. (30.3 mm)

Weight Approximately 1.9 lb (860 g)

Capacity 16.9 oz (500 ml)

Print yield may vary, depending on how often you run print head cleaning cycles and how much you use the printer. Yield of the initial cartridge set is reduced because of ink charging.

Parallel Interface

Forward Channel

Data format	8-bit parallel, IEEE-1284 compatibility mode
Synchronization	$\overline{\text{STROBE}}$ pulse
Handshake timing	BUSY and $\overline{\text{ACKNLG}}$ signals
Signal level	TTL compatible
Connector	57-30360 Amphenol connector or equivalent

Reverse Channel

Transmission mode	IEEE-1284 Nibble mode
Adaptable connector	57-30360 Amphenol connector or equivalent
Synchronization	Refer to the IEEE-1284 specification
Handshaking	Refer to the IEEE-1284 specification
Signal level	IEEE-1284 Level 1 device
Data transmission timing	Refer to the IEEE-1284 specification

ECP Mode

Transmission mode	IEEE-1284 ECP mode
Adaptable connector	57-30360 Amphenol connector or equivalent
Synchronization	Refer to the IEEE-1284 specification
Handshaking	Refer to the IEEE-1284 specification
Signal level	IEEE-1284 Level 1 device
Data transmission timing	Refer to the IEEE-1284 specification

USB Interface

Standard	Based on Universal Serial Bus Specifications Revision 1.1, Universal Serial Bus Device Class Definition for Printing Devices Version 1.1
Bit rate	Approx. 12M bps (full speed device)
Data encoding	NRZI
Connector	USB Series B
Recommended cable length	6 feet

Index

A

- Accessories, 2
- Adhesive Synthetic Paper, 2-4
- Adhesive Vinyl, 2-4
- Advanced Photo setting, 3-5
- Aligning print head
 - control panel, 6-4 to 6-6
 - software, 1-25 to 1-27
- AppleTalk setting, 1-14
- Archival Ink
 - ink cartridges, 6-7
 - Media Type settings, 3-8 to 3-9, 4-5 to 4-6
- Auto Cut setting, 3-3, 4-7
- Auto Rotate setting, 3-3, 4-7
- Automatic Take-Up Reel, ordering, 2

B

- Background printing, Macintosh, 3-13 to 3-14
- Backlight Film, 2-2, 3-10
- Banding, 7-3
- Basic printing
 - Macintosh, 3-2 to 3-9
 - Windows, 4-1 to 4-6
- Basket, paper, *see* Hammock, paper
- Belts, roll paper, 2-7 to 2-8
- Blank pages, 7-7
- Blurry prints, 7-4
- Buttons, control panel, 5-1 to 5-12

C

- Cable problems, 7-5, 7-6
- Canceling print jobs
 - control panel, 5-2
 - Macintosh, 3-15, 3-16
 - Windows, 4-12
- Canvas
 - cutting, 2-9
 - ordering, 5, 2-4
- Cartridges, *see* Ink cartridges
- Casters, 6-18

- Chooser, selecting printer, 1-14
- Cleaner (cleaning unit), checking status, 5-3 to 5-4
- Cleaning
 - paper hammock, 6-14
 - print head, 6-1 to 6-4
 - printer, 6-14 to 6-15
- Cleaning button, 6-4
- Code page setting, 5-11
- Color management
 - Macintosh, 3-5, 3-11 to 3-12
 - Windows, 4-9 to 4-10
- Color problems, 7-3, 7-7
- Color viewing conditions, 3-12, 4-10
- ColorSync settings, 3-11 to 3-12
- Component life, checking, 5-3 to 5-4
- Configuration options
 - Macintosh, 3-18 to 3-19
 - printer, 5-8 to 5-12
 - Windows, 4-14 to 4-17
- Configuring printer, 2-18 to 2-19, 5-8 to 5-12
- Connecting printer, 1-11 to 1-13
- Control panel
 - aligning print head, 6-4 to 6-6
 - buttons, 5-1 to 5-12
 - cleaning print head, 6-4
 - component life, checking, 5-3 to 5-4
 - configuring printer, 5-8 to 5-12
 - default settings, restoring, 5-11
 - illustration, 5-1
 - ink levels, checking, 5-3 to 5-4
 - language, setting, 5-12
 - lights, 5-2, 5-5 to 5-7
 - menus, 5-8
 - messages, 5-2, 5-5 to 5-7
 - monitoring printer, 5-1 to 5-7
 - status check, printing, 5-3
- CR (carriage) motor, checking status, 5-3 to 5-4
- Custom paper size, creating, 3-2, 4-7

Cut sheet paper
 heavy stock, 2-11 to 2-14
 loading, 2-10 to 2-11
 printable area, A-5
Cut/Eject button, 2-9
Cutter
 checking life, 5-4
 cutting paper manually, 2-9
 replacing blade, 6-11 to 6-14
 service life, A-1

D

Data transfer, optimizing,
 4-16 to 4-17
Default settings, restoring, 5-11
Deleting print jobs
 Macintosh, 3-15, 3-16
 Windows, 4-12
Diagnosing problems, 7-1 to 7-2
Digital camera correction, 3-12, 4-10
Dimensions of printer, A-2
DMA transfers, 4-17
Documentation, how to use, 3 to 4
Drying time setting, 2-18 to 2-19

E

ECP mode, 5-10, A-7
EFI RIP software, ordering, 2
Electrical specifications, A-3
Energy consumption, A-3
ENERGY STAR, 7
Engine reliability, A-1
Environmental specifications, A-2
EPSON
 accessories, 2, 5
 help, 4 to 5
 media, 2-2 to 2-6
 Preferred Protection Plan, 4
 Printer Port, 4-17, 7-5, 7-6
 Store, 2, 5
EpsonNet Internal Print Server, 2
Error messages, 5-5 to 5-7

Error notification, 3-18 to 3-19,
 4-14 to 4-15
Ethernet interface
 card, ordering, 2
 system requirements, 5, 6

F

Faint prints, 7-3
Fiery RIP software, ordering, 2
FireWire
 cable requirements, 5, 6
 connecting to port, 1-12 to 1-13
 system requirements, 5, 6
Firmware version, 5-4
Flip Horizontal setting, 3-10, 4-9, 7-7

G

Gamma setting, 3-12, 4-10
Graph setting, 3-5, 4-3
Guides, paper, 7-9 to 7-10

H

Hammock, paper
 cleaning, 6-14
 in front of printer, 2-14 to 2-15
 under printer, 2-16 to 2-17
Head Alignment menu, 6-5
Head unit (print head), checking
 status, 5-3 to 5-4
Heavy media, cutting, 2-9
Height of printer, A-2
Help, EPSON, 4 to 5
Hex dump mode, 7-2
High Speed Copies setting, 3-18, 4-16
High Speed setting, 3-10, 4-8
Humidity requirements, A-2

I

ICM setting, 4-3, 4-9
Initialization, A-3

- Ink
 - monitoring level, 3-17, 3-18, 4-11 to 4-15, 5-3 to 5-4
 - waste ink system, 5-3 to 5-4, 6-19, A-1
 - Ink cartridges
 - checking status, 5-3 to 5-4
 - installing in new printer, 1-1 to 1-3
 - ordering, 6-7
 - removing for transportation, 6-16
 - replacing, 6-7 to 6-10
 - safety instructions, 8 to 9
 - specifications, A-5 to A-6
 - Ink Out light(s), 5-5 to 5-7
 - Installing
 - ink cartridges in new printer, 1-1 to 1-3
 - Macintosh software, 1-13 to 1-15
 - Windows software, 1-15 to 1-16
 - Interface, selecting, 5-9 to 5-10
 - Item button, 5-4
- J**
- Jams, paper, 7-11 to 7-12
- L**
- Language, control panel, 5-12
 - Layout
 - Macintosh options, 3-2 to 3-3
 - Windows options, 4-6 to 4-7
 - Lights, control panel, 5-2, 5-5 to 5-7
 - Loading
 - cut sheet paper, 2-10 to 2-11
 - posterboard, 2-11 to 2-13
 - roll paper, 1-4 to 1-9
- M**
- Macintosh
 - advanced print options, 3-9 to 3-13
 - background printing, 3-13 to 3-14
 - basic print options, 3-3 to 3-9
 - color management, 3-11 to 3-12
 - ColorSync settings, 3-11 to 3-12
 - configuration options, 3-18 to 3-19
 - custom print job settings, 3-5
 - drivers, 3-1 to 3-13
 - layout options, 3-2 to 3-3
 - managing print jobs, 3-13 to 3-19
 - Monitor3, 3-14 to 3-16
 - monitoring printer, 3-13 to 3-19
 - page setup options, 3-2 to 3-3
 - sharing printer, 1-17 to 1-18
 - software, installing, 1-13 to 1-15
 - software, uninstalling, 7-12 to 7-13
 - Status Monitor, 3-17
 - system requirements, 5
 - Utility menu, 3-17
 - Maintenance, 6-1 to 6-15
 - Manual cutter, ordering, 2
 - Manuals, how to use, 3 to 4
 - Margins
 - incorrect, 7-7
 - minimum, A-5
 - setting default roll paper, 5-8 to 5-9
 - Mechanical specifications, A-2
 - Media Type settings
 - Archival Ink, 3-8 to 3-9, 4-5 to 4-6
 - Photographic Dye Ink, 3-7, 4-4
 - Memory
 - problems, 7-6
 - specifications, A-1
 - Menus, SelecType, *see* SelecType menus
 - Messages
 - error, 5-5 to 5-7
 - status, 5-2
 - Metamerism, 3-12, 4-10
 - MicroWeave setting, 3-10, 4-8
 - Monitor3, 3-14 to 3-16
 - Monitoring printer
 - control panel, 5-1 to 5-7
 - Macintosh, 3-13 to 3-19
 - Windows, 4-11 to 4-15

Motors, checking status, 5-3 to 5-4
 Moving printer, 6-15 to 6-18

N

Nozzle check
 control panel, printing from,
 1-9 to 1-10
 Nozzle Check utility, using,
 6-1 to 6-2

O

Operate light, 5-2
 Optimizing data transfer,
 4-16 to 4-17
 Options, 2

P

Page count, 5-4
 Page Line setting, 2-9, 3-3, 4-7
 Page setup options, Macintosh,
 3-2 to 3-3
 Paper
 attaching to spindle, 1-4
 configuration settings,
 2-18 to 2-19, 7-3
 custom size, creating, 3-2, 4-7
 cut sheet, 2-10 to 2-14
 drying time setting, 2-18 to 2-19
 EPSON, 2-2 to 2-6
 hammock, 2-14 to 2-17
 handling, 2-1 to 2-19
 heavy stock, 2-11 to 2-14
 jams, 7-11 to 7-12
 loading sheets, 2-10 to 2-11
 non-EPSON, 2-18 to 2-19
 options, Macintosh, 3-2 to 3-3
 options, Windows, 4-6 to 4-7
 ordering, 5, 2-2 to 2-5
 printable area, A-5
 problems, 7-8 to 7-12
 registering, 2-18 to 2-19
 removing from spindle, 2-8

 requirements, 2-1
 roll, 2-6 to 2-9
 selecting registered, 2-19
 setting default roll paper margins,
 5-8 to 5-9
 specifications, A-4
 suction setting, 2-18 to 2-19
 thickness setting, 2-18 to 2-19
 trim lines, 2-9, 3-3, 4-7
 Paper basket, *see* Paper hammock
 Paper Config. menu, 2-18, 2-19
 Paper cutter
 checking life, 5-3 to 5-4
 replacing blade, 6-11 to 6-14
 service life, A-1
 Paper feed speed, A-1
 Paper guides, 7-9 to 7-10
 Paper hammock, 2-14 to 2-17
 Paper monitoring, turning off, 5-9
 Paper Out light, 5-5 to 5-7
 Paper Size setting, 3-2, 4-7, 7-7
 Paper Source setting, 3-3, 4-7, 7-7
 Parallel interface
 cable requirements, 6
 configuring, 5-10
 connecting to port, 1-12
 optimizing speed, 4-16 to 4-17
 problems, 7-5, 7-6
 specifications, A-7
 Pause button, 2-13
 Pause light, 5-2, 5-5 to 5-7
 Pausing print jobs
 control panel, 5-2
 Macintosh, 3-15
 Windows, 4-12
 PF (paper feed) motor, checking
 status, 5-3 to 5-4
 Photo Printing Accelerator, 1, 3-4, 4-9
 PhotoEnhance4, 3-11, 3-12, 4-9, 4-10
 Photographic Dye Ink
 ink cartridges, 6-7
 Media Type settings, 3-7
 Photo-realistic setting, 3-12, 4-10
 Platen gap setting, 2-13, 7-3

- Posterboard, 2-11 to 2-14
 - Power consumption, A-3
 - Print head
 - aligning, 1-25 to 1-27, 6-4 to 6-6
 - checking status, 5-3 to 5-4, 6-1 to 6-3
 - cleaning, 6-1 to 6-4
 - service life, A-1
 - Print jobs
 - canceling, 3-15, 3-16, 4-12, 5-2
 - custom settings, 3-5, 4-3
 - managing, 3-13 to 3-19, 4-11 to 4-15
 - pausing, 3-15, 4-12, 5-2
 - Print quality, 3-10, 4-8, 7-2 to 7-4
 - Print speed, A-1
 - Print time, setting, 3-13 to 3-16
 - Printer
 - checking status, 3-17 to 3-19, 4-12 to 4-15, 5-3
 - cleaning, 6-14 to 6-15
 - code page setting, 5-11
 - configuring, 5-8 to 5-12
 - connecting to computer, 1-11 to 1-13
 - control panel language, 5-12
 - default settings, 5-11
 - dimensions, A-2
 - firmware version, 5-4
 - initialization, A-3
 - interface, selecting, 5-9 to 5-10
 - maintaining, 6-1 to 6-15
 - monitoring, 3-13 to 3-19, 4-11 to 4-15, 5-1 to 5-7
 - motors, checking status, 5-3 to 5-4
 - moving, 6-15 to 6-18
 - page count, 5-4
 - parallel interface, configuring, 5-10
 - pausing, 5-2
 - Port, EPSON, 4-17, 7-5, 7-6
 - posterboard, loading, 2-11 to 2-13
 - resetting, 5-2
 - sharing, 1-16 to 1-24
 - software, uninstalling, 7-12 to 7-13
 - specifications, A-1 to A-3
 - status check, 5-3
 - storing, 6-15 to 6-17
 - total print volume, A-1
 - transporting, 6-15 to 6-18
 - turning off, 7
 - weight, A-2
 - Printer Setting menu, 2-9, 2-13, 5-8 to 5-11
 - Printer Status menu, 5-4
 - Problems
 - banding, 7-3
 - blank paper, 7-7
 - blurry prints, 7-4
 - cable, 7-5, 7-6
 - color, 7-3, 7-7
 - diagnosing, 7-1 to 7-2
 - faint prints, 7-3
 - garbled characters, 7-6
 - inverted image, 7-7
 - margin, 7-7
 - memory, 7-6
 - misalignment, 7-3
 - nothing prints, 7-5 to 7-6
 - operational, 7-5 to 7-6
 - paper, 7-8 to 7-12
 - paper feeding, 7-7, 7-9 to 7-10
 - paper jams, 7-11 to 7-12
 - print quality, 7-2 to 7-4
 - printer driver, 7-5 to 7-7
 - printing stops, 7-5
 - roll paper cannot be cut, 7-8
 - slow printing, 7-8
 - smear prints, 7-7
 - Progress Meter, 4-11, 4-16
- ## R
- RAM, *see* Memory
 - Registering non-EPSON media, 2-18 to 2-19
 - Requirements, system, 5 to 6
 - Resetting printer, 5-2

Resolution

- Macintosh, 3-10
- maximum, A-1
- Windows, 4-8

RIP software, ordering, 2

Roll Marg setting, 5-8, 7-7

Roll paper

- attaching to spindle, 1-4
- Auto Cut, 3-3, 4-7
- Auto Rotate, 3-3, 4-7
- belts, 2-7 to 2-8
- cannot be cut, 7-8
- cutting manually, 2-9
- feed problems, 7-9 to 7-10
- loading, 1-4 to 1-9
- Page Line setting, 2-9, 3-3, 4-7
- printable area, A-5
- removing from spindle, 2-8
- Save Roll Paper setting, 3-3, 4-7
- setting default margins, 5-8 to 5-9
- settings, Macintosh, 3-3
- settings, Windows, 4-7
- specifications, A-4
- trim lines, 2-9, 3-3, 4-7

S

Safety

- approvals, A-3
- instructions, 7 to 9

Saturation setting, 3-13

Save Roll Paper setting, 3-3, 4-7

SelecType menus

- Cutter Replace, 6-11
- Head Alignment, 6-5
- list, 5-8
- Paper Configuration, 2-18 to 2-19
- Printer Setting, 2-9, 2-13, 5-8 to 5-11
- Printer Status, 5-4
- Test Print, 5-3

Sharing printer, 1-16 to 1-24

Slow printing, 7-8

Smooth Fine Art Paper, 2-4

Software

- installing, 1-13 to 1-16
- uninstalling, 7-12 to 7-13

Specifications

- electrical, A-3
- environmental, A-2
- initialization, A-3
- ink cartridges, A-5 to A-6
- mechanical, A-2
- paper, A-4
- parallel interface, A-7
- printable area, A-5
- printer, A-1 to A-3
- USB interface, A-8

Speed and Progress utility,
4-16 to 4-17

Spindle

- ordering, 2
- removing roll paper, 2-8

Spool folders, 3-18 to 3-19, 4-16

Spool Manager, 4-12

sRGB setting, 4-3, 4-9

Stabilizer knobs, 6-18

Status check, 5-3

Status messages, 5-2

Status Monitor

- Macintosh, 3-17
- Windows, 4-12 to 4-13

Storing printer, 6-15 to 6-17

Support, EPSON, 4 to 5

System requirements, 5 to 6

T

Technical support, 4 to 5

Temperature requirements, A-2

Test Print menu, 5-3

Text/Graph setting, 3-5, 4-3

Transporting printer, 6-15 to 6-18

Trim lines, printing

- control panel, 2-9
- Macintosh, 3-3
- Windows, 4-7

Troubleshooting, 7-1 to 7-13
Tyvek Brillion, 2-5

U

Uninstalling software, 7-12 to 7-13
Unit ID number, 4
USB
 cable requirements, 5, 6
 connecting to port, 1-11
 driver, uninstalling, 7-13
 interface specifications, A-8
User-defined paper size, 4-7
Utility cutter, ordering, 2
Utility menu
 Macintosh, 3-17
 Windows, 4-13

V


Vivid setting, 3-12, 4-10


W

Waste ink system, 5-3 to 5-4, 6-19,
 A-1
Watercolor Paper-Radiant White, 2-5
Weight of printer, A-2
Width of printer, A-2

Windows

advanced print options,
 4-7 to 4-10
basic print options, 4-1 to 4-6
color management, 4-9 to 4-10
custom print job settings, 4-3
drivers, 4-1 to 4-10
layout options, 4-6 to 4-7
managing print jobs, 4-11 to 4-12
monitoring preferences, setting,
 4-14 to 4-15
optimizing print speed,
 4-16 to 4-17
printer status, checking,
 4-12 to 4-13
sharing printer, 1-19 to 1-24
software, installing, 1-15 to 1-16
software, uninstalling, 7-13
Speed and Progress utility,
 4-16 to 4-17
status alerts, 4-15
Status Monitor 3, 4-12 to 4-13
system requirements, 6
user-defined paper size, 4-7





EPSON Stylus® Pro 10000

YOU'VE GOT TO SEE IT IN **EPSON** COLOR.™



Printed in USA
CPD-12208