


EPSON Bluetooth  
printing application  
for mobile phone

*User's Guide*



# Contents





Introduction	1
Installing the Application	3
Starting and Closing the Application	4
Searching and Selecting the Printer	5
Printing Images	9
Printing Contacts	22
Printing a Calendar	28
Printing Messages	32
Printing Notes	38
Help and About	42
Known Limitations	44


# Introduction

In this application you can print the following kind of contents saved to your phone.


## Print photographic images    Print contacts




## Print daily schedule



## Print E-mail or message



## Print Memo



It's easy to check what you are printing with the following image display methods.

### List display



### Grid display



### Full screen display



# Installing the Application

1. Copy print application file (suffix is sis) to your mobile phone.
2. The installation program starts up.
3. Click “Yes” to install the software.

## **Uninstalling the application**

When uninstalling the software, please refer to your mobile phone manual.

## **Reinstalling the application**

When reinstalling the application, first uninstall the software that was previously installed on your mobile phone then reinstall the software.

# Starting and Closing the Application

Choose "Print" when the application is starting up. When the message, "This application is not tested for this phone. OK or start?" is displayed, choose "Yes".



Choose "Exit" to close the application.




# Searching and Selecting the Printer

## *Select a Printer*


When multiple printers have been selected, the printer currently chosen can be changed.

1. From "Options" choose "Settings" then "Printers".
2. Select the printer from the list then choose "Done".




# Adding a New Printer

1. From "Options" choose "Settings" then "Printers".



2. From "Options" choose "Add". The printer is detected and displayed.



3. To print from this printer, choose "Select". The new printer has been added.





4. Choose "Done".

# Removing a Printer from the List


Removing a printer that has been added but is not connected.

1. From "Options" choose "Settings" then "Printers".
2. Select the printer to remove, then from "Options" choose "Delete".



3. Choose "Yes".

The printer information is deleted.



4. Choose "Done".

# Printing Images

*Printing the images in the Gallery.*

1. Choose "Gallery".
2. Add a check mark to the images you want to print.



3. From "Options" choose "Settings" then make any print settings you require. Please refer to "Print Settings" for details on how to make or change settings.

4. From "Options" choose "Print". The print settings confirmation screen is displayed.



5. Choose "Yes".



## How to attach a check mark

When selecting images to be printed, attach a check mark to single or multiple target images.

When in list display or grid display, from "Options", choose "mark/Unmark".




Choose "Mark" when attaching a check mark to the selected image only.

When removing a check mark from the selected image, choose "unmark".

Choose "Mark all" when attaching check marks to all images.

When removing check marks from all images, choose "Unmark all".



Once an image has been marked, a check mark will appear beside or beneath the image.




When in list display



When in grid display

## *Canceling Printing*

To cancel printing, from "Options", choose "Print cancel" then "Yes".




# Print Settings


You can change the printer or make detailed print settings if from "Options", you choose "Settings".

Adding, removing or changing printers is performed in "Printers". Please refer to page 5 for detailed procedures.

When selecting "Print settings", choose "OK" to set up each individual item, "Done" to confirm a setting and "Back" to return to the image display screen.




print settings



the opened screen


**Media type:**

Choose the type of paper for printing.




**Media size:**

Choose the size of paper for printing.



**Print layout:**

Choose the size of the image to be printed.



**Print quality:**

Choose the quality of the images to be printed.



# Viewing the Images

## List display/Grid display/Full display

List display shows thumbnails of the images with their file name and creation date.

When in this display mode, you can attach check marks to the images you want to print.



Grid display shows only thumbnails of the images.

When in this display mode, you can attach check marks to the images you want to print.




Full display shows full screen images.

When in this display mode, you can set titles or add a memo to the image. Please refer to "Setting the image title" and "Adding the Memo" for information about titles and memos.





Please switch between the display modes as you like. From "Options", choose "View" then select the type of display.



## Setting the Image Title

You can change the filename of the selected image and set the contents of the print time.

1. From "Options" choose "Detail", then "Title".
2. Set the title details.




3. Choose "Done".

## Title Settings


### Text:

Change the image title. Input a new title, then choose "OK".




### Colour:

Set the colour for the title to be printed in. Pick a colour, then choose "OK".



### Size:


Set the size of the characters for the title to be printed in. Select a size, then choose "OK".



# Adding a Memo

When printing images, you can print text you have inputted as a memo, at the same time.

1. From "Options" choose "Detail", then "Memo".
2. Set the memo details.




3. Choose "Done".

## Memo Settings

### Text:

Enter up to 50 characters of text, then choose "OK".




### Colour:

Set the colour for the text to be printed in. Pick a colour, then choose "OK".



### Size:

Set the size for the text to be printed in. Select a size, then choose "OK".



# Printing Contacts

*Print the contents of your saved contacts.*



## **Select the Data to Print**

1. Choose "Contacts".



2. Select the contact information to print.


Once selected, a check mark appears to the left.



**3.** From “Options” choose “Settings” then make any print settings you require. Please refer to “Print Settings” for details on how to make or change settings.


**4.** From “Options” choose “Print”. The print settings confirmation screen is displayed.

**5.** Choose “Yes”.




# *Print All the Contact Information Saved to a Group*

1. Choose "Contacts".
2. Select the group tab.




3. Choose the group to print. Once selected, a check mark appears to the left.



4. From "Options" choose "Settings" then make any print settings you require. Please refer to "Print Settings" for details on how to make or change settings.

5. From "Options" choose "Print". The print settings confirmation screen is displayed.



6. Choose "Yes".




## *Print Settings*


You can change the printer or make detailed print settings if from "Options", you choose "Settings".

Adding, removing or changing printers is performed in "Printers". Please refer to page 5 for detailed procedures.

When selecting "Print settings", choose "OK" to set up each individual item, "Done" to confirm a setting and "Back" to return to the image display screen.



print settings screen




the opened screen

**Media type:**


Choose the type of paper for printing.

**Media size:**

Choose the size of paper for printing.

**Print layout:**

Choose the size of the image to be printed.

**Print quality:**

Choose the quality of the images to be printed.



# Printing a Calendar


*Print the contents saved to your Calendar.*

1. Choose "Calendar". The schedule saved for today's date is displayed.




2. Choose the date to print.

From "Options", choose "Go to date" then input the date that is displayed and choose "OK".



3. From "Options" choose "Settings" then make any print settings you require. Please refer to "Print Settings" for details on how to make or change settings.
4. From "Options" choose "Print". The print settings confirmation screen is displayed.
5. Choose "Yes".




## *Print Settings*


You can change the printer or make detailed print settings if from "Options", you choose "Settings".

Adding, removing or changing printers is performed in "Printers". Please refer to page 5 for detailed procedures.

When selecting "Print settings", choose "OK" to set up each individual item, "Done" to confirm a setting and "Back" to return to the image display screen.




print settings screen



the opened screen


**Media type:**

Choose the type of paper for printing.




**Media size:**

Choose the size of paper for printing.



**Print layout:**

Choose the size of the image to be printed.



**Print quality:**

Choose the quality of the images to be printed.



# Printing Messages

*Print a sent or received message or an attached file.*


1. Choose "Messaging".



2. Choose the folder to print. When Drafts has been chosen, a list of messages contained in the folder is displayed.




3. If you want to confirm the contents of your message, from "Options", choose "Open".




4. From "Options" choose "Settings" then make any print settings you require. Please refer to "Print Settings" for details on how to make or change settings.

5. From "Options" choose "Print". The print settings confirmation screen is displayed



6. Choose "Yes".



## **When printing messages that have not been Fetched**

A screen to confirm whether or not a message has been fetched will be displayed, in the event that a message that has not been fetched is chosen.

When fetching a message, choose "Yes" then enter the username and password. The message can be retrieved.

## **When printing an attached file**

### **Text Message(SMS)**

Text only messages. The transmission origin, destination and body of the message will be printed.

### **Multimedia Message(MMS)**

Messages with images attached. The transmission origin and destination (cc: and bcc: included), the subject and the body of the message will be printed.

### **E-mail**


The transmission origin and destination (cc: and bcc: included), the subject and the body of the message will be printed. When an image file has been attached, images in JPEG format only can be printed from the Gallery. Please save your image data to the Image folder beforehand.

# Print Settings


You can change the printer or make detailed print settings if from "Options", you choose "Settings".

Adding, removing or changing printers is performed in "Printers". Please refer to page 5 for detailed procedures.

When selecting "Print settings", choose "OK" to set up each individual item, "Done" to confirm a setting and "Back" to return to the image display screen.




print settings screen



the opened screen


**Media type:**

Choose the type of paper for printing.




**Media size:**

Choose the size of paper for printing.



**Print layout:**

Choose the size of the image to be printed.



**Print quality:**

Choose the quality of the images to be printed.



# Printing Notes

*Print the contents of a note.*

1. Choose "Notes". The note list is displayed.



2. Choose the note to print.

The contents of the note are displayed.



3. From "Options" choose "Settings" then make any print settings you require. Please refer to "Print Settings" for details on how to make or change settings.

4. From "Options" choose "Print". The print settings confirmation screen is displayed.



5. Choose "Yes".




## *Print Settings*


From "Options", if you choose "About", you can view the software version and other information about this software.

Adding, removing or changing printers is performed in "Printers". Please refer to page 5 for detailed procedures.

When selecting "Print settings", choose "OK" to set up each individual item, "Done" to confirm a setting and "Back" to return to the image display screen.




print settings screen



the opened screen


**Media type:**

Choose the type of paper for printing.




**Media size:**

Choose the size of paper for printing.



**Print layout:**

Choose the size of the image to be printed.



**Print quality:**

Choose the quality of the images to be printed.



# Help and About

## *Help*

From “Options”, if you choose “Help”, you can view a simple explanation of the currently selected command or screen. Once you have confirmed the contents, choose “Close”.



## About

From "Options", if you choose "About", you can view the software version and other information about this software. Once you have confirmed the contents, choose "OK".



# Known Limitations

- ❑ This phone only supports images in JPEG format. It is not able to print GIF images or any other kind of image attached to email or MMS messages. The phone is not able to print images taken from moving media (videos and movies). It is not able to print black and white animated images. These images are sometimes known as picture mail.
- ❑ If the images you are trying to print exceed the phone or printer memory the printer will be unable to complete the task. The images may only partially print or not print at all. Usually you can fix this problem by deleting items that use a lot of memory. This will create more free space in the memory and the printer should be able to complete the task.
- ❑ When using a NOKIA 7650 handset with an old OS version, it is possible that an error message may be displayed upon completion of the installation. Additionally, unless the handset is reset upon completion of the installation, it is possible that it may not function correctly.
- ❑ JPEG images attached to emails must first be saved to a file. Then you can print the image.
- ❑ The printer application does not recognize images sent to the phone using Bluetooth wireless technology. The image must first be saved to a file. Then you can print the image.
- ❑ Not all of the screens have a help option.

- ❑ On occasion the Bluetooth wireless technology may stop working. This is normally because "Find Printers" has been accessed repeatedly in a short space of time. When this happens, some printers may display a red light or a flashing red light. To restart the Bluetooth wireless technology, go to the phone's "Connections" screen. Then go to the Bluetooth wireless technology settings and switch the Bluetooth wireless technology off and then on again.