

# EPSON<sup>®</sup>

## MM PROJECTOR

### EMP-82

### EMP-62

### EMP-X3

[Troubleshooting](#)[Notations Used in This Guide](#)[Index](#)[Understanding This Guide](#)[Glossary](#)[Saving This Guide on a Computer](#)

## User's Guide

### [Projector Features](#)

### [Part Names and Functions](#)

### [Projection Procedure](#)

### [Adjusting and changing the image](#)

This explains how to adjust the quality of the image, the volume, the colour mode selection and so on, and also how to change the image.

### [Useful Functions](#)

This explains useful functions for giving presentations and so on, and the security functions.

### [Configuration Menu](#)

This explains how to use the configuration menu and its functions.

### [Appendices](#)

This provides information on maintenance procedures to ensure the best level of performance from the projector.

### [Optional Accessories and Consumables](#)

\* This User's Guide is for EMP-82/62/X3. All of the illustrations are from EMP-X3 unless stated otherwise.

## Safety Instructions

This explains how to use this unit safely. Read these notes carefully before using this unit.

### [Safety Instructions](#)

### [Notes on Handling and Storage](#)

## World-Wide Warranty Terms

This explains support and service information for this unit.

### [Utility Software](#)

### [Problem Check Sheets](#)

### [International Warranty Conditions](#)