

"Uxx" refers to a page number of the EMP-7850 User's Guide.  
 "Exx" refers to a page number of the EasyMP Operation Guide.

## Symbols

.bmp .....	E-3, E-15
.jpg .....	E-3, E-15
.mpg .....	E-3, E-15
.mrk .....	E-15
.png .....	E-15
.sit .....	E-8, E-15
.wav .....	E-3

## Numerics

13w3 Port .....	U-20
5BNC Port .....	U-21

## A

A/V Mute .....	U-62, U-84, E-22, E-31
"About" Menu .....	U-90
AC-3 .....	E-3, E-15
Advance .....	E-13
"Advanced1" Menu .....	U-86
"Advanced2" Menu .....	U-89
Air exhaust vent .....	U-6
Air filter .....	U-6, U-7
Air intake vent .....	U-6, U-7
Analogue-RGB .....	U-76, U-90
Animation .....	E-3, E-6, E-12

Aspect Ratio .....	U-70
Audio cable .....	U-31
"Audio" Menu .....	U-81
[Audio Out] port .....	U-10, U-32
[Audio] port .....	U-10, U-31
Auto Setup .....	U-53, U-89
Automatic keystone correction .....	U-46, U-83
Autorun .....	E-8

## B

Background Color .....	E-5
Bass .....	U-81
Battery insertion and replacement period .....	U-11
BGM .....	E-5
BNC Input .....	U-84
BNC Sync Termination .....	U-89
Brightness .....	U-76, U-79
Brightness Control .....	U-89

## C

CardPlayer .....	E-16
Ceiling .....	U-14
Cell .....	E-6
Cleaning the Air Filter .....	U-119
Cleaning the Lens .....	U-119
Cleaning the Projector Case .....	U-119
CMYK colour format .....	E-3, E-15



Color .....	U-79
Color Adjustment .....	U-87
Color Mode .....	U-77, U-80
Color Temperature .....	U-87
Colour Mode .....	U-56
COM Port .....	U-89
Component Video .....	U-28
Composite Video .....	U-27
Computer cable .....	U-19
Computer Input .....	U-84
[Computer] port .....	U-10
Computer/DVI Audio Input .....	U-31, U-81
Connecting to a Computer .....	U-18
Connecting to a Video Source .....	U-27
Continuous Play .....	E-9, E-26
Contrast .....	U-76, U-79
[Control (RS-232C)] port .....	U-10
Control Panel .....	U-9
Cool-down .....	U-40, U-99
Create a Scenario Easily .....	E-10
Cross .....	U-63
Curved Line .....	U-67

## D

Digital Camera .....	U-33
Digital-RGB .....	U-76, U-90
Display Conditions .....	E-26

Display order .....	E-26
DPOF .....	E-15
Dynamic .....	U-56, U-77, U-80

## E

Easy Menu .....	E-17
EasyWeb .....	E-29
Editing a Scenario .....	E-22
Effect .....	E-26
Effect Function .....	U-66
Eligible Computers .....	U-18
EMP Link21L .....	U-135
EMP Monitor .....	E-32
EMP SlideMaker2 .....	E-4
Error data .....	E-35
ESC/VP21 .....	U-133
External Monitor .....	U-26
E-Zoom .....	U-63, E-22

## F

Focus .....	U-42
Focus Adjustment .....	U-42
Focus ring .....	U-6
Foot Adjustment .....	U-44
Freeze .....	U-63, E-22, E-31
Frequency .....	U-90
Front adjustable foot .....	U-6

**G**

Glossary ..... U-130  
Graphics and Movie Files ..... E-3, E-24  
Guide mode ..... E-17

**H**

Handle ..... U-6  
HDTV ..... U-131, U-136  
Height Correction ..... U-48  
Help function ..... U-95  
High ..... U-89  
Highest image quality ..... E-5

**I**

Image Quality ..... E-5  
Image Size ..... U-15, U-42  
Indicator ..... U-6, U-97  
Input Signal ..... U-90

**J**

JPEG ..... E-3, E-5

**K**

Keystone ..... U-45

**L**

Lamp ..... U-90

Lamp cover ..... U-7  
Lamp indicator ..... U-6, U-97  
Lamp Replacement Period ..... U-120  
Language ..... U-88  
Lens cover ..... U-6  
Linear PCM ..... E-3, E-15  
Living Room ..... U-56, U-77, U-80  
Low ..... U-89

**M**


Main menu ..... U-75  
Manually Correcting Keystone Distortion ..... U-45  
Menu ..... U-92  
Message ..... U-84  
Mini D-Sub 15-pin Port ..... U-19  
[Monitor Out] port ..... U-10  
Mouse pointer ..... U-25  
MPEG ..... E-3, E-15  
MPEG-1 Layer 2 ..... E-3, E-15

**N**

Network setup ..... E-31  
No-Signal Msg. .... U-84  
Numeric buttons ..... U-8

**O**

Operating angle (Remote Control) ..... U-13



Operating distance (Remote control) .....	U-13
Operating temperature .....	U-137
Operation indicator .....	U-6, U-97
Operation mode .....	E-26
Optional Accessories .....	U-129
Overheating .....	U-98

## P

P in P function .....	U-64
Part Names and Functions .....	U-6
Password Protect .....	U-58
Password Protect stickers .....	U-60
Playing a Scenario .....	E-21
Pointer .....	U-66
Pointer Speed .....	U-82
Port .....	U-37
Position .....	U-53, U-76, U-79
Power Cable .....	U-35
Power inlet .....	U-7
PowerPoint .....	E-3
Presentation .....	U-56, U-77, U-80
Preset .....	U-77
Preset Function .....	U-68
Preview .....	E-11
Preview Function .....	U-38
Problem Solving .....	U-97
Progressive .....	U-86

Progressive format .....	E-3, E-15
Projection .....	U-40
Projection angle .....	U-43
Projection Distance .....	U-15
Projector Control .....	E-31
Projector ID .....	U-73
Projector Setup .....	E-30

## Q

Quick Corner .....	U-49
Quick mode .....	E-17, E-19

## R

[R/C] switch .....	U-8, U-12
Real display .....	U-71
Rear adjustable foot .....	U-7, U-44
Rear Proj. ....	U-14, U-87
Refresh Rate .....	U-91
Remote Control .....	U-8, U-11, U-12, U-24
Remote Control ID .....	U-73
Remote control light-emitting area .....	U-8
Remote control light-receiving area .....	U-6, U-7
[Remote] port .....	U-8, U-10
Replacing the Air Filter .....	U-125
Replacing the Lamp .....	U-121
Request Code .....	U-58
"Reset All" Menu .....	U-91

Reset Lamp Timer .....	U-90, U-124
Resized display .....	U-71
Resolution .....	U-77, U-91, U-136
RGB .....	U-87
RGB Video .....	U-29
Rotating the Image .....	E-19

## S

Scenario .....	E-4, E-21
Scenario Folder .....	E-5
Scenario Name .....	E-5
Scenario Preview .....	E-11
Screen Size .....	U-15
Screen switching .....	E-22
Screen switching time .....	E-26
Security lock .....	U-7
Sending a Scenario .....	E-8
"Setting" Menu .....	U-83
Setting Up the Projector .....	U-14
Sharpness .....	U-76, U-79
Sleep Mode .....	U-84
Slideshow .....	E-3, E-25
SNMP .....	E-38
Source .....	U-90
Speaker .....	U-7, U-31, U-32
Specifications .....	U-137
Squeeze mode .....	U-72

sRGB .....	U-56, U-77, U-80
Standby Mode .....	U-88
Startup Screen .....	U-86
Stop playing a scenario .....	E-22
Storage temperature .....	U-137
Straight line .....	U-67
Sub-menu .....	U-75
Supported Monitor Displays .....	U-136
Suspension bracket fixing point .....	U-7, U-139
S-Video .....	U-28, U-79
[S-Video] port .....	U-10
Sync .....	U-53, U-76
SYNC Mode .....	U-91
SYNC Polarity .....	U-90

## T

Temperature indicator .....	U-6, U-97
Theatre .....	U-56, U-77, U-80
Tint .....	U-79
Tracking .....	U-53, U-76
Translucent screen .....	U-14
Treble .....	U-81
Turning off .....	U-40

## U

USB Cable .....	U-24, U-33
USB Connection Setup .....	U-135

USB mouse .....	U-24
[USB TypeA] port .....	U-10, U-33
[USB TypeB] port .....	U-10
User's Logo .....	U-126
User's logo .....	U-62
"User's Logo" Menu .....	U-85
Using the Configuration Menu Functions .....	U-75

## V

Vertical correction and horizontal correction .....	U-47, U-83
Video .....	U-79, U-90
"Video" Menu .....	U-76
[Video] port .....	U-10
Video Signal .....	U-80, U-90
View graphics or movie files .....	E-24
Volume .....	U-57, U-81

## W

Wall Shot .....	U-51
Web browser .....	E-29
Wide-screen Projection .....	U-72
Wireless Mouse Function .....	U-24
Workstation .....	U-20

## Y

YCbCr .....	U-37, U-79, U-90
YPbPr .....	U-37, U-79, U-90

## Z

Zoom Function .....	U-42
Zoom ring .....	U-6

