

EPSON

User's Guide

Multimedia Projector EMP-1815/1810



Attention	Indicates procedures which may result in damage or injury if sufficient care is not taken.
	Indicates additional information and points which may be useful to know regarding a topic.
	Indicates a page where detailed information regarding a topic can be found.
	Indicates that an explanation of the underlined word or words in front of this symbol appears in the glossary of terms. See the "Glossary" section of the "Appendices".  p.88
Procedure	Indicates operating methods and the order of operations. The procedure indicated should be carried out in the order of the numbered steps.
[(Name)]	Indicates the name of the buttons on the remote control or the control panel. Example: [Esc] button
"(Menu Name)"	Indicates configuration menu items. Example: "Image" - "Brightness"
	Indicates that the explanation continues on the following page. Clicking this symbol will display the following page.
	Indicates that the explanation is continued from the previous page. Clicking this symbol will display the previous page.

Projector Features	5
EMP-1815/1810 Common Features	5
EMP-1815 Features	6
Part Names and Functions	7
Front/Top.....	7
Side (EMP-1815 Only)	8
Base	9
Rear	10
Control Panel	12
Remote Control	13

Useful Functions

Correcting Distortion in the Projected Image	16
Automatically Correcting Distortion (Quick Setup)	17
Aligning the Projected Image to the Screen (Quick Corner)	18
Changing the Projected Image	20
Automatically Detect Incoming Signals and Change the Projected Image (Source Search)	20
Changing Directly from the Remote Control	21
Functions for Enhancing Projection	22
Selecting the Projection Quality (Selecting Colour Mode)	22
Hiding the Image and Sound Temporarily (A/V Mute)	23
Freezing the Image (Freeze).....	24
Changing the Aspect Ratio (Resize)	25
Pointer Function (Pointer)	26
Enlarging Part of the Image (E-Zoom)	27
Using the Remote Control to Operate the Mouse Pointer (Wireless Mouse).....	28
Remote Control of Two or More Projectors	30
Setting the Projector ID	30
Setting the Remote Control ID	31
Adjusting Colour for Several Projectors (Multi-Screen Colour Adjustment)	32
Summary of Adjustment Procedure	32
Image Correction Method.....	33
Security Functions	34
Managing Users (Password Protect)	34
Restricting Operation (Operation Lock).....	37
Anti-Theft Lock	38

Configuration Menu

Using the Configuration Menu	40
List of Functions	41
Image Menu.....	41
Signal Menu.....	42
Settings Menu.....	43
Extended Menu.....	44
Network Menu (EMP-1815 Only).....	46
Info Menu (Display Only)	57
Reset Menu	58

Troubleshooting

Using the Help	60
Problem Solving	61
Reading the Indicators.....	61
When the Indicators Provide No Help.....	64

Appendices

Installation Methods	72
Cleaning	73
Cleaning the Projector's Surface	73
Cleaning the Lens.....	73
Cleaning the Air Filter and Air Intake Vent.....	73
Replacing Consumables	74
Replacing the Remote Control Batteries	74
Replacing the Lamp.....	75
Replacing the Air Filter	78
Saving a User's Logo	79
Screen Size and Distance	81
Connecting USB Devices (Digital Camera, Hard Disk Drive or Memory Devices) (EMP-1815 Only)	82
Connecting USB Devices	82
Inserting and Ejecting CompactFlash Cards (EMP-1815 Only)	83
How to Insert Cards	83
How to Remove Cards.....	83
Connecting to External Equipment	85
Connecting to an External Monitor	85
Connecting to External Speakers	85



Connecting a LAN Cable	86
Optional Accessories and Consumables	87
Glossary	88
ESC/VP21 Commands	90
Command List.....	90
Cable Layouts	90
PJLink (EMP-1815 Only)	91
List of Supported Monitor Displays	92
Specifications	93
Appearance	97
Index	98



EMP-1815/1810 Common Features

The following introduces features common to the EMP-1815 and the EMP-1810.


Ease of use

■ Quick Setup

This feature corrects distortion in the projected image by a simple one-touch operation. Images can be corrected and matched to the size of the screen to simplify preparations.

■ The A/V mute slide makes it easy to project and store


You can stop and resume projection easily by opening and closing the A/V mute slide which makes giving clear presentations easier.



■ A single foot design means you do not have to make any difficult leveling adjustments

You can easily make height adjustments with one hand.

☞ *Quick Start Guide*



Enhanced security functions

■ Password Protect to restrict and manage users

By setting a password you can restrict who can use the projector. ☞ p.34

■ Operation Lock restricts button operation on the control panel

You can use this to prevent people changing projector settings without permission at events, in schools, and so on. ☞ p.37

■ Equipped with various anti-theft devices

The projector is equipped with the following security devices. ☞ p.38

- Security slot
- Security cable installation point

Easy to handle

■ Direct power On/Off

In places where power is managed centrally, such as in a conference room, the projector can be set to power on and off automatically when the power source to which the projector is connected is switched on or off.

■ No cool down delay

You can disconnect the projector's power cable without having to wait for the projector to cool down first.

■ High powered, 1.6 times zoom lens

The 1.6 times zoom allows for a wide range of installation positions to suit most room layouts, whether the projector is on a stand, a table, or ceiling mounted.

EMP-1815 Features


The EMP-1815 can be connected to a computer by a wired or wireless LAN connection. The situations in which this projector can be used increase as shown below if you use the PC applications supplied.

Connect to a computer easily

■ Computer and wireless connection

Use a wireless LAN to connect easily to your computer in a 1:1 configuration. [☛ Wireless LAN Quick Connection Guide](#)


You can also connect to the access point. [☛ EasyMP Operation Guide](#)



■ Connect using a USB cable (USB display)

Simply by connecting a cable to your computer you can project images from the computer's screen.

[☛ Wireless LAN Quick Connection Guide](#)



Powerful presentation support

■ Presentations without a computer

You can record presentation data scenarios to media beforehand, and then simply start playback to make the presentation without a computer.

[☛ EasyMP Operation Guide](#)

■ Slide show projection only (Presentation mode)

This mode allows you to project only images of your PowerPoint slide show. You can give stylish presentations without showing spectators operations or other preparation material. [☛ EasyMP Operation Guide](#)

Strengthened security level of wireless LAN

Security is stronger than previous models. You can feel secure using it as part of the network. [☛ EasyMP Operation Guide](#)


Second and third screen projection (Multi-screen display)

You can project each virtual display set on the computer by using two or more projectors. You can use it to make file operations and arrangements for the virtual displays while projecting only the virtual displays.

[☛ EasyMP Operation Guide](#)




Front/Top



Name	Function
① Control panel	☞ p.12
② USB access indicator (EMP-1815 Only)	Whether they are flashing or lit indicates the access status of USB Type A. When the indicator is off, this indicates that no USB devices are inserted. When the light is orange, this indicates that a USB device is inserted. When the light is red, this indicates that an error has occurred.
③ Lamp cover	Open this cover when replacing the projector's lamp. ☞ p.75


Name	Function
④ Air exhaust vent	Attention Do not place objects that may become warped or otherwise affected by heat near the air exhaust vent and do not put your face or hands near the air exhaust vent while projection is in progress.
⑤ Speaker	
⑥ Front adjustable feet	Extend and adjust the position of the projected image when the projector is placed on a surface such as a desk. ☞ Quick Start Guide
⑦ Foot adjust lever	Pull out the foot lever to extend and retract the front foot. ☞ Quick Start Guide
⑧ A/V mute slide	Slide shut when not using the projector to protect the lens. By closing during projection you can hide the image and the sound (A/V Mute). ☞ Quick Start Guide, p.22
⑨ Remote receiver	Receives signals from the remote control. ☞ Quick Start Guide
⑩ A/V mute slide knob	Slide the knob to open and close the A/V mute slide.
⑪ Focus ring	Adjusts the image focus. ☞ Quick Start Guide
⑫ Zoom ring	Adjusts the image size. ☞ Quick Start Guide

Side (EMP-1815 Only)



Name	Function
① Wireless LAN unit	Install this before using the projector. Connects the projector to a computer by a wireless connection.  Wireless LAN Quick Connection Guide
② Card slot	This slot is for inserting a CompactFlash card when the PC Free function in EasyMP is used. You can also write to the CompactFlash card from a computer connected to the projector via a network.  p.83
③ Card slot access indicator	Indicates the access status of the CompactFlash card.  p.84
④ Eject button	Press this button to eject the CompactFlash card.  p.83


Base



Name	Function
5 Air filter (Air intake vent)	This prevents dust and other foreign particles from getting inside the projector when air is drawn in. The projector displays a warning message when it is time to clean or replace the air filter. p.73, 78

Name	Function
1 Suspension bracket fixing points (3 points)	Attach the optional ceiling mount here when suspending the projector from a ceiling. p.72, 87
2 Security cable installation point	Pass a commercially available anti-theft wire lock through here when you want to secure the projector to a fixed object. p.38
3 Rear foot	Turn to extend and retract to adjust the horizontal tilt. Quick Start Guide
4 Screw hole to fix wireless LAN unit	This hole is for a screw to fix the wireless LAN unit in place. Wireless LAN Quick Connection Guide

Rear



Name	Function
1 Monitor Out port	Outputs the image signal from the computer connected to the Computer1 input port to an external monitor. This is not available for <u>component video</u> signals or other signals being input to any port other than the Computer1 input port.
Audio Out port	Outputs the sound of the image currently being projected to external speakers. p.85
2 Power inlet	Connects to the power cable. Quick Start Guide
3 S-Video input port	For <u>S-video</u> signals from video sources.
Video input port	For <u>composite video</u> signals from video sources.


Name	Function
Audio-L/R input port	These connect to the audio out port of equipment that is connected to the S-Video or Video input port. Quick Start Guide
4 RS-232C port	When controlling the projector from a computer, connect it to the computer with an RS-232C cable. This port is for control use and should not normally be used. p.90
5 Remote receiver	Receives signals from the remote control. Quick Start Guide
6 Security slot (K)	The security slot is compatible with the Microsaver Security System manufactured by Kensington. p.38
7 USB port (Type A) (EMP-1815 only)	Connects the memory for compatible digital cameras and USBs, and projects image/movie files and scenarios with the PC Free of EasyMP. p.82
8 LAN port (EMP-1815 only)	When a LAN cable is connected, you can monitor and control the projector over a LAN. p.86
9 USB port (Type B)	Connects the projector to a computer by a USB cable, and the image on the computer is projected (EMP-1815 only). Wireless LAN Quick Connection Guide Use this port also to connect with a computer to use the wireless mouse function. p.28
10 Computer1 input port	For video signals from a computer and <u>component video</u> signals from other video sources.
Audio1 input port	Connect to the audio out port of the computer connected to the Computer1 input port.



Name	Function
Computer2 input port	For video signals from a computer and <u>component video</u> signals from other video sources.
Audio2 input port	Connect to the audio out port of the computer connected to the Computer2 input port.  Quick Start Guide




Control Panel



Name	Function
1 [Power] button	Turns the projector power on or off. Quick Start Guide
2 [Quick Setup] button	Press this button to correct distortion in the projected image so that it perfectly matches the size of the screen. p.17
3 [Source Search] button	Changes to the next input source that is connected to the projector and is sending an image. p.20

Name	Function
4 [Enter] button	If pressed during projection of computer signal images, it automatically adjusts the tracking, synchronization, and position to project the optimum image. When a configuration menu or a help screen is displayed, it accepts and enters the current selection and moves to the next level. p.40
5 [↖] [↗] buttons	Corrects keystone distortion. If pressed when a configuration menu or a help screen is displayed, these buttons select menu items and setting values. Quick Start Guide, p.40
6 [Help] button	Displays and closes the help screen which shows you how to deal with problems if they occur. p.60
7 [Esc] button	Stops the current function. If pressed when a configuration menu is displayed, it moves to the previous menu level. p.40
8 [↕] [↔] buttons	Corrects keystone distortion. If pressed when a configuration menu or a help screen is displayed, these buttons select menu items and setting values. Quick Start Guide, p.40
9 [Menu] button	Displays and closes the configuration menu. p.40
10 Status indicators	The colour of the indicators and whether they are flashing or lit indicates the status of the projector. p.61

Remote Control



Name	Function
1 [E-Zoom]button (⊕) (⊖)	(⊕) Enlarges the image without changing the projection size. (⊖) Reduces parts of images that have been enlarged using the [⊕] button. 🖱️ p.27

Name	Function
2 [Page] button (⬆) (⬇)	When the wireless mouse function or Network presentation* is performed, you can change the PowerPoint file page by pressing the page up/page down buttons. 🖱️ p.28 , EasyMP Operation Guide * EMP-1815 only
3 [A/V Mute] button	Turns the video and audio on or off. 🖱️ p.23
4 [Pointer] button	Press to activate the on screen pointer. 🖱️ p.26
5 [Color Mode] button	Each time the button is pressed, the colour mode changes. 🖱️ p.22
6 [Comp2] button	Changes to an image from the Computer2 input port. 🖱️ p.21
7 [Comp1] button	Changes to an image from the Computer1 input port. 🖱️ p.21
8 [S-Video] button	Changes to an image from the S-Video input port. 🖱️ p.21
9 [Video] button	Changes to images from the Video input port. 🖱️ p.21
10 [EasyMP] button	Changes to the EasyMP image. This feature is not provided on the EMP-1810. (EMP-1815 only)
11 Numeric buttons	Use these buttons when entering a password, projector ID or remote control ID. 🖱️ p.36
12 [Source Search] button	Changes to the next input source that is connected to the projector and is sending an image. 🖱️ p.20



Name	Function
13 [Volume] button (◀) (▶)	(◀) Decreases the volume. (▶) Increases the volume. ☞ Quick Start Guide
14 [Auto] button	If pressed during projection of computer signal images, it automatically adjusts the tracking, synchronization, and position to project the optimum image. ☞ p.41
15 [Help] button	Displays and closes the help screen which shows you how to deal with problems if they occur. ☞ p.60
16 [ID] button	Press this button to check if the projector can be operated by the remote control. Also, press it to set the remote control ID. ☞ p.30
17 [Resize] button	The <u>aspect ratio</u> changes each time the button is pressed. ☞ p.25
18 [Num] button	Use this button when entering a password or screen ID. ☞ p.36
19 [Freeze] button	Images are paused or unpaused. ☞ p.24
20 [Esc] button	Stops the current function. If pressed when a configuration menu is displayed, it moves to the previous level. Acts as a mouse's right button when using the wireless mouse function. ☞ p.40
21 [Enter] button	When a configuration menu or a help screen is displayed, it accepts and enters the current selection and moves to the next level. Acts as a mouse's left button when using the wireless mouse function. ☞ p.40

Name	Function
22 [◉] button	When a configuration menu or help screen is displayed, it selects menu items and setting values. When the wireless mouse function is activated, tilting this button moves the pointer in the direction it is tilted. ☞ p.40
23 [Menu] button	Displays and closes the configuration menu. ☞ p.40
24 [Power] button	Turns the projector power on or off. ☞ Quick Start Guide
25 Remote control light-emitting area	Outputs remote control signals. ☞ Quick Start Guide





Useful Functions

This chapter explains useful functions for giving presentations and so on, and the security functions.

Correcting Distortion in the Projected Image .. 16

- **Automatically Correcting Distortion (Quick Setup).....17**
 - Fitting projected image properly inside the screen 17
- **Aligning the Projected Image to the Screen (Quick Corner)18**

Changing the Projected Image 20

- **Automatically Detect Incoming Signals and Change the Projected Image (Source Search)20**
- **Changing Directly from the Remote Control.....21**

Functions for Enhancing Projection 22

- **Selecting the Projection Quality (Selecting Colour Mode)22**
- **Hiding the Image and Sound Temporarily (A/V Mute) 23**
- **Freezing the Image (Freeze).....24**
- **Changing the Aspect Ratio (Resize)25**
- **Pointer Function (Pointer)26**
- **Enlarging Part of the Image (E-Zoom)27**
- **Using the Remote Control to Operate the Mouse Pointer (Wireless Mouse)28**

Remote Control of Two or More Projectors.....30

- **Setting the Projector ID 30**
- **Setting the Remote Control ID..... 31**

Adjusting Colour for Several Projectors (Multi-Screen Colour Adjustment) 32

- **Summary of Adjustment Procedure..... 32**
- **Image Correction Method 33**

Security Functions 34

- **Managing Users (Password Protect)..... 34**
 - Type of Password Protect 34
 - Setting Password Protect..... 35
 - Entering the Password..... 36
- **Restricting Operation (Operation Lock)..... 37**
- **Anti-Theft Lock 38**
 - Installing the wire lock..... 38

There are four ways to correct distortion in projected images as below.

Automatic correction

- Quick Setup
Press the [Quick Setup] button to fit on the screen at an aspect ratio of 4:3.
- Auto V-Keystone
Tilt the projector vertically to automatically correct distortion in the vertical direction.


Manual correction

- Quick Corner
This allows you to manually correct each of the four corners of the projected image separately.
- H/V-Keystone
This allows you to manually correct distortion in the horizontal and vertical directions independently.

The "Quick Setup", "Quick Corner", "Auto V-Keystone" and "H/V-Keystone" functions project a test pattern onto the screen to correct the projected image, so connection to a computer for preparing the projector is not required.



- *The default setting in the configuration menu is H/V-Keystone.*
- *Select "Settings" - "Keystone" - "Quick Corner" to use Quick Corner for correction.*
- *To change the setting from Quick Corner to H/V-Keystone, press and hold the [Esc] button on the projector or the remote control for about two seconds and display the following screen where you can make the change.*




Reset Quick Corner: Resets the Quick Corner settings.
Switch to H/V-Keystone: Switches the keystone correction method to H/V-Keystone.  p.43

Automatically Correcting Distortion (Quick Setup)

Quick Setup automatically corrects distortion in the projected image, that occurs when the projector is installed at a tilt to the image projection surface, so that the image is projected at an aspect ratio of 4:3. In the case of a screen having an aspect ratio of 4:3, the projected image is corrected so that it fits perfectly in the screen.


Refer to *Quick Start Guide* for how to do the operation. Here is how to fit the projected image within the screen.




The status after correction by Quick Setup is stored in memory even after the projector is turned off. When the projector is installed at a fixed position for use, the projected image does not need to be corrected once Quick Setup has been performed.

Fitting projected image properly inside the screen

When Quick Setup detects a "frame" (detecting 3 or more sides, or top and bottom sides, or 2 adjacent sides) within the projection area, it automatically corrects the image so that it fits within the "frame" at an aspect ratio of 4:3. The "frame" means the borders of the screen, whiteboard or blackboard.



* When the projector is mounted from the ceiling, the image will be corrected so that the bottom edge of the frame, such as the screen, fits inside the projection area.





- *Quick Setup can provide effective correction when the borders of the projection surface stand out clearly, such as a white screen with black borders. When projecting images on a blackboard, for example, you should stick a large-sized sheet of white paper on the blackboard.*
- *Quick Setup can be used to carry out correction within the ranges given below. If the distortion is outside these ranges, correction will not be carried out correctly. Furthermore, if the image is distorted both vertically and horizontally or if the zoom has been adjusted to "W", the correction range will become narrower than the angles given below.*
 - *When correcting to within a border*
Vertically: Approx. 45° Horizontally: Approx. 20°
 - *When projecting onto a surface without a border*
Vertically: Approx. 45° Horizontally: Approx. 15°

Aligning the Projected Image to the Screen (Quick Corner)

This function independently corrects each of the four corners of the projected image to align the image with the screen.


Procedure

To operate this function on the projector's control panel, set "Setting menu" - "Keystone" in the configuration menu to "QuickCorner".




Press one of [↖], [↘], [↙] and [↗] on the projector.


The Quick Corner screen for selecting the four corners is displayed.




Select the corner to be corrected, and press the [Enter] button on the projector or remote control.



- 3 Correct the position of the corner by the [↶], [↷], [↵] and [↸] buttons on the projector or the [⏪] button on the remote control.



If the screen below is displayed during the correction, this indicates that the correction amount limit has been reached.




- 4 To exit the correction, press the [Esc] button on the projector or remote control.




You can change the projected image in the following two ways.

- Changing by Source Search
The projector automatically detects signals being input from connected equipment, and the image being input from the equipment is projected.
- Changing directly
You can use the remote control buttons to change to the target input port.

Using the remote control




Using the control panel



When two or more pieces of equipment are connected, press the [Source Search] button until the target image is projected.

Automatically Detect Incoming Signals and Change the Projected Image (Source Search)

You can project the target image quickly as input ports with no image signal being input are ignored when you change by pressing the [Source Search] button.




* EasyMP changes when using EMP-1815.
Install the wireless LAN unit supplied.

Procedure

When your video equipment is connected, start playback before beginning this operation.



The following screen showing the status of image signals is displayed when only the image that the projector is currently displaying is available, or when no image signal can be found. You can select the input port where the connected equipment you want to use is projecting. If no operation is performed after about 10 seconds, the screen closes.



Changing Directly from the Remote Control


You can change directly to the target image by pressing the following buttons on the remote control.

Remote control

Changes to images from the Computer1 input port.

Changes to images from the S-Video input port.

Changes to the EasyMP image. This feature is not provided on the EMP-1810. (EMP-1815 only)



Changes to images from the Computer2 input port.

Changes to images from the Video input port.


Selecting the Projection Quality (Selecting Colour Mode)

You can easily obtain the optimum image quality simply by selecting the setting that best corresponds to your surroundings when projecting. The brightness of the image varies depending on the mode selected.


Mode	Application
Dynamic	Ideal for use in a bright room. This is the brightest mode, and reproduces shadow tones well.
Presentation 1	Ideal for making presentations using color materials in a bright room.
Presentation 2	Ideal for making presentations using black-and-white materials in a bright room.
Theatre	Ideal for watching films in a dark room. Gives images a natural tone.
Photo	(When computer images are input) Ideal for projecting still pictures, such as photos, in a bright room. The images are vivid and brought into contrast.
Sports	(When component video, S-video, or composite video images are input) Ideal for watching TV programmes in a bright room. The images are vivid and brought to life.
sRGB [®]	Ideal for images that conform to the sRGB colour standard.
Blackboard	Even if you are projecting onto a blackboard (greenboard), this setting gives your images a natural tint, just like when projecting onto a screen.
Customized	Select "Customized" to adjust "R,G,B,C,M,Y" from "Color Adjustment" in the configuration menu. ☞ "Color Adjustment"

Procedure

Remote control



Each time you press the button, the colour mode name is displayed on the screen and the colour mode changes.




If you press the button while the colour mode name is displayed on the screen, it changes to the next colour mode.



The colour mode can also be set using "Color Mode" in the "Image" menu from the configuration menu. ☞ p.41


Hiding the Image and Sound Temporarily (A/V Mute)

You can use this when you want to focus the audience's attention on what you are saying, or if you do not want to show details such as when you are changing between files during presentations from a computer.




Procedure

Remote control



Projector



Each time you press the button, or the A/V mute slide is opened or closed, A/V Mute turns on or off.




- *If you use this function when projecting moving images, the images and sound continue to be played back by the source, and you cannot return to the point where A/V Mute was activated.*
- *You can choose to display black, blue, or logo as the A/V mute display using the "Extended"- "Display"- "A/V Mute" setting from the configuration menu. p.44*
- *When the A/V mute slide is closed and A/V mute begins, the power supply can be set to automatically turn off after about 30 minutes by setting "Extended" - "Sleep Mode" from the configuration menu. p.45*

Freezing the Image (Freeze)

When the moving image on the screen is frozen, the image continues to project, so you can project a moving image one frame at a time like a still photo. Also, you can perform operations such as changing between files during presentations from a computer without projecting any images if the freeze function is activated beforehand.

Procedure

Remote control




Each time you press the button, Freeze turns on or off.



- **Audio does not stop.**
- **The image source continues to playback the moving images even while the screen is frozen, and so it is not possible to resume projection from the point where it was paused.**
- **If the [Freeze] button is pressed while the configuration menu or a help screen is displayed, the menu or help screen being displayed is cleared.**
- **Freeze still works while E-Zoom is being used.**


Changing the Aspect Ratio» (Resize)

When video equipment is connected, images that have been recorded in digital video or onto DVDs can be viewed in 16:9 wide-screen format. You can change the aspect ratio for images in squeeze mode» as follows.




Procedure

Remote control



Each time you press the button, the aspect name is displayed on the screen and the aspect changes.




If you press the button while the aspect name is displayed on the screen, it changes to the next aspect mode.



The colour mode can also be set using "Resize" in the "Signal" menu from the configuration menu. [p.42](#)

Pointer Function (Pointer)


This allows you to move a pointer icon on the projected image, and helps you draw attention to the area you are talking about.



Procedure

1 Display the pointer.


Remote control



Each time you press the button, the pointer appears or disappears.

2 Move the pointer icon.


Remote control



You can choose from three different kinds of pointer icon () in "Settings" - "Pointer Shape" from the configuration menu. p.43


Enlarging Part of the Image (E-Zoom)

This is useful when you want to expand images to see them in greater detail, such as graphs and tables.




Procedure


1 Start E-Zoom.



2 Move the cross to the area of the image that you want to enlarge.



3 Enlarge.



Each time the button is pressed, the area is expanded. You can expand quickly by holding the button down. You can reduce the enlarged image by pressing the [Q] button. Press the [Esc] button to cancel.




- *The enlargement ratio appears on the screen. The selected area can be enlarged to between 1 to 4 times in 25 incremental steps.*
- *Tilt the [Q] button to scroll the image.*

Using the Remote Control to Operate the Mouse Pointer (Wireless Mouse)

Connect the USB port of a computer and the USB port (TypeB) on the rear of the projector with a commercially available USB cable*. If the "Extended" - "USB TypeB" setting in the configuration menu is set to "Wireless Mouse", you can use the projector's remote control like a wireless mouse to control the computer's mouse pointer. 🖱️ p.45

Computer
Windows 98/98SE/2000/Me/XP Home Edition/XP Professional
Macintosh (OS 8.6–9.2/10.1–10.4)


* Supplied with the EMP-1815.




- It may not be possible to use the mouse function under some versions of both the Windows and Macintosh operating systems.
- Some computer settings may have to be changed in order for the mouse function to be used. Consult the documentation for the computer for further details.

Once the connection has been made, the mouse pointer can be operated as follows.

Moving the mouse pointer




Mouse clicks



Double-click: Press twice in rapid succession.

Drag and drop




1. Hold down the [Enter] button and tilt and drag the [⬇️] button.
2. Release the [Enter] button to drop at the desired location.

This is useful for displaying the previous or next slide in a PowerPoint slideshow.

To previous slide

To next slide





- *If the mouse button settings are set to reverse on the computer, the operation of the remote control buttons will also be reversed.*
- *The wireless mouse function cannot be used while the following functions are being used.*
 - *While a configuration menu is being displayed*
 - *While a help menu is being displayed*
 - *While the E-Zoom function is being used*
 - *While a user's logo is being captured*
 - *Pointer function*
 - *While adjusting sound volume*



When using two or more projectors, you can operate only the projector having a specific ID if you register the same ID to both the projector and the remote control.

Set the projector ID in the configuration menu. Set the remote control ID by the [ID] button and numeric buttons on the remote control.



- *The default projector ID is "Off" and default remote control ID is "0".*
- *When the projector is turned off and turned on again, the remote control ID returns to its default.*


Setting the Projector ID

Procedure



1

Press the [Menu] button and select "Extended" - "Projector ID" from the configuration menu.
☞ "Using the Configuration Menu" p.40

Using the remote control



Using the control panel



[Esc] / [Enter] : Return [↔] : Select [Menu] : Exit

Check the buttons you can use and the operations they perform in the guide under the menu.

2

Choose the ID you want to set and press the [Enter] button.



3 Press the [Menu] button to close the configuration menu.

When this setting is completed, only operations from a remote control having a matching ID or whose ID is set to "0" are accepted.

Setting the Remote Control ID

You need to set the remote control ID every time you turn on the projector.

Procedure

Point the remote control at the remote receiver on the projector you want to operate.

- 1 Press the [ID] button.
- 2 Press the numeric button of the same number as the ID of the projector you want to operate.

You can operate only the projector with the specified ID number.



Checking if remote control operation is possible

You can check whether or not remote control operation is possible on the projector to be operated with the following procedure.

Press the [ID] button on the remote control pointing at the remote receiver of the projector to be operated.

Projector ID : 3
Remote Control: On

When remote control operations are enabled:





When several projectors are lined up and projecting images, you can adjust the brightness and colour tone of each projector's image with multi-screen colour adjustment so that the colours of images from each projector match closely.
In some cases the brightness and colour tone may not match completely even after adjustment.

Attention

If you use two or more projectors arranged side by side, the exhaust from the adjacent projector might cause a high temperature warning. So, pay attention to the following points:

- *Project the image so that it is larger than 50".*
- *Leave at least 65 cm of space between each projector.*
- *Do not install projectors at locations that get hot, such as in the direct sunlight or near air conditioner or heater exhaust ports.*

- Adjusting brightness
Adjust each image by levels 1 to 5 so that they are all equal.
- Adjusting colour
Adjust each image by levels 1 to 5 so that the colours match using "Color Correct. (G/R)" and "Color Correct. (B/Y)".

Summary of Adjustment Procedure

Make adjustments according to the following procedure.

1. Setting the projector ID

Set one projector ID to each projector.  p.30

2. Setting the remote control ID

If you set the same ID as the projector you want to operate on the remote control, too, you can operate the projector with the same ID.

 p.31

3. Making image corrections

After the projectors are setup, you can adjust the image for each projector.

Using Image Correction you can adjust from black to white in five stages called levels 1 to 5, and in each level 1 to 5 you can adjust the following two points.

Image Correction Method

After setting up the projectors, adjust the brightness and tone for each image.

Procedure

- 1** Press the [Menu] button and select "Extended" - "Multi-screen" from the configuration menu.
☞ "Using the Configuration Menu" p.40
- 2** Select the level to be adjusted in "Adjustment Level".
 - Each time a level is selected, the pattern of the level selected is displayed.
 - You can start adjusting from any level, usually you can make it darker or lighter by adjusting 1 to 5 or 5 to 1.
- 3** Adjust the brightness with "Brightness Correct.".
 - When you select level 5, it adjusts to the darkest image from several projectors.
 - When you select level 1, it adjusts to the brightest image from several projectors.
 - When you select level 2 to 4, it adjusts to the mid-range brightness image from several projectors.
 - Each time the [Enter] button is pressed the image displayed changes between the pattern display and the actual image, and you can check the adjustment results and make corrections in the actual image.
- 4** Adjusting "Color Correct. (G/R)" and "Color Correct. (B/Y)".

Each time the [Enter] button is pressed the image displayed changes between the pattern display and the actual image, and you can check the adjustment results and make corrections in the actual image.
- 5** Repeat procedures 2 to 4 until adjustments are finished.
- 6** When all adjustments are finished, press the [Menu] button to close the configuration menu.

The projector has the following enhanced security functions.

- **Password protect**
You can limit who can use the projector.
- **Operation Lock**
You can prevent people changing the settings on the projector without permission.
- **Anti-Theft Lock**
The projector is equipped with various types of anti-theft security devices.

Managing Users (Password Protect)

When Password Protect is activated, people who do not know the password cannot use the projector to project images even if the projector power is on. Furthermore, the user's logo that is displayed when you turn on the projector cannot be changed. This acts as an anti-theft device as the projector cannot be used even if it is stolen. At the time of purchase, Password Protect is not activated.

■ Type of Password Protect

The following three kinds of password protect settings can be made according to how the projector is being used.

1. "Power On Protect"

When "Power On Protect" is "On", the password must be entered whenever the projector is turned on after it has been disconnected from the power supply it was connected to the last time the password was entered.

If the correct password is not entered, projection does not start.

2. "User's Logo Protect"

When "User's Logo Protect" is set to "On" the user's logo cannot be changed and the following setting changes for user's logo are prohibited.

- Capturing a user's logo
- Settings for "Display Background", "Startup Screen", and "A/V Mute" from "Display" in the configuration menu.

3. "Network Protect" (EMP-1815 only)

When "Network Protect" is set to "On" setting changes for "Network" in the configuration menu are prohibited.

■ Setting Password Protect


Use the following procedure to set Password Protect.

Procedure

- 1 Hold down the [Freeze] button for about five seconds.

The password protect setting menu is displayed.

Remote control



- *If Password Protect is already activated, you must enter the password.
If the password is entered correctly, the password protect setting menu is displayed.  "Entering the Password" p.36*
- *When the password is set, stick the password protect sticker in a visible position on the projector as a further theft deterrent.*

- 2 Turn on "Power On Protect".

- (1) Select "Power On Protect", and then press the [Enter] button.
- (2) Select "On", and then press the [Enter] button.
- (3) Press the [Esc] button.

- 3 Turn on "User's Logo Protect".

- (1) Select "User's Logo Protect", and then press the [Enter] button.
- (2) Select "On", and then press the [Enter] button.
- (3) Press the [Esc] button.


- 4 Turn on "Network Protect".

- (1) Select "Network Protect", and then press the [Enter] button.
- (2) Select "On", and then press the [Enter] button.
- (3) Press the [Esc] button.



5 Set the password.

- (1) Select "Password", and then press the [Enter] button.
- (2) The message "Change the password?" is displayed, select "Yes" and then press the [Enter] button. The default setting for the password is "0000". Change this to your own desired password. If you select "No", the screen shown in step 1 is displayed again.
- (3) While holding down the [Num] button, enter a four digit number using the numeric buttons. The number entered is displayed as "* * * *". When you enter the fourth digit, the confirmation screen is displayed.



- (4) Re-enter the password.
The message "Password accepted." is displayed.
If you enter the password incorrectly, a message is displayed prompting you to re-enter the password.

Entering the Password

When the password entry screen is displayed, enter the password using the numeric buttons on the remote control.

Procedure

While holding down the [Num] button, enter the password by pressing the numeric buttons.

When you enter the correct password, projection begins.

Attention

- *If an incorrect password is entered three times in succession, the message "The projector's operation will be locked." is displayed for about five minutes, and then the projector switches to standby mode. If this happens, disconnect the power plug from the electrical outlet and then reinsert it and turn the projector's power back on. The projector displays the password entry screen again so that you can enter the correct password.*
- *If you have forgotten the password, make a note of the "Request Code: xxxxx" number that appears on the screen and contact the nearest address provided in the World-Wide Warranty Terms.*
👉 **Inquiries**
- *If you continue to repeat the above operation and input the wrong password thirty times in succession, the following message is displayed and the projector does not accept any more password entries. "The projector's operation will be locked. Contact Epson as described in your documentation."* 👉 **Inquiries**

Restricting Operation (Operation Lock)

Do one of the following to lock the operation buttons on the control panel.


- Full lock
All of the buttons on the control panel are locked. You cannot perform any operations from the control panel, including turning the power on or off.
- Partial lock
All of the buttons on the control panel, except for the [Power] button, are locked.

This is useful at events or shows when you want to deactivate all buttons and only project, or at schools when you want to limit button operation. The projector can still be operated using the remote control.



Procedure

- 1 Press the [Menu] button and select "Settings" - "Operation Lock".  "Using the Configuration Menu" p.40

Using the remote control




Using the control panel



Check the buttons you can use and the operations they perform in the guide under the menu.

- 2 Select either "Full Lock" or "Partial Lock".



- 3 Select "Yes" when the confirmation message is displayed.

The control panel buttons are locked according to the setting you chose.



You can release the control panel lock by one of the following two methods.

- From the remote control, select "Off" in "Settings" - "Operation Lock" from the configuration menu.
- Press and hold down the [Enter] button on the control panel for about seven seconds, a message is displayed and the lock is released.

Anti-Theft Lock

As the projector is often setup on ceiling mounts and left in rooms unattended, it is possible that someone may try and take the projector, so the projector includes the following security devices.

- **Security slot**


The security slot is compatible with the Microsaver Security System manufactured by Kensington. You can find details about the Microsaver Security System on the Kensington homepage <http://www.kensington.com/>.

- **Security cable installation point**

A commercially available theft-prevention wire lock can be passed through the installation point to secure the projector to a desk or pillar.

- **Installing the wire lock**

Pass an anti-theft wire lock through the installation point. See the documentation supplied with the wire lock for locking instructions.




Configuration Menu


This chapter explains how to use the configuration menu and its functions.

Using the Configuration Menu	40
List of Functions	41
• Image Menu	41
• Signal Menu	42
• Settings Menu	43
• Extended Menu	44
• Network Menu (EMP-1815 Only)	46
Operations in the Network Menu	47
Soft keyboard operations	47
Basic Menu	48
Wireless LAN Menu	49
Security Menu	50
Wired LAN Menu	54
Mail Menu	55
SNMP Menu	56
• Info Menu (Display Only).....	57
• Reset Menu	58




1 Selecting from the top menu



2 Selecting from the sub menu



3 Changing the selected item



Select the setting to change



Image Menu

Items that can be set vary depending on the image signal currently being projected as shown in the following screen shots. Setting details are saved for each image signal.

Computer image



Component video/Composite video/S-video




Sub Menu	Function
Color Mode	You can select the quality of the image to suit your surroundings. p.22
Brightness	You can adjust the image brightness.
Contrast ▶▶	You can adjust the difference between light and shade in the images.
Color Saturation	You can adjust the colour saturation for the images.
Tint	(Adjustment is only possible when NTSC signals are being input if you use composite video/S-video.) You can adjust the image tint.
Sharpness	You can adjust the image sharpness.
Abs. Color Temp.	You can adjust the overall tint of the image. You can adjust tints in 10 stages from 5000 K to 10000 K. When a high value is selected the image becomes tinged with blue, when a low value is selected the image becomes tinged with red. (This item cannot be selected if " <u>sRGB</u> ▶▶" is selected as the "Color Mode" setting in the "Image" menu.)
Color Adjustment	You can make adjustments by choosing one of the following Red, Green, Blue: You can adjust the saturation of each colour individually. (This item cannot be selected if values for " <u>sRGB</u> ▶▶" or "Customized" are selected from "Image" - "Color Mode".) R, G, B, C, M, Y: You can adjust the strength of each colour R (red), G (green), B (blue), C (cyan), M (magenta), Y (yellow) individually. (This item can only be selected when "Customized" is selected from "Image" - "Color Mode".)
Reset	You can reset all adjustment values for the "Image" menu functions to their default settings. To return all menu items to their default settings, see p.58


Signal Menu

Items that can be set vary depending on the image signal currently being projected as shown in the following screen shots. Setting details are saved for each image signal.


Computer image



Component video




Composite video/S-video




Sub Menu	Function
Auto Setup	You can select whether, when the input signal changes, the image is automatically adjusted to the optimum state (On) or not (Off).  p.67
Tracking	You can adjust computer images when vertical stripes appear in the images.  p.67
Sync.	You can adjust computer images when flickering, fuzziness, or interference appear in the images.  p.67
Position	You can adjust the display position up, down, left, and right when a part of the image is missing so that all of the image is projected.
Progressive	(Component video can only be adjusted when 525i/625i signals are being input) Off: IP conversion is carried out for each field in the screen. This is ideal for viewing images with a large amount of movement. On: <u>interlace</u> (i) signals are converted into <u>progressive</u> (p) signals. This is ideal for viewing still images.
Computer1 Input	You can select the input signal from the Computer1 input port or Computer2 input port. If set to "Auto" the input signal is set automatically according to the connected equipment.
Computer2 Input	If colours do not appear correctly when set to "Auto", select the appropriate signal according to the connected equipment.
Video Signal	If set to "Auto", video signals are recognized automatically. If interference appears in the image or a problem occurs such as no image is being projected when set to "Auto", select the appropriate signal according to the connected equipment.
Resize	You can set the <u>aspect ratio</u> for projected images.  p.25
Reset	You can reset all adjustment values on the "Signal" menu to their default settings, except for "Computer1 Input" and "Computer2 Input". To return all menu items to their default settings, see  p.58

Settings Menu

For EMP-1815




For EMP-1810




Sub Menu	Function
Keystone	<p>You can correct keystone distortion in images.</p> <p>H/V Keystone : Corrects horizontal and vertical keystone distortion. Select one of "V-Keystone", "H-Keystone" and "Auto V-Keystone". If "Auto V-Keystone" is selected and set to "On", vertical tilt of the projector is detected and automatically corrected. When set to "Off", correct manually by the [↖], [↗], [↘] and [↙] buttons on the control panel.</p> <p>"V-Keystone" and "H-Keystone" are for performing correction manually.</p> <p>Quick Corner : Selects and corrects the four corners of the projected image.  p.18</p>
Operation Lock	<p>You can use this to restrict operation of the projector's control panel.  p.37</p>
Pointer Shape	<p>You can select the shape of the pointer.  p.26</p> <p>Pointer 1:  Pointer 2:  Pointer 3: </p>
Brightness Control	<p>You can set the lamp brightness to one of two settings.</p> <p>Select "Low" if the images being projected are too bright such as when projecting images in a dark room or onto a small screen. When "Low" is selected, the amount of electricity consumed and the lamp's operating life are changed as follows, and fan rotation noise during projection is reduced. Electrical consumption: about a 40 W decrease, lamp life: about 1.5 times longer</p>
Volume	<p>You can adjust the volume.</p>
Remote Receiver	<p>You can limit the reception of the operation signal from the remote control.</p> <p>When you want to prohibit operation by remote control, or if the remote receiver has a fluorescent light too close to it , you can make settings to deactivate the remote receiver you do not want used or that is experiencing interference.</p>
Test Pattern	<p>When the projector is setup, a test pattern is displayed so that you can adjust the projection without connecting other equipment. While the test pattern is displayed, zoom and focus adjustments, and keystone correction, excluding Quick Setup, can be performed.</p> <p>To cancel the test pattern, press the [Esc] button on the remote control or the control panel.</p>
Reset	<p>You can reset all adjustment values for the "Settings" menu to their default settings.</p> <p>To return all menu items to their default settings, see  p.58</p>

Extended Menu

For EMP-1815



For EMP-1810



Sub Menu	Function
Display	<p>You can make settings related to the projector's display.</p> <p>Messages: You can set whether to display (On) or not display (Off) the source name when you change the input source, the colour mode name when you change the colour mode, a message when no image signal is input, and so on.</p> <p>Display Background*: You can set the screen status for when no image signal is available to "Black", "Blue", or "Logo".</p> <p>Startup Screen*: You can set if the startup screen (the image projected when starting the projector) is displayed or not.</p> <p>A/V Mute*: You can set the screen displayed during A/V Mute as "Black", "Blue", or "Logo".</p>
User's Logo*	You can change the user's logo that is displayed as a background and displayed during A/V Mute.  p.79
Projection	<p>You can set from the following according to the way the projector is setup.  p.72</p> <p>"Front" "Front/Ceiling" "Rear" "Rear/Ceiling"</p> <p>You can change the setting as follows by pressing down the [A/V Mute] button on the remote control for about five seconds.</p> <p>"Front" ↔ "Front/Ceiling"</p> <p>"Rear" ↔ "Rear/Ceiling"</p>

* When "User's Logo Protect" is set to "On" in "Password Protect", settings concerning user's logo cannot be changed. You can make changes after setting "User's Logo Protect" to "Off".  [p.35](#)



Sub Menu	Function
Operation	<p>Direct Power On: You can set whether Direct Power On is enabled (On) or disabled (Off). When it is set to "On" and the projector power cable is connected to an electrical outlet, be aware that sudden surges of electricity when power comes back on after a power outage may cause the projector to turn on automatically.</p> <p>Sleep Mode: You can set whether projection stops automatically (On) or not (Off) when no operations are carried out for about 30 minutes while no image signal is being input, or when about 30 minutes have elapsed since the A/V mute slide is closed. Sleep mode is set to (Off) at the time of purchase, so do not forget to turn off the power after projecting.</p> <p>High Altitude Mode: Set to "On" when using the projector above an altitude of 1500 m.</p>
Standby Mode	<p>You can use network monitoring and control functions while the projector is in standby mode when this is set to "Network On". You can use SNMP to monitor and control the status of the projector over the network, or by using the "EMP Monitor" software supplied with this product.</p>
USB Type B (EMP-1815 only)	<p>Set to "USB Display" when the projector and a computer are connected by a USB cable and computer images are projected. Wireless LAN Quick Connection Guide</p> <p>Set to "Wireless Mouse" when the mouse pointer is to be operated by the remote control. p.28</p>
Projector ID	<p>Set the ID within the range "1" to "9". "Off" indicates that no ID is set. p.30</p>
Multi-screen	<p>You can adjust the hue and brightness of each projected image when multiple projectors are lined up and projecting. p.32</p> <p>Adjustment Level: You can adjust from black to white in five stages called levels 1 to 5, and in each level 1 to 5 you can adjust "Brightness Correct." and "Color Correct".</p> <p>Brightness Correct.: Corrects the difference in the brightness of each product.</p> <p>Color Correct. (G/R) / Color Correct. (B/Y): You can correct the difference in the colour of each product.</p>
Language	<p>You can set the language for message displays.</p>
Reset	<p>You can reset "Display^{*1}" and "Operation^{*2}", in the "Extended" menu to their default settings. To return all menu items to their default settings, see p.58</p>


*1 When "User's Logo Protect" is set to "On" in "Password Protect", settings relating to user's logo cannot be changed. You can make changes after setting "User's Logo Protect" to "Off". [p.35](#)

*2 Except for "High Altitude Mode".



Network Menu (EMP-1815 Only)

When "Network Protect" is set to "On" in "Password Protect", a message is displayed and the settings cannot be changed. You can make changes after setting "Network Protect" to "Off".  [p.35](#)



Sub Menu	Function
To Network Configuration	The display changes to the Network menu so that you can make network settings. The following menus are available for network settings: "Basic", "Wireless LAN menu", "Security Menu", "Wired LAN Menu", "Mail notification menu", "SNMP menu", and "Complete menu". Once the required items are set up, the projector can be connected to a computer over the network.

 *The projector's functions can be set and the projector can be controlled from a computer by using the Web browser on a computer connected to the projector on a network.  [EasyMP Operation Guide](#)*
Settings that involve input of text from Web control also can be performed easily as a keyboard can be used to input the settings.

Operations in the Network Menu

Selection from the top menu, selection of submenus, and changing of selected items are the same as operations in the configuration menu.




However, to exit, the following operation is needed. Go to "Complete menu", and select one of "Yes", "No" or "Cancel".



- Yes:** Saves the settings and exits the network menu.
- No:** Exits the network menu without saving the settings.
- Cancel:** Display of the network menu is continued.

The screen returns to the configuration menu.



Soft keyboard operations

The network menu contains items that require input of alphanumeric during setup. In this case, the following software keyboard is displayed. Move the cursor to the desired key by the [⊙] button on the remote control or [△], [▽], [◀] or [▶] on the projector, and press the [Enter] button to enter the alphanumeric. After inputting, press [Finish] on the keyboard to confirm your input. Press [Cancel] on the keyboard to cancel your input.



Each time this key is selected, it sets and changes between upper case and lower case letters.

Each time this key is selected, it sets and changes the symbol keys for the section enclosed by the frame.

Basic Menu




Sub Menu	Function
Projector name	You can enter a name for the projector. When connected to a network, this name is used to identify the projector. The initial value is "EMPxxxxxx" (where xxxxxx are the last six digits of the MAC Address). You can enter up to 16 single-byte alphanumeric characters.
PJLink Password	Enter a password to use when you access the projector using compatible PJLink software.  p.91 You can enter up to 32 single-byte alphanumeric characters.
Web Control Password	Enter a password to use when making settings and controlling the projector using Web control.* You can enter up to 8 single-byte alphanumeric characters. Web control is a computer function that allows you to set up and control the projector by using the Web browser on a computer connected on a network.  EMP Monitor Operation Guide
Projector keyword	When projector keyword is set to "ON", you have to enter the keyword when you try to connect to a network. When using this function, you can prevent presentations from being interrupted by unscheduled connections from the computer. Normally this should be set to "ON".

■ Wireless LAN Menu



Sub Menu	Function
Connection mode	Sets the connection mode. Set "Quick" to establish a quick wireless connection in a 1:1 configuration. Set "Advanced" to connect to the network system via an access point.
Antenna level	Displays the wireless LAN wave strength.
Wireless LAN system	Sets the wireless LAN system.
<u>ESSID</u> »	Enter an ESSID. When an ESSID is provided for the wireless LAN system in which the projector participates, enter the ESSID. The initial value is EPSON. You can enter up to 32 single-byte alphanumeric characters.
<u>DHCP</u> »	You can set whether to use DHCP (On) or not (Off). If this is set to "On" you cannot set any more addresses.
<u>IP address</u> »	You can input the IP address assigned to the projector. You can enter a number from 0 to 255 in each field of the address. However, the following IP addresses cannot be used. 0.0.0.0, 127.x.x.x, 224.0.0.0 to 255.255.255.255 (where x is a number from 0 to 255)
<u>Subnet mask</u> »	You can input the subnet mask for the projector. You can enter a number from 0 to 255 in each field of the address. However, the following subnet masks cannot be used. 0.0.0.0, 255.255.255.255
<u>Gateway address</u> »	You can input the IP address for the gateway for the projector. You can enter a number from 0 to 255 in each field of the address. However, the following gateway addresses cannot be used. 0.0.0.0, 127.x.x.x, 224.0.0.0 to 255.255.255.255 (where x is a number from 0 to 255)

■ Security Menu



Sub Menu	Function
Security	Select the security type from the items that are displayed. EasyMP Operation Guide When setting up security, follow the instructions from the administrator of the network system you are about to access.

Type of security

When connecting and communicating in wireless LAN mode, you can select one of the following encryption and authentication methods.

- WEP
 - Data is encrypted with a code key (WEP key)
 - This mechanism prevents communication unless the encrypted keys for the access point and the projector match.
- WPA
 - This is an encryption standard that improves security which is a weak point of WEP. Although there are several kinds of WPA encryption methods, this projector uses "TKIP". TKIP uses PSK to automatically update the encryption key at regular fixed intervals, which makes it harder to break compared to WEP which uses a constant encryption key.
 - WPA also includes user authentication functions. WPA authentication provides two methods: using an authentication server, or authenticating between a computer and an access point without a server. This projector supports the latter method, without a server.
- EAP
 - EAP is a protocol used for communication between clients and authentication servers. These are several protocols, such as EAP-TLS which uses electronic certification for user authentication, LEAP which uses user ID and password, and EAP-TTLS.




System	Authentication	Notes
EAP-TLS	Electronic certification, CA certification	
EAP-TTLS	User ID, Password	Funk Software Company
PEAP/MS-CHAPv2	User ID, Password	Microsoft Corporation
PEAP/EAP-GTC	User ID, Password	Cisco Systems Company
LEAP	User ID, Password	Cisco Systems Company






- *For setting details, follow the directions from the network administrator of your network.*
- *If using EAP, you need to make settings at the projector that match the authentication server settings. Check with your network administrator for details on RADIUS settings.*
- *Register an electronic certificate and a CA certificate to the projector. Only one set of an electronic certificate and a CA certificate can be registered to the projector. These certificates are used with EAP-TLS.*





When WEP is selected

Sub Menu	Function
WEP encryption	You can set the encryption for WEP encoding. 128 bit : Uses 128 (104) bit encoding 64 bit : Uses 64 (40) bit encoding
Format	You can set the input method for the WEP encrypted key. ASCII : Input text. The method of inputting the encrypted WEP with text differs depending on the access point. Check with the network administrator for the network in which the projector participates, and then set to "ASCII". HEX : Input in hexadecimal.
Key ID	Selects the WEP encryption ID key.
Encryption key 1/ Encryption key 2/ Encryption key 3/ Encryption key 4	You can enter the key used for WEP encryption. Enter the key in single-byte characters following instructions from the network administrator for the network in which the projector participates. The type of character and the number that can be entered differ according to the "WEP Encryption" and "Format" settings. If the number of characters you enter is shorter than the required character length, no character is encrypted. If the number of characters you enter is longer than the required character length, characters that exceed the permitted number are not encrypted. "128 bit" - when "ASCII": Single-byte alphanumerics, up to 13 characters max. "64 bit" - when "ASCII": Single-byte alphanumerics, up to 5 characters max. "128 bit" - when "HEX": 0 to 9 and A to F, up to 26 characters "64 bit" - when "HEX": 0 to 9 and A to F, up to 10 characters



When WPA-PSK (TKIP) or WPA2-PSK (AES) are selected

Sub Menu	Function
PSK (Encryption key)	You can enter a PreSharedKey (encrypted key) in single-byte alphanumeric characters. Enter at least 8 and up to 64 characters. When the PreSharedKey is entered and the [Enter] button is pressed, the value is set and displayed as an asterisk (*). You cannot enter more than 32 characters on the option settings menu. When setting from Web Control, you can enter more than 32 characters. EasyMP Operation Guide

When EAP-TLS is selected

Sub Menu	Function
Issued to/Issued by/Validity period	Information in the certificate is displayed. You cannot enter.

When EAP-TTLS/MD5, EAP-TTLS/MS-CHAPv2, PEAP/MS-CHAPv2, PEAP/GTC, LEAP, EAP-Fast/MS-CHAPv2 or EAP-FAST/GTC are selected

Sub Menu	Function
User name	You can enter a user name to be used for authentication in single-byte alphanumeric characters (no spaces). You can enter up to 64 characters. You cannot enter more than 32 characters on the configuration menu. When setting from Web Control, you can enter more than 32 characters. EasyMP Operation Guide
Password	You can enter an authentication password in single-byte alphanumeric characters. You can enter up to 64 characters. When the password is entered and the [Enter] button is pressed, the value is set and displayed as an asterisk (*). You cannot enter more than 32 characters on the configuration menu. When setting from Web Control, you can enter more than 32 characters. EasyMP Operation Guide


■ Wired LAN Menu



Sub Menu	Function
<u>DHCP</u> »	You can set whether to use DHCP (On) or not (Off). If this is set to "On" you cannot set any more addresses.
<u>IP address</u> »	You can input the IP address assigned to the projector. You can enter a number from 0 to 255 in each field of the address. However, the following IP addresses cannot be used. 0.0.0.0, 127.x.x.x, 224.0.0.0 to 255.255.255.255 (where x is a number from 0 to 255)
<u>Subnet mask</u> »	You can input the subnet mask for the projector. You can input a number from 0 to 255 in each field of the address. However, the following subnet masks cannot be used. 0.0.0.0, 255.255.255.255
<u>Gateway address</u> »	You can input the IP address for the gateway for the projector. You can enter a number from 0 to 255 in each field of the address. However, the following gateway addresses cannot be used. 0.0.0.0, 127.x.x.x, 224.0.0.0 to 255.255.255.255 (where x is a number from 0 to 255)

■ Mail Menu

When this is set, if the projector enters an abnormal/warning state, you are notified by e-mail.



Sub Menu	Function
Mail Notification	You can set whether to be notified by mail (On) or not (Off).
SMTP server	You can input the <u>IP address</u> for the SMTP server for the projector. You can input a number from 0 to 255 in each field of the address. However, the following IP addresses cannot be used. 127.x.x.x, 224.0.0.0 to 255.255.255.255 (where x is a number from 0 to 255)
Port Number	You can input the port number for the SMTP server. The initial value is 25. You can input numbers between 1 to 65535.
Email Address 1/ Email Address 2/ Email Address 3	You can input the e-mail address of the destination to send the notification mail to. You can register up to three destinations. You can enter up to 32 single-byte alphanumeric characters for the mail addresses.
Setting a Notification Event	You can select the abnormalities or warnings to be notified about by mail. When the selected abnormality or warning occurs in the projector, a mail is sent to the specified "Destination address" notifying that an abnormality or warning has occurred. You can select multiple items from the displayed items.

■ SNMP Menu

You can set the SNMP. To use SNMP to monitor the projector, you need to install the SNMP manager program on your computer. SNMP should be managed by a network administrator.




Sub Menu	Function
SNMP trap IP address 1 / SNMP trap IP address 2	<p>You can register up to two for the SNMP trap notification destination.</p> <p>The IP address registered in "Trap IP Address 2" is used when the IP address in "Trap IP Address 1" cannot be accessed.</p> <p>You can enter a number from 0 to 255 in each field of the address.</p> <p>However, the following IP addresses cannot be used.</p> <p>127.x.x.x, 224.0.0.0 to 255.255.255.255 (where x is a number from 0 to 255)</p>


Info Menu (Display Only)

Lets you check the status of the image signals being projected and the status of the projector. Items displayed vary depending on the image signal currently being projected as shown in the following screen shots.

Computer image/Component video»



Composite video»/S-video»



EasyMP



Sub Menu	Function
Lamp Hours	You can display the cumulative lamp operating time* . When it reaches the lamp warning time, the characters are displayed in yellow.
Source	You can display the input port name for the connected equipment currently being projected.
Input Signal	You can display the content of "Computer1" or "Computer2" set in the "Signal" menu according to the "Source".
Resolution	You can display the input resolution.
Video Signal	You can display the content of "Video Signal" set in the "Signal" menu.
Refresh Rate»	You can display the refresh rate.
Sync» Info	You can display the image signal information. This information may be needed if service is required.
Status	This is information about errors that have occurred on the projector. This information may be needed if service is required.

* The cumulative use time is displayed as "0H" for the first 10 hours.

Reset Menu



Sub Menu	Function
Reset All	You can reset all items in all menus to their default settings. The following items are not reset to their defaults: "Computer1 Input", "Computer2 Input", "User's Logo", "Multi-screen", all items for "Network" menus, "Lamp Hours", and "Language".
Reset Lamp Hours	You can clear the cumulative lamp hours use time, and return it to "0H". Reset when you replace the lamp.



Troubleshooting

This chapter describes how to identify problems and what to do if a problem is found.


Using the Help	60
Problem Solving	61
• Reading the Indicators	61
⏻ Power indicator lights red	62
☀ · 📢 Indicator is lit or flashing orange.....	63
• When the Indicators Provide No Help	64
Problems relating to images	65
Problems when projection starts.....	69
Other problems	69

If a problem occurs with the projector, Help uses on-screen displays to assist you in solving the problem.


Procedure

- 1 Press the [Help] button.**
The help screen is displayed.


Using the remote control




Using the control panel




- 2 Select a menu item.**



Using the remote control




Using the control panel




- 3 Confirm the selection.**


Using the remote control



Using the control panel



Questions and solutions are displayed as shown on the screen below.
Press the [Help] button to exit Help.




If Help does not provide a solution to the problem, refer to "Problem Solving" (p.61).

If you are having a problem with the projector, first check the projector's indicators and refer to "Reading the Indicators" below.
If the indicators do not show clearly what the problem might be, refer to "When the Indicators Provide No Help".  [p.64](#)

Reading the Indicators

The projector is provided with the following three indicators that indicate the operating status of the projector.



Refer to the following table to see what the indicators mean and how to remedy problems that they indicate.

If all indicators are off, check that the power cable is connected correctly and that the power is being supplied normally.

Sometimes, when the power cable is unplugged, the  indicator remains lit for a short period, this is not a fault.

■ Power indicator lights red **Abnormal**

: Lit : Flashing: : Off

Status	Cause	Remedy or Status
<p>Red Red Red</p> 	Internal Error	Stop using the projector, disconnect the power cable from the electrical outlet, and contact your local dealer or the nearest address provided in the <i>World-Wide Warranty Terms</i> . Inquiries
<p>Red Red</p> 	Fan Error Sensor Error	Stop using the projector, disconnect the power cable from the electrical outlet, and contact your local dealer or the nearest address provided in the <i>World-Wide Warranty Terms</i> . Inquiries
<p>Red Red</p> 	High Temp Error (overheating)	<p>The lamp turns off automatically and projection stops. Wait for about five minutes. After about five minutes the projector switches to standby mode, so check the following two points.</p> <ul style="list-style-type: none"> • Check that the air filter and air exhaust vent are clear, and that the projector is not positioned against a wall. • If the air filter is clogged, clean or replace it. p.73, 78 <p>If the error continues after checking the points above, stop using the projector, disconnect the power cable from the electrical outlet, and contact your local dealer or the nearest address provided in the <i>World-Wide Warranty Terms</i>. Inquiries</p> <p>When using at an altitude of 1500 m or more, set "High Altitude Mode" to "On". p.45</p>
<p>Red Red</p> 	Lamp Error Lamp Failure Lamp Cover Open	<p>Check the following two points.</p> <ul style="list-style-type: none"> • Take out the lamp and check if it is cracked. p.75 • Clean the air filter. p.73 <p>If it is not cracked → Re-fit the lamp and turn on the power. If the error continues → Replace the lamp with a new lamp and turn on the power. If the error continues → Stop using the projector, disconnect the power cable from the electrical outlet, and contact your local dealer or the nearest address provided in the <i>World-Wide Warranty Terms</i>. Inquiries</p> <p>If it is cracked → Replace it with a new lamp, or contact your local dealer for further advice. If replacing the lamp yourself, be careful to avoid pieces of broken glass (you cannot continue projecting until the lamp is replaced).</p> <p>Check that the lamp cover and the lamp are securely installed. p.75 If the lamp cover or the lamp is not securely installed, the lamp does not switch on.</p> <p>When using at an altitude of 1500 m or more, set "High Altitude Mode" to "On". p.45</p>

■ · Indicator is lit or flashing orange **Warning**

: Lit : Flashing : Off : Varies according to the projector status

Status	Cause	Remedy or Status
<p>Red Orange</p> 	High Temp Warning	<p>(This is not an abnormality. However, if the temperature rises too high again, projection stops automatically.)</p> <ul style="list-style-type: none"> • Check that the air filter and air exhaust vent are clear, and that the projector is not positioned against a wall. • If the air filter is clogged, clean or replace it. p.73, 78
<p>Orange</p> 	Replace Lamp	<p>Replace it with a new lamp. p.75</p> <p>If you continue to use the lamp after the replacement period has passed, the possibility that the lamp may explode increases. Replace it with a new lamp as soon as possible.</p>



- *If the projector is not operating properly, even though the indicators are all showing normal, refer to "When the Indicators Provide No Help" ([p.64](#)).*
- *If an indicator is displaying a status not described in the tables, contact your local dealer or the nearest address provided in the World-Wide Warranty Terms. [Inquiries](#)*

When the Indicators Provide No Help

If any of the following problems occur and the indicators do not offer a solution, refer to the pages given for each problem.

Problems relating to images


- **No images appear**  [p.65](#)
Projection does not start, the projection area is completely black, the projection area is completely blue, and so on.
- **Moving images are not displayed**  [p.65](#)
Moving images being projected from a computer appear black and nothing is projected.
- **Projection stops automatically**  [p.65](#)
- **The message "Not supported." is displayed**  [p.66](#)
- **The message "No Signal." is displayed**  [p.66](#)
- **Images are fuzzy or out of focus**  [p.66](#)
- **Interference or distortion appears in images**  [p.67](#)
Problems such as interference, distortion, or black & white checked patterns appear.
- **The image is truncated (large) or small, or the aspect is not suitable**  [p.67](#)
Only part of the image is displayed, or the height and width ratios of the image are not correct, and so on.
- **Image colours are not right**  [p.68](#)
The whole image appears purplish or greenish, images are black & white, colours appear dull, and so on.
(Computer monitors and LCD screens have different colour reproduction performance, so that the colours projected by the projector and the colours appearing on the monitor may not necessarily match, but this is not a sign of a problem.)
- **Images appear dark**  [p.68](#)
- **Nothing appears on the external monitor**  [p.68](#)

Problems when projection starts

- **Power does not turn on**  [p.69](#)

Other problems

- **No sound can be heard or the sound is faint**  [p.69](#)
- **The remote control does not work**  [p.69](#)
- **Mail is not received even if an abnormality occurs in the projector**  [p.70](#)



■ Problems relating to images

■ No images appear

Check	Remedy
Did you press the [Power] button?	Press the [Power] button to turn the power on.
Are the indicators switched off?	The power cable is not connected correctly or power is not being supplied normally. Connect the projector's power cable correctly.  Quick Start Guide Check that your electrical outlet or power source is functioning correctly.
Is A/V Mute active?	Press the [A/V Mute] button on the remote control to cancel A/V Mute.  p.23
Is the A/V mute slide closed?	Open the A/V mute slide.
Are the configuration menu settings correct?	Reset all of the settings.  "Reset"-"Reset All" p.58
Is the projected image completely black? Only when projecting computer images	Some input images, such as screen savers, may be completely black.
Is the image signal format setting correct? Only when projecting images from a video source	Change the setting according to the signal for the connected equipment.  "Signal"-"Video Signal" p.42

■ Moving images are not displayed

Check	Remedy
Is the computer's image signal being output to the LCD and the monitor? Only when projecting images from a laptop computer or a computer with a built-in LCD screen	Change the image signal to external output only.  Check your computer's documentation.

■ Projection stops automatically

Check	Remedy
Is "Sleep Mode" set to "On"?	Press the [Power] button to turn the power on. If you do not want to use "Sleep Mode", change the setting to "Off".  "Extended"-"Operation"-"Sleep Mode" p.45

■ The message "Not supported." is displayed

Check	Remedy
Is the image signal format setting correct? Only when projecting images from a video source	Change the setting according to the signal for the connected equipment.  "Signal"-"Video Signal" p.42
Do the image signal resolution and the refresh rate correspond to the mode? Only when projecting computer images	Refer to the computer's documentation for how to change the image signal resolution and the refresh rate output from the computer.  "List of supported monitor displays" p.92

■ The message "No Signal." is displayed

Check	Remedy
Are the cables connected correctly?	Check that all the cables required for projection are securely connected.  <i>Quick Start Guide</i>
Is the correct input port selected?	Change the image by pressing the [Source Search] button on the remote control or the control panel.  p.20
Is the power for the computer or video source turned on?	Turn the power on for the equipment.
Are the image signals being output to the projector? Only when projecting images from a laptop computer or a computer with a built-in LCD screen	If the image signals are only being output to the computer's LCD monitor or to the accessory monitor, you need to change the output to an external destination as well as the computer's own monitor. For some computer models, when the image signals are output externally, they no longer appear on the LCD monitor or accessory monitor.  Computer's documentation, under a title such as "External output" or "Connecting an external monitor". If the connection is made while the power of the projector or computer is already turned on, the function [Fn] key that changes the computer's image signal to external output may not work. Turn the power for the computer and the projector off and then back on again.  <i>Quick Start Guide</i>

■ Images are fuzzy or out of focus

Check	Remedy
Is the focus adjusted correctly?	Turn the focus ring to adjust the focus.  <i>Quick Start Guide</i>
Is the projector at the correct distance?	The recommended projection distance ranges from 83 to 1469 cm (33 to 578 in.). Setup within this range.  p.81
Is the Keystone adjustment value too large?	Lower the projection angle to reduce the amount of keystone correction.  <i>Quick Start Guide</i>
Has condensation formed on the lens?	If the projector is suddenly taken from a cold environment to a warm environment, or if sudden ambient temperature changes occur, condensation may form on the surface of the lens, and this may cause the images to appear fuzzy. Set the projector up in the room about one hour before it is used. If condensation forms on the lens, turn the projector off and wait for the condensation to disappear.

■ Interference or distortion appear in images

Check	Remedy
Is the image signal format setting correct? Only when projecting images from a video source	Change the setting according to the signal for the connected equipment. 🖱️ "Signal"-"Video Signal" p.42
Are the cables connected correctly?	Check that all the cables required for projection are securely connected. 🖱️ <i>Quick Start Guide</i>
Is an extension cable being used?	If an extension cable is used, electrical interference may affect the signals. Use the cables supplied with the projector to check if the cables you are using may be causing the problem.
Is the correct resolution selected? Only when projecting computer images	Set the computer so that the signals being output are compatible with this projector. 🖱️ "List of Supported Monitor Displays" p.92 🖱️ Computer documentation
Are the "Sync.▶▶" and "Tracking▶▶" settings adjusted correctly? Only when projecting computer images	Press the [Auto] button on the remote control or the [Enter] button on the control panel to perform automatic adjustment. If the images are not adjusted correctly after using automatic adjustment, you can make the adjustments using "Sync." and "Tracking" from the configuration menu. 🖱️ "Signal"-"Tracking", "Sync." p.42

■ The image is truncated (large) or small, or the aspect is not suitable

Check	Remedy
Is a wide panel computer image being projected? Only when projecting computer images	Press the [Resize] button on the remote control to change the aspect mode in the order of "Normal", "4:3", and "16:9". Change the aspect mode according to the resolution.
Is the image still being enlarged by E-Zoom?	Press the [Esc] button on the remote control to cancel E-Zoom. 🖱️ p.27
Is "Position" adjusted correctly?	Press the [Auto] button on the remote control or the [Enter] button on the control panel to perform automatic adjustment of the computer image being projected. If the images are not adjusted correctly after using automatic adjustment, you can make the adjustments using "Position" from the configuration menu. Apart from computer image signals, you can adjust other signals while projecting by adjusting "Position" from the configuration menu. 🖱️ "Signal"-"Position" p.42
Is the computer set for dual display? Only when projecting computer images	If dual display is activated in the "Display Properties" of the computer's control panel, only about half of the image on the computer screen is projected. To display the entire image on the computer screen, turn off the dual display setting. 🖱️ Computer video driver documentation
Is the correct resolution selected? Only when projecting computer images	Set the computer so that the signals being output are compatible with the projector. 🖱️ "List of Supported Monitor Displays" p.92 🖱️ Computer documentation

■ Image colours are not right

Check	Remedy
Do the input signal settings match the signals from the connected device?	Change the following settings according to the signal for the connected equipment. In case of an image from a computer connected to the Computer1, Computer2 input terminal  "Signal"- "Computer1/2 Input" p.42 When projecting images from equipment connected to Video or S-Video  "Signal"- "Video Signal" p.42
Is the image brightness adjusted correctly?	Adjust the "Brightness" setting from the configuration menu.  "Image"- "Brightness" p.41
Are the cables connected correctly?	Check that all the cables required for projection are securely connected.  Quick Start Guide
Is the " <u>contrast</u> 	Adjust the "Contrast" setting from the configuration menu.  "Image"- "Contrast" p.41
Is the colour adjusted correctly?	Adjust the "Color Adjustment" setting from the configuration menu.  "Image"- "Color Adjustment" p.41
Are the colour saturation and tint adjusted correctly?	Adjust the "Color Saturation" and "Tint" settings from the configuration menu.  "Image"- "Color Saturation", "Tint" p.41
Only when projecting images from a video source	

■ Images appear dark

Check	Remedy
Are the image brightness and luminance adjusted correctly?	Adjust the "Brightness" and "Brightness Control" settings from the configuration menu.  "Image"- "Brightness" p.41  "Settings"- "Brightness Control" p.43
Is the " <u>contrast</u> 	Adjust the "Contrast" setting from the configuration menu.  "Image"- "Contrast" p.41
Is the lamp due for replacement?	When the lamp is nearly ready for replacement, the images become darker and the colour quality becomes poorer. When this happens, replace the lamp with a new lamp.  p.75

■ Nothing appears on the external monitor

Check	Remedy
Are images from a port other than the Computer1 port being projected?	The only images that can be displayed on an external monitor are computer images from Computer1 port.  p.85

■ **Problems when projection starts**

■ **Power does not turn on**

Check	Remedy
Did you press the [Power] button?	Press the [Power] button to turn the power on.
Are the indicators switched off?	The power cable is not connected correctly or power is not being supplied normally. Connect the projector's power cable correctly.  Quick Start Guide Check that your electrical outlet or power source is functioning correctly.
Do the indicators turn on and off when the power cable is touched?	There is probably a poor contact in the power cable, or the power cable may be defective. Reinsert the power cable. If this does not solve the problem, stop using the projector, disconnect the power cable from the electrical outlet, and contact your local dealer or the nearest address provided in the <i>World-Wide Warranty Terms</i> .  Inquiries
Is the operation lock set to "Full Lock"?	Press and hold down the [Enter] button on the control panel for about seven seconds, a message is displayed and the lock is released.  p.37
Is the correct setting for the remote receiver selected?	Check the "Remote Receiver" from the configuration menu.  "Settings"- "Remote receiver" p.43
Was the power cable plugged back in immediately after Direct Power Off, or is the breaker turned off?	When the operation to the left is performed when "Direct Power On" is set to "On", the power may not turn back on. [Power]Press the button to turn the power back on.

■ **Other problems**

■ **No sound can be heard or the sound is faint**

Check	Remedy
Is the audio source connected correctly?	Check that the cable is connected to the Audio port.
Is the volume adjusted to the minimum setting?	Adjust the volume so that sound can be heard.  Quick Start Guide
Is A/V Mute active?	Press the [A/V Mute] button on the remote control to cancel A/V Mute.  p.23
Is the audio cable's specification "No resistance"?	When using a commercially available audio cable, make sure it is labeled "No resistance".

■ **The remote control does not work**

Check	Remedy
Is the remote control light-emitting area pointing towards the remote receiver on the projector when it is operated?	Point the remote control towards the remote receiver. The operating angle for the remote control is about 30° horizontally, and about 15° vertically.  Quick Start Guide
Is the remote control too far from the projector?	The operating range for the remote control is about 6 m.  Quick Start Guide



Check	Remedy
Is direct sunlight or strong light from fluorescent lamps shining onto the remote receiver?	Set the projector up in a location where strong light does not shine onto the remote receiver. Or set the remote receiver to "Off" from "Remote Receiver" in the configuration menu.  "Settings"- "Remote receiver" p.43
Is the correct setting for the remote receiver selected?	Check the "Remote Receiver" from the configuration menu.  "Settings"- "Remote receiver" p.43
Are the remote control ID and the projector ID matched?	Press the [ID] button on the remote control pointing at the remote receiver of the projector to be operated. When the remote control operation is disabled, turn off the projector and then turn it on again.  p.31
Are the batteries dead or have the batteries been inserted correctly?	Make sure the batteries are inserted correctly or replace the batteries with new ones if necessary.  p.74
Was a remote control button pressed for more than 30 seconds?	If any of the buttons on the remote control are pressed down for more than 30 seconds, the remote control stops sending signals (remote control's sleep mode). This feature is to prevent the batteries running down if the remote control buttons are held down accidentally such as when it is stored in a bag or if an object is placed on top of it. When the button is released, normal remote control operation resumes.

■ Mail is not received even if an abnormality occurs in the projector (EMP-1815 only)

Check	Remedy
Is "Standby Mode" set to "Network On"?	To use the mail notification function when the projector is in standby, set "Network On" in "Standby Mode" from the configuration menu.  "Extended"- "Standby Mode" p.45
Did a fatal abnormality occur and the projector come to a sudden stop?	When the projector comes to a sudden stop, mail cannot be sent. If the abnormal state continues, contact your local dealer or the nearest address provided in the <i>World-Wide Warranty Terms</i> .  Inquiries
Is power being supplied to the projector?	Check that your electrical outlet or power source is functioning correctly.
Is the LAN cable connected correctly?	Check that the LAN cable is connected correctly. Reconnect it if it is not connected or it is not connected correctly.  p.86
Is "Mail" set correctly in the configuration menu?	Mail notification of abnormalities is sent according to the "Mail" settings in the configuration menu. Check if it is set correctly.  "Network"- "Mail" p.55





Appendices

This chapter provides information on maintenance procedures to ensure the best level of performance from the projector for a long time to come.


Installation Methods	72	Connecting to External Equipment	85
Cleaning.....	73	• Connecting to an External Monitor.....	85
• Cleaning the Projector's Surface.....	73	• Connecting to External Speakers.....	85
• Cleaning the Lens.....	73	Connecting a LAN Cable	86
• Cleaning the Air Filter and Air Intake Vent.....	73	Optional Accessories and Consumables	87
Replacing Consumables	74	Optional accessories.....	87
• Replacing the Remote Control Batteries	74	Consumables	87
• Replacing the Lamp	75	Glossary	88
Lamp replacement period.....	75	ESC/VP21 Commands	90
How to replace the lamp.....	75	• Command List	90
Resetting the lamp operating time.....	77	• Cable Layouts	90
• Replacing the Air Filter	78	Serial connection.....	90
Air filter replacement period	78	PJLink (EMP-1815 Only)	91
How to replace the air filter.....	78	List of Supported Monitor Displays	92
Saving a User's Logo	79	Computer image.....	92
Screen Size and Distance	81	Component video	92
Connecting USB Devices		Composite video/S-video.....	92
(Digital Camera, Hard Disk Drive or Memory		Specifications	93
Devices) (EMP-1815 Only).....	82	Appearance.....	97
• Connecting USB Devices	82	Index.....	98
Inserting and Ejecting CompactFlash Cards			
(EMP-1815 Only)	83		
• How to Insert Cards.....	83		
• How to Remove Cards	83		
Card Slot Access Indicator Statuses.....	84		

The projector supports the following four different projection methods.


Attention

- *A special method of installation is required when suspending the projector from a ceiling (ceiling mount). If it is not installed correctly, it could fall causing an accident and injury.*
- *If you use adhesives on the ceiling mount to prevent the screws from loosening, or if you use things such as lubricants or oils on the projector, the projector case may crack causing it to fall from its ceiling mount. This could cause serious injury to anyone under the ceiling mount and could damage the projector. When installing or adjusting the ceiling mount, do not use adhesives to prevent the screws from loosening and do not use oils or lubricants and so on.*
- *Do not use the projector on its side. This may cause malfunctions to occur.*


- *Project images from in front of the screen. (Front projection)*




- *Project images from behind a translucent screen. (Rear projection)*



- *Suspend the projector from the ceiling and project images from in front of the screen. (Front/Ceiling projection)*



- *Suspend the projector from the ceiling and project images from behind a translucent screen. (Rear/Ceiling projection)*



- *An optional ceiling mount is required when suspending the projector from a ceiling. [p.87](#)*
- *You can change the setting as follows by pressing down the [A/V Mute] button on the remote control for about five seconds.
"Front" ↔ "Front/Ceiling"
Set "Rear" or "Rear/Ceiling" from the configuration menu. [p.44](#)*

You should clean the projector if it becomes dirty or if the quality of projected images starts to deteriorate.

Cleaning the Projector's Surface

Clean the projector's surface by wiping it gently with a soft cloth. If the projector is particularly dirty, moisten the cloth with water containing a small amount of neutral detergent, and then firmly wring the cloth dry before using it to wipe the projector's surface.

Attention

Do not use volatile substances such as wax, alcohol, or thinner to clean the projector's surface. The quality of the case may change or become discoloured.

Cleaning the Lens

Use a commercially available cloth for cleaning glasses to gently wipe the lens.

Attention

Do not rub the lens with harsh materials or subject the lens to shocks, as it can easily become damaged.


Cleaning the Air Filter and Air Intake Vent

Clean the air filter and the air intake vent when the following message is displayed.

"The projector is overheating. Make sure nothing is blocking the air vent, and clean or replace the air filter."  "How to replace the air filter" [p.78](#)

Attention

If dust collects on the air filter it can cause the internal temperature of the projector to rise, and this can lead to problems with operation and shorten the optical engine's service life. Clean the air filter immediately when the message is displayed.



- *If a message is frequently displayed, even after cleaning, it is time to replace the air filter. Replace it with a new air filter.  [p.78](#)*
- *It is recommended that you clean these parts at least once every three months. Clean them more often than this if using the projector in a particularly dusty environment.*

This section explains how to replace the remote control batteries, the lamp, and the air filter.

Replacing the Remote Control Batteries

If delays in the responsiveness of the remote control occur or if it does not operate after it has been used for some time, it probably means that the batteries are becoming flat. When this happens, replace them with new batteries. Have two spare AAA-size alkali batteries ready to use when required.


Attention

Make sure you read the Safety Instructions/World-Wide Warranty Terms before handling the batteries.  [Safety Instructions](#)

Procedure

1 Remove the battery cover.

While pushing the battery compartment cover catch, lift the cover up.




2

2 Replace the old batteries with new batteries.

Attention


Check the positions of the (+) and (-) marks inside the battery holder to ensure the batteries are inserted the correct way.



3

3 Replace the battery cover.

Press the battery compartment cover until it clicks into place.




Replacing the Lamp

Lamp replacement period


It is time to replace the lamp when:

- The message "Replace the lamp.Replace the lamp." is displayed when you start projecting.



A message is displayed.

- The lamp indicator flashes orange.



Flashing orange

- The projected image gets darker or starts to deteriorate.

Attention

- *The lamp replacement message is set to appear after the following time periods in order to maintain the initial brightness and quality of the projected images. See "Brightness Control" p.43*
 - *When used continually at high brightness: About 2400 hours*
 - *When used continually at low brightness: About 2900 hours*
- *If you continue to use the lamp after the replacement period has passed, the possibility that the lamp may explode increases. When the lamp replacement message appears, replace the lamp with a new one as soon as possible, even if it is still working.*
- *Depending on the characteristics of the lamp and the way it has been used, the lamp may become darker or stop working before the lamp warning message appears. You should always have a spare lamp ready incase it is needed.*

How to replace the lamp

Attention

- *When replacing the lamp because it has stopped illuminating, there is a possibility that the lamp may be broken. If replacing the lamp of a projector which has been installed on the ceiling, you should always assume that the lamp is broken, and you should stand to the side of the lamp cover, not underneath it. Remove the lamp cover gently. Small pieces of glass may fall out when the lamp cover is opened. If pieces of glass get into your eyes or mouth, seek medical advice immediately.*
- *Wait until the lamp has cooled down sufficiently before removing the lamp cover. If the lamp is still hot, burns or other injuries may result. It takes about one hour after the power has been turned off for the lamp to be cool enough.*





Procedure


1 After you turn off the projector's power and the confirmation buzzer beeps twice, disconnect the power cable.

2 Wait until the lamp has cooled down, then remove the lamp cover.

Loosen the lamp cover fixing screw with the screwdriver supplied with the new lamp or a + head screwdriver. Then slide the lamp cover straight forward and lift it to remove.




3 Loosen the two lamp fixing screws.





4 Take out the old lamp.

If the lamp is cracked, replace it with a new lamp, or contact your local dealer for further advice. If replacing the lamp yourself, be careful to avoid pieces of broken glass.




5 Install the new lamp.

Insert the new lamp along the guide rail in the correct direction so that it fits in place, push down firmly at the location marked "PUSH", and once it is fully inserted tighten the two screws.



6 Replace the lamp cover.



Attention

- *Make sure you install the lamp securely. If the lamp cover is removed, the lamp turns off automatically as a safety precaution. If the lamp or the lamp cover is not installed correctly, the lamp does not turn on.*
- *This product includes a lamp component that contains mercury (Hg). Please consult your local regulations regarding disposal or recycling. Do not dispose of it with normal waste.*

Resetting the lamp operating time

The projector records how long the lamp is turned on and a message and indicator notify you when it is time to replace the lamp. After replacing the lamp, make sure you reset the lamp hours from the configuration menu. p.58



Only reset the lamp operating time after the lamp has been replaced, otherwise the lamp replacement period is not indicated correctly.



Replacing the Air Filter

Air filter replacement period

It is time to replace the air filter when:

- The air filter is ripped.
- The message is displayed even though the air filter has been cleaned.


How to replace the air filter

The air filter can be replaced even when the projector is suspended from a ceiling.

Procedure


1 After you turn off the projector's power and the confirmation buzzer beeps twice, disconnect the power cable.

2 Remove the air filter.
Put your finger into the recess of the air filter and slide it forward to remove it.



3 Install the new air filter.

Slide the air filter in from the outside and push until it clicks into place.



Dispose of used air filters properly in accordance with your local regulations.

Material quality of the frame section: Polycarbonate, ABS resin

Material quality of the filter section: Polyurethane form

You can save the image that is currently being projected as a user's logo.




When a user's logo is saved, the previous user's logo is erased.


Procedure

1 Project the image you want to use as the user's logo, and then press the [Menu] button.

Using the remote control




Using the control panel



2

From the configuration menu, select "Extended" - "User's Logo". "Using the Configuration Menu" p.40

Check the buttons you can use and the operations they perform in the guide under the menu.



- If "User's Logo Protect" from "Password Protect" is set to "On", a message is displayed and the user's logo cannot be changed. You can make changes after setting "User's Logo Protect" to "Off". p.35
- If "User's Logo" is selected when Keystone, E-Zoom, Resize, or Progressive are being performed, the function currently being performed is cancelled.

3


When "Choose this image as the User's Logo?" is displayed, select "Yes".




When you press the [Enter] button on the remote control or the control panel, the screen size may change according to the signal as it changes to the resolution of the image signal.




- 4** The image is recorded and a selection marquee box is displayed. Move the box to select the part of the image to use as the user's logo.




Using the remote control



Using the control panel



- 5** When "Select this image?" is displayed, select "Yes".
- 6** Select the zoom factor from the zoom setting screen.



- 7** When the message "Save this image as the User's Logo?" is displayed, select "Yes".

The image is saved. After the image has been saved, the message "Completed." is displayed.



- Saving the user's logo may take about 15 seconds. Do not use the projector or any connected equipment while it is saving, otherwise malfunctions may occur.
- Once a user's logo has been saved, the logo cannot be returned to the factory default.



You can save at up to 400 × 300 dots in size.





See the following table to choose the best position for your projector. The values are only a guide.

Units: cm (in.)

4:3 Screen Size		Projection Distance A		Offset B
		Minimum (Wide)	Maximum (Tele)	
30"	61 × 46 (24 × 18)	83 to 139 (33 to 55)		7 (2.6)
40"	81 × 61 (32 × 24)	114 to 189 (45 to 74)		9 (3.4)
50"	100 × 76 (39 × 30)	144 to 238 (57 to 94)		11 (4.3)
60"	120 × 90 (47 × 35)	174 to 287 (69 to 113)		13 (5.1)
80"	160 × 120 (63 × 47)	235 to 386 (93 to 152)		17 (6.9)
100"	200 × 150 (79 × 59)	296 to 484 (117 to 191)		22 (8.6)
120"	240 × 180 (94 × 71)	357 to 583 (141 to 229)		26 (10.3)
150"	300 × 230 (118 × 91)	449 to 730 (177 to 288)		33 (12.9)
200"	410 × 300 (161 × 118)	601 to 977 (237 to 385)		44 (17.1)
300"	610 × 460 (240 × 181)	906 to 1469 (357 to 578)		65 (25.7)

Units: cm (in.)

16:9 Screen Size		Projection Distance A		Offset B
		Minimum (Wide)	Maximum (Tele)	
30"	66 × 37 (26 × 15)	90 to 152 (36 to 60)		1 (0.4)
40"	89 × 50 (35 × 20)	124 to 205 (49 to 81)		1 (0.5)
50"	110 × 62 (43 × 24)	157 to 259 (62 to 102)		1 (0.6)
60"	130 × 75 (51 × 28)	190 to 313 (75 to 123)		2 (0.7)
80"	180 × 100 (71 × 39)	256 to 420 (101 to 165)		2 (0.9)
100"	220 × 120 (87 × 47)	323 to 527 (127 to 208)		3 (1.2)
120"	270 × 150 (106 × 59)	389 to 635 (153 to 250)		4 (1.4)
150"	330 × 190 (130 × 75)	489 to 796 (192 to 313)		4 (1.8)
200"	440 × 250 (173 × 98)	655 to 1064 (258 to 419)		6 (2.3)
300"	660 × 370 (260 × 146)	987 to 1601 (388 to 630)		9 (3.5)



USB2.0/1.1-compatible digital cameras, hard disk drives and USB storage devices can be connected to the projector. Image files that are stored inside the digital camera and scenarios, images and movies that are stored inside USB storage devices can be played back by EasyMP CardPlayer. [EasyMP Operation Guide "PC Free Basic Operations"](#)


Connecting USB Devices

The following procedure describes how to connect USB devices, using a digital camera as an example.

Connect a digital camera to the projector using a USB cable provided with, or specified for use with your digital camera.



- *Use a USB cable less than 3m in length. If the cable exceeds 3m, CardPlayer may not function correctly.*
- *Check that there is no wireless LAN card or memory card in the projector's card slot before connecting any USB device.*



Attention

- *If you use a USB hub, the connection may not operate correctly. Devices such as digital cameras and USB storage devices should be connected to the projector directly.*
- *When using an USB-compatible hard disc, be sure to connect the AC adaptor supplied with the hard disc.*

On the EMP-1815, CompactFlash cards can be used as external memory storage. The following explains how to insert and eject CompactFlash cards.

How to Insert Cards


Attention

- *Insert CompactFlash card so that it faces the correct direction. Inserting a card in the wrong direction may result in malfunction or damage.*
- *When carrying the projector, be sure to remove the CompactFlash card.*

Procedure

Insert the CompactFlash card into the card slot with its top surface facing up.

Firmly insert the card as far as it can go.



How to Remove Cards

Attention


When the access indicator of the card slot is lit green or is flashing, do not remove the CompactFlash card. Doing so will damage data stored on the card or cause the projector to malfunction.

Procedure



Press the eject button at the side of the card slot.

The eject button springs out.



2 Press the eject button again.

The CompactFlash card is ejected from the card slot. Remove the card from the card slot.

Attention

Be sure to push the eject button back in. If the eject button stays out, it may become bent or damaged in other ways.

■ Card Slot Access Indicator Statuses

When a CompactFlash card is inserted into the projector, the access status of the card is indicated by the lighting status of the card slot access indicator.


 : Flashing  : Lit:  : Off

Indicator Status	Access Status
Flashing 	Data is either being read from or being written to the CompactFlash card.
Lit 	The CompactFlash card is standing by.
Off 	The CompactFlash card is not performing any operations.



Connecting to an External Monitor


Computer images being input to the Computer1 port can be displayed on an external monitor and the screen at the same time when connected to the projector. This means that you can check projected images on an external monitor when giving presentations even if you cannot see the screen. Connect to an external monitor using the cable supplied with the monitor.



- *Component video signals and equipment connected to the Computer2 port, Video port, and S-Video port cannot be output to an external monitor.*
- *The setting gauge for Keystone, the configuration and help screen, and so on are not output to an external monitor.*

Connecting to External Speakers

You can connect speakers with built-in amplifiers to the projector's Audio Out port to enjoy a fuller quality of sound. Connect with a commercially available audio cable (pin plug ↔ 3.5 mm stereo mini plug and so on). Use an audio cable compatible with the connector on the external speakers.




When an audio cable plug is inserted in the Audio Out port, the audio changes to the external destination, and audio is no longer emitted from the projector's built-in speaker.

Connecting a LAN Cable



Connect with a commercially available 100baseTX or 10baseT type LAN cable.



Attention

To prevent malfunctions, use a category 5 shielded LAN cable.

The following list of optional accessories is current as of February, 2007. Details of accessories are subject to change without notice and availability may vary depending on the country of purchase.

■ Optional accessories

60" portable screen ELPSC07
80" portable screen ELPSC08
100" screen ELPSC10
Portable roll-type screens ([Aspect ratio](#)▶▶ 4:3)

50" portable screen ELPSC06
A compact screen that can be carried easily. (Aspect ratio 4:3)

HD-15 cable ELPKC02
(1.8 m - for mini D-Sub15-pin/mini D-Sub 15pin)
This is the same as the computer cable supplied with the projector.

HD-15 cable ELPKC09
(3 m - for mini D-Sub15-pin/mini D-Sub 15pin)
HD-15 PC cable ELPKC10
(20 m - for mini D-Sub15-pin/mini D-Sub 15pin)
Use one of these longer cables if the computer cable supplied with the projector is too short.

Component video cable ELPKC19
(3 m - for mini D-Sub 15-pin/RCA male×3)
Use to connect a [component video](#)▶▶ source

Ceiling plate* ELPFC03
Ceiling pipe (370 mm (14.57 in.)/silver)* ELPFP04
Ceiling pipe (570 mm (22.44 in.)/silver)* ELPFP05
Ceiling pipe (770 mm (30.31 in.)/silver)* ELPFP06
Use when installing the projector on a high ceiling.

Ceiling mount* ELPMB18
Use when installing the projector on a ceiling.

* A special method of installation is required to suspend the projector from a ceiling. Contact your dealer or the nearest address provided in the *World-Wide Warranty Terms* if you want to use this installation method.  [Inquiries](#)

■ Consumables

Lamp unit ELPLP40
Use as a replacement for used lamps.

Air filter (by 2) ELPAF08
Use as a replacement for used air filters.

This section explains easily terms that are used with the projector and difficult terms that are not explained in the text of this guide. For details, refer to other commercially available publications.

Aspect ratio	The ratio between an image's length and its height. HDTV images have an aspect ratio of 16:9 and appear elongated. The aspect ratio for standard images is 4:3.
Component video	A video signal which has the luminance component and colour component separated to provide better image quality. Refers to images that consist of three independent signals: Y (luminance signal), Pb and Pr (colour difference signals).
Composite video	Video signals that have the video brightness signals and colour signals mixed together. The type of signals commonly used by household video equipment (NTSC, PAL, and SECAM formats). The carrier signal Y (luminance signal) and chroma (colour) signal that are contained in the colour bar are overlapped to form a single signal.
Contrast	The relative brightness of the light and dark areas of an image can be increased or decreased to make text and graphics stand out more clearly, or to make them appear softer. Adjusting this particular property of an image is called "contrast adjustment".
DHCP	An abbreviation of Dynamic Host Configuration Protocol, this protocol automatically assigns an IP address to equipment connected to a network.
Dolby Digital	A sound format developed by Dolby Laboratories. Normal stereo is a 2-channel format that uses two speakers. Dolby Digital is a 6-channel (5.1-channel) system which adds to this a centre speaker, two rear speakers, and a sub-woofer.
ESSID	ESS is an abbreviation of Extended Service Set (enhanced service set). ESSID is an identification number for connecting with a counterpart on a wireless LAN. Wireless communication is possible between devices that correspond to ESSID.
Gateway address	This is a server (router) for communicating across a network (subnet) divided according to subnet masks .
HDTV	An abbreviation for High-Definition Television that refers to high-definition systems which satisfy the following conditions. <ul style="list-style-type: none"> • Vertical resolution of 750p or 1125i or greater (p = progressive, i = interlace) • Screen aspect ratio of 16:9 • Dolby Digital audio reception and playback (or output)
Interlace	A method of image scanning whereby the image data is divided into fine horizontal lines that are displayed in sequence starting from left to right and then from top to bottom. The even-numbered lines and odd-numbered lines are displayed alternately.
IP address	A number to identify a computer connected to a network.
Progressive	A method of image scanning whereby the image data from a single image is scanned sequentially from top to bottom to create a single image.
Refresh rate	The light-emitting element of a display maintains the same luminosity and colour for an extremely short time. Because of this, the image must be scanned many times per second to refresh the light-emitting element. The number of refresh operations per second is called the Refresh rate and is expressed in hertz (Hz).
SDTV	An abbreviation for Standard Definition Television that refers to standard television systems which do not satisfy the conditions for HDTV High-Definition Television.
SNMP	An abbreviation for Simple Network Management Protocol, which is the protocol for monitoring and controlling devices such as routers and computers connected to a TCP/IP network.
SNMP Trap IP address	This is the IP address for the destination computer used for error notification in SNMP



Squeeze mode	In this mode, wide-screen images in 16:9 mode are compressed in the horizontal direction so that they are stored on the recording medium as 4:3 images. When these images are played back by the projector in squeeze mode, they are restored to their original 16:9 format.
sRGB	An international standard for colour intervals that was formulated so that colours that are reproduced by video equipment can be handled easily by computer operating systems (OS) and the Internet. If the connected source has an sRGB mode, set both the projector and the connected signal source to sRGB.
Subnet mask	This is a numerical value that defines the number of bits used for the network address on a divided network (subnet) from the IP address.
SVGA	A type of video signal with a resolution of 800 (horizontal) × 600 (vertical) dots that is used by IBM PC/AT-compatible computers.
S-video	A video signal which has the luminance component and colour component separated to provide better image quality. Refers to images that consist of two independent signals: Y (luminance signal) and C (colour signal).
SXGA	A type of video signal with a resolution of 1280 (horizontal) × 1024 (vertical) dots that is used by IBM PC/AT-compatible computers.
Synchronization	The signals output from computers have a specific frequency. If the projector frequency does not match this frequency, the resulting images are not of a good quality. The process of matching the phases of these signals (the relative position of the crests and the troughs in the signal) is called Synchronization. If the signals are not synchronized, flickering, blurriness, and horizontal interference occur.
Tracking	The signals output from computers have a specific frequency. If the projector frequency does not match this frequency, the resulting images are not of a good quality. The process of matching the frequency of these signals (the number of crests in the signal) is called Tracking. If tracking is not carried out correctly, wide vertical stripes appear in the signal.
VGA	A type of video signal with a resolution of 640 (horizontal) × 480 (vertical) dots that is used by IBM PC/AT-compatible computers.
XGA	A type of video signal with a resolution of 1024 (horizontal) × 768 (vertical) dots that is used by IBM PC/AT-compatible computers.



Command List

When the power ON command is transmitted to the projector, the power turns on and it enters warm-up mode. When the projector's power has turned on, a colon ":" (3Ah) is returned.

When a command is input, the projector executes the command and returns a ":", and then accepts the next command.

If the command being processed terminates abnormally, an error message is output and a ":" is returned.

Item		Command	
Power ON/OFF	ON	PWR ON	
	OFF	PWR OFF	
Signal selection	Video	SOURCE 41	
	S-Video	SOURCE 42	
	EasyMP (EMP-1815 only)	SOURCE 50	
A/V Mute ON/OFF	ON	MUTE ON	
	OFF	MUTE OFF	
A/V Mute selection	Black	MSEL 00	
	Blue	MSEL 01	
	Logo	MSEL 02	
Item		Command	
		Computer1 Port	Computer2 Port
Signal selection	Computer (Auto)	SOURCE 1F	SOURCE 2F
	Computer	SOURCE 11	SOURCE 21
	Component Video	SOURCE 14	SOURCE 24

* Add a Carriage Return (CR) code (0Dh) to the end of each command and transmit.

Cable Layouts


Serial connection

- Connector shape: D-Sub 9-pin (male)
- Projector input connector: RS-232C

<At the projector>



<At the computer>



<At the projector> (PC serial cable) <At the computer>

GND	5	—————	5	GND
RD	2	←————	3	TD
TD	3	————→	2	RD
DTR	4	————→	6	DSR
DSR	6	←————	4	DTR

Signal	Function
GND	Signal wire ground
TD	Transmit data
RD	Receive data
DSR	Data set ready
DTR	Data terminal ready

PJLink Class 1 was established by the JBMIA (Japan Business Machine and Information System Industries Association) as a standard protocol for controlling network-compatible projector's as part of their efforts to standardize projector control protocols.

The projector complies with the PJLink Class 1 standard established by the JBMIA.

It complies with all commands except for the following commands defined by PJLink Class 1, and agreement was confirmed by the PJLink standard adaptability verification.

Non-compatible commands

	Function	PJLink Command
Mute settings	Image muting set	AVMT 11
	Image muting cancel	AVMT 10
	Audio muting set	AVMT 21
	Audio muting cancel	AVMT 20

Input names defined by PJLink and corresponding projector connectors

Input Connector	PJLink Command
Computer1 input	INPT 11
Computer2 input	INPT 12
Video input	INPT 21
S-Video input	INPT 22

Manufacturer name displayed for "Manufacture name information query"

EPSON

Model name displayed for "Product name information query"

EMP-1815

■ Computer image

Signal	Refresh Rate [▶] (Hz)	Resolution (dots)	Number of Pixels Used When Display is Resized (dots)
VGAEGA		640 × 350	1024 × 560
VGA [▶]	60/72/75/85, iMac*	640 × 480	1024 × 768
SVGA [▶]	56/60/72/75/85, iMac*	800 × 600	1024 × 768
XGA [▶]	60/70/75/85, iMac*	1024 × 768	1024 × 768
SXGA [▶]	70/75/85	1152 × 864	1024 × 768
SXGA	60/75/85	1280 × 960	1024 × 768
SXGA	60/75/85	1280 × 1024	960 × 768
UXGA	60	1600 × 1200	1024 × 768
MAC13"		640 × 480	1024 × 768
MAC16"		832 × 624	1024 × 768
MAC19"		1024 × 768	1024 × 768
MAC19"	60	1024 × 768	1024 × 768
MAC21"		1152 × 870	1016 × 768
SDTV [▶] (525i)	60	720 × 480	1024 × 768
SDTV (625i)	50	720 × 576	1024 × 768
SDTV (525p)	60	720 × 480	1024 × 768
SDTV (625p)	50	720 × 576	1024 × 768
HDTV [▶] (750p)	50/60	1280 × 720	1024 × 576
HDTV (1125i)	50/60	1920 × 1080	1024 × 576

* Connection is not possible if the equipment does not have a VGA output port.

Even when signals other than those mentioned above are input, it is likely that the image can be projected. However, not all functions may be supported.

■ Component video

Signal	Refresh Rate [▶] (Hz)	Resolutions (dots)	
		Aspect Ratio [▶] 4:3	Aspect Ratio 16:9
SDTV [▶] (525i)	60	1024 × 768	1024 × 576
SDTV (625i)	50	1024 × 768	1024 × 576
SDTV (525p)	60	1024 × 768	1024 × 576
SDTV (625p)	50	1024 × 768	1024 × 576
HDTV [▶] (750p) 16:9	50/60	1024 × 768	1024 × 576
HDTV (1125i) 16:9	50/60	1024 × 768	1024 × 576

■ Composite video/S-video


Signal	Refresh Rate [▶] (Hz)	Resolutions (dots)	
		Aspect Ratio [▶] 4:3	Aspect Ratio 16:9
TV (NTSC)	60	1024 × 768	1024 × 576
TV (PAL, SECAM)	50	1024 × 768	1024 × 576

Product name	Multimedia Projector EMP-1815	Multimedia Projector EMP-1810
Dimensions	345 (W) × 86 (H) × 257 (D) mm (not including protruding parts)	
Panel size	0.8"	
Display method	Polysilicon TFT active matrix	
Resolution	786,432 pixels XGA (1024 (W) × 768 (H) dots) × 3	
Focus adjustment	Manual	
Zoom adjustment	Manual (1 to 1.6)	
Lamp	UHE lamp, 210 W, Model No.: ELPLP40	
Max. audio output	5 W monaural	
Speaker	1	
Power supply	100 to 200 V AC ±10%, 50/60 Hz 3.4 to 1.5 A	
Power consumption	100 to 120 V area	Operating: 306 W Standby power consumption (network invalid): 2.6 W Standby power consumption (network valid): 12 W
	200 to 240 V area	Operating: 286 W Standby power consumption (network invalid): 4.6 W Standby power consumption (network valid): 12 W
Operating altitude	Altitude 0 to 2286 m (0 to 7500 ft)	
Operating temperature	5 to 35°C (No condensation)	
Storage temperature	-10 to +60°C (No condensation)	
Mass	Approx 3.1 kg	Approx 2.9 kg



Pixelworks DNX™ ICs are used in this projector.

Angle of tilt



If you use the projector tilted at an angle of more than 45° it could be damaged and cause an accident.



Connectors	Computer1 input port	1	Mini D-Sub15-pin (female) blue	
	Audio1 input port	1	Stereo mini jack	
	Computer2 input port	1	Mini D-Sub15-pin (female) blue	
	Audio2 input port	1	Stereo mini jack	
	S-Video input port	1	Mini DIN 4-pin	
	Video input port	1	RCA pin jack	
	Audio-L/R input port	1	RCA pin jack	
	Monitor Out port	1	Mini D-Sub15-pin (female) black	
	Audio Out port	1	Stereo mini jack	
	RS-232C port	1	Mini D-Sub 9-pin (male)	
	LAN port	1	RJ45	-
	USB port (Type A)*	1	USB connector (Type A)	-
	USB port (Type B)*	1	USB connector (Type B)	USB connector (Type B)
	USB port (exclusive wireless LAN unit)	1	USB connector (Type A)	-
Card slot	1	CompactFlash card	-	

* This supports USB2.0.

USB ports are not guaranteed to operate all devices that support USB.

Other detailed specifications, please access your location (country/area) from Epson homepage, <http://www.epson.com>



Safety standards

USA: UL60950-1

Canada: CSA C22.2 No.60950-1

EU: The Low Voltage Directive
(73/23/EEC)
IEC/EN60950-1

This product is also designed for IT power distribution system with phase-to-phase voltage 230V.

EMC standards

USA: FCC Part 15B Class B (DoC)

Canada: ICES-003 Class B

EU: The EMC Directive
(89/336/EEC)
EN55022, Class B
EN55024
IEC/EN61000-3-2
IEC/EN61000-3-3

Australia/New Zealand: AS/NZS CISPR 22:2002 Class B

DECLARATION of CONFORMITY

According to 47CFR, Part 2 and 15
Class B Personal Computers and Peripherals; and/or
CPU Boards and Power Supplies used with Class B
Personal Computers

We: Epson America, Inc.
Located at: 3840 Kilroy Airport Way
MS: 3-13
Long Beach, CA 90806
Tel: 562-290-5254

Declare under sole responsibility that the product identified herein, complies with 47CFR Part 2 and 15 of the FCC rules as a Class B digital device. Each product marketed, is identical to the representative unit tested and found to be compliant with the standards. Records maintained continue to reflect the equipment being produced can be expected to be within the variation accepted, due to quantity production and testing on a statistical basis as required by 47CFR 2.909. Operation is subject to the following two conditions :

Trade Name: EPSON
Type of Product: Projector
Model: EMP-1815/1810

**FCC Compliance Statement
For United States Users**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio and television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING


The connection of a non-shielded equipment interface cable to this equipment will invalidate the FCC Certification or Declaration of this device and may cause interference levels which exceed the limits established by the FCC for this equipment. It is the responsibility of the user to obtain and use a shielded equipment interface cable with this device. If this equipment has more than one interface connector, do not leave cables connected to unused interfaces. Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

The wireless LAN 802.11a/b/g adapter Model: WN6501CEP complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device should be installed and operated with minimum distance 20 cm between the radiator and your body.



* Distance from centre of lens to suspension bracket fixing point



Units: mm

A

A/V mute	23
A/V mute slide	7
Abs. Color Temp.	41
Air exhaust vent	7
Air filter	9
Air filter replacement period	78
Air intake vent	9
Angle of tilt	93
Aspect ratio	25
Audio Out port	10
Audio-L/R input port	10
Auto setup	42

B

Basic Menu	48
Blackboard	22
Brightness	41
Brightness control	43

C

Ceiling	44
Cleaning the air filter and air intake vent	73
Cleaning the projector's surface	73
Color adjustment	41
Color mode	22, 41
Color saturation	41
Computer1 Input	42
Computer1 input port	10
Computer2 Input	42
Computer2 input port	11
Configuration menu	40
Connecting a LAN Cable	86
Connecting USB Devices	82
Consumables	87
Contrast	41
Control panel	12

Cross	27
-------------	----

D

DHCP	49
Digital Camera	82
Direct power on	45
Display	44
Display background	44

E

Email Address 1/2/3 setting	55
ESC/VP21	90
ESSID	49
Extended menu	44
External dimension diagram	97
External monitor	85
External speakers	85
E-zoom	27

F

Focus ring	7
Freeze	24
Front	44
Front adjustable feet	7
Full Lock	37

G

Gateway address	49, 54
Glossary	88

H

HDTV	92
Help function	60
High altitude mode:	45
How to replace the air filter	78

How to replace the lamp	75
-------------------------------	----

I

Image menu	41
Indicators	61
Info menu	57
Input signal	57
IP address	49, 54

K

Keystone	43
----------------	----

L

Lamp cover	7
Lamp hours	57
Lamp indicator	61
Lamp replacement period	75
LAN port	10
Language	45
Low brightness	43

M

Mail Menu	55
Mail Notification	55
Menu	40
Messages	44
Monitor Out port	10
Mouse pointer	28
Multi-Screen Colour Adjustment	32

N

Network Menu	46
Network Protect	35
Numeric buttons	13, 14



O

Operating temperature	93
Operation	45
Operation lock	37, 43
Optional accessories	87
Overheating	62

P

Part names and functions	7
Password protect	34
Password protect sticker	35
Photo	22
PJLink	91
Pointer	26
Pointer shape	43
Port number	55
Position	42
Power indicator	61
Power inlet	10
Power on protect	34
Presentation	22
Problem solving	61
Progressive	42
Projection	44
Projection distance	81
Projector ID	30
Projector name	48

R

Rear	44
Rear foot	9
Rear screen	72
Refresh rate	57
Remote control	13, 28
Remote Control ID	31
Remote control light-emitting area	14
Remote receiver	7, 10

Replacing batteries	74
Request code	36
Reset all	58
Reset menu	58
Resetting the lamp operating time	58, 77
Resize	92
Resize display	92
Resolution	57, 92
RS-232C port	10

S

Screen size	81
Security Menu	50
Security slot	10
Settings menu	43
Sharpness	41
Signal menu	42
Sleep mode	45
SMTP server	55
SNMP Menu	56
SNMP Trap IP address	56
Software keyboard	47
Source	57
Source search	12, 13, 20
Speaker	7, 85
Specifications	93
Sports	22
sRGB	22
Standby mode	45
Startup screen	44
Storage temperature	93
Sub menu	40
Subnet mask	49, 54
Supported monitor displays	92
Suspension bracket fixing points	9, 97
S-video port	10
Sync info	57
Synchronization	42

T

Temp indicator	61
Theatre	22
Tint	41
Top menu	40
Tracking	42

U

USB port	10
User's logo	79
User's logo protect	34

V

Video port	10
Video signal	42, 57
Volume	43

W

Wide-screen projection	25
Wired LAN Menu	54
Wireless LAN Menu	49
Wireless mouse	28

Z

Zoom ring	7
-----------------	---



All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. No patent liability is assumed with respect to the use of the information contained herein. Neither is any liability assumed for damages resulting from the use of the information contained herein.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable against any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

The contents of this guide may be changed or updated without further notice.

Illustrations in this guide and the actual projector may differ.

General Notice:

Macintosh, Mac, and iMac are registered trademarks of Apple Computer, Inc.

IBM is a registered trademark of International Business Machines Corporation.

Windows, Windows NT, and PowerPoint are either registered trademarks or trademarks of Microsoft Corporation in the U.S. and/or other countries.

Dolby is a trademark of Dolby Laboratories.

Pixelworks and DNX are trademarks of Pixelworks, Inc.

CompactFlash is a registered trademark or trademark of Sandisk Corporation.

Other product names used herein are also for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

This product uses open source software.