

Safety Instructions

- Safety Instructions 2
- Notes on Handling and Storage..... 10



Support and Service Guide

- Utility Software 14
- Problem Check Sheets 15
- Epson Projector Contact List 17

Safety Instructions

All safety and operating instructions should be read before using the projector. After you have read all instructions, save this information for later reference. To prevent personal injury or damage to property, the following symbols are used to show dangerous operation or handling. Make sure you understand them properly when reading the guide.

Explanation of symbols

 Warning	This symbol indicates information that, if ignored, could possibly result in serious personal injury or even death due to incorrect handling.
 Caution	This symbol indicates information that, if ignored, could possibly result in personal injury or physical damage due to incorrect handling.

Symbols indicating an action that must not be done



Do not do



Do not
disassemble



Do not
touch



Do not
wet



Do not use in
wet areas



Do not place
on an
unstable
surface

Symbols indicating an action that should be done



Instructions



Disconnect
the plug from
the outlet

Warning

Unplug the projector from the outlet and refer all repairs to qualified service personnel under the following conditions:

- If smoke, strange odors or strange noises come from the projector.
- If liquid or foreign objects get inside the projector.
- If the projector has been dropped or the housing has been damaged.

Continuing to use under these conditions may result in fire or electric shock.

Do not try to repair this projector yourself. Refer all repairs to qualified service personnel.

Place the projector near an outlet where the plug can be easily unplugged.



Disconnect
the plug from
the outlet

Never open any covers on the projector except as specifically explained in the User's Guide. Never attempt to disassemble or modify the projector (including consumables). Refer all repairs to qualified service personnel.

Electrical voltages inside the projector can cause severe injury.



Do not
disassemble

If you are installing the projector on the ceiling, this projector should be installed by qualified technicians using only approved mounting equipment.

If installation work is not carried out correctly, the projector could fall down. This may result in injury or accidents. Contact your dealer to carry out the installation work.



Instructions

If you use a ceiling mount and apply adhesives to the mount to prevent the screws from loosening, or if you use lubricants or oils on the projector, the projector housing may crack and the projector may fall from its ceiling mount. This could cause serious injury to anyone under the mount and could damage the projector. When installing or adjusting a ceiling mount, do not use adhesives to prevent the screws from loosening and do not use oils or lubricants.



Do not do

Do not use the projector where it may be exposed to rain, water, or excessive humidity.



Do not use in
wet areas

Warning

Use the type of power source indicated on the projector. Use of a different power source may result in fire or electric shock. If you are not sure of the power available, consult your dealer or power company.



Do not do

Check the specifications of the power cable. Using an inappropriate power cable could result in fire or electric shock.

The power cable supplied with the projector is intended to comply with power supply requirements for the country of purchase. If you use the projector in the country where it was purchased, only use the power cable that came with the projector. If you use the projector in a country other than where it was purchased, use the correct power cable for that country.



Instructions

Take the following precautions when handling the plug.

Failure to comply with these precautions could result in fire or electric shock.

- Do not overload wall outlets, extension cables, or power strips.
- Do not insert the plug into a dusty outlet.
- Insert the plug firmly into the outlet.
- Do not hold the plug with wet hands.
- Do not pull the power cable when disconnecting the plug; always be sure to hold the plug when disconnecting it.



Instructions

Do not use the power cable that is damaged. Fire or electric shock may result.

- Do not modify the power cable.
- Do not place heavy objects on top of the power cable.
- Do not bend, twist or pull the power cable excessively.
- Keep the power cable away from hot electrical appliances.

Contact your dealer if the cable becomes damaged.



Do not do

Do not touch the plug during an electrical storm. Otherwise, you may receive an electric shock.



Do not touch

Warning

Do not place any containers of liquid on top of the unit.

Spilling liquid of any kind into the projector may result in fire or electric shock.



Do not
wet

Do not look into the lens when the projector is on. The bright light can damage your eyes.



Do not do

Do not insert or drop metal, flammable, or foreign objects into the projector's vents or openings nor leave them nearby.

Doing so may result in fire, electric shock, or burns.



Do not do

A mercury lamp with high internal pressure is used as the projector's light source. Be sure to observe the instructions below. If the following points are not observed, injury or poisoning may result.



Instructions

- Do not disassemble or damage the lamp or subject it to any impacts.
- The gases inside mercury lamps contain mercury vapor. If the lamp breaks, ventilate the room to prevent the gases that are released from being inhaled or coming into contact with the eyes or mouth.
- Do not bring your face close to the projector while it is in use.
- Particular care should be taken when the projector is installed to a ceiling, as small pieces of glass may fall down when the lamp cover is removed. When cleaning the projector or replacing the lamp yourself, be very careful not to allow such pieces of glass to get into the eyes or mouth.

If the lamp breaks and gases or fragments of broken glass from the lamp are inhaled or get into the eyes or mouth, or if any other ill effects are noticed, immediately seek medical advice. In addition, consult your local regulations regarding proper disposal and do not place in the trash.

Warning

Do not leave the projector or the remote control with batteries inside a vehicle with the windows closed, in places where they will be exposed to direct sunlight, or in other places that may become extremely hot.

Thermal deformation or technical malfunction may occur, which could result in fire.



Do not do

Do not use sprays containing a flammable gas to remove dirt or dust which is adhering to parts such as the lens or filter of the projector.

Because the lamp inside the projector becomes very hot during use, the gases may ignite and result in a fire.



Do not do

Do not use the projector in places where flammable gases or explosive gases may be present in the atmosphere.

Because the lamp inside the projector becomes very hot during use, the gases may ignite and result in a fire.



Do not do

Do not place any objects that are easily flammable in front of the projector's lens, otherwise a fire may occur.



Do not do

Caution

Do not use the projector in places where there is a lot of humidity or dust, near cooking or heating appliances, or in places where it may come into contact with smoke or steam.

Do not use or store this projector outdoors for an extended length of time.

Fire or electric shock may result.



Do not do

Caution

Do not block the slots and opening in the projector case. They provide ventilation and prevent the projector from overheating.

- If setting up the projector near a wall, leave a space of at least 20 cm between the wall and the air exhaust vent.
- Do not place the projector in the following locations.
 - Badly ventilated or narrow places, such as inside a closet or in a book case.
 - On a rug, bedding, blanket, and so on.
 - Do not cover the projector with a blanket, curtain, or tablecloth.
 - Badly ventilated locations such as inside an AV rack or cabinet.
 - Locations subject to high temperatures, such as near heating equipment.



Do not do

Do not place the projector on an unstable cart, stand, or table. The projector may fall down or tip over, and injury may result.



Do not place
on an
unstable
surface

Do not stand on the projector or place heavy objects on it. You may fall over resulting in injury or the projector may become damaged.



Do not do

Do not place anything that can become warped or damaged by heat near the exhaust vents. Do not bring your hands or face close to the vents while projection is in progress.

Because of hot air coming out from the air exhaust vents, you could get burnt or it could be a cause of warping or other damage to property.



Do not do

Do not block the light coming out of the projector's lens with a book or the lens cover.

If the projector's light shines on something for a long time, it will heat it, which may melt the lens cover, cause burns, or start a fire. Also, the reflected light may heat the lens and damage the projector. Use the A/V Mute function to temporarily stop projecting, or turn the power off for a long interval.



Do not do

Caution

Never try to remove the lamp immediately after use because it will be extremely hot. Before removing the lamp, turn off the power and wait the duration specified in the User's Guide to allow the lamp to cool completely.

The heat may cause burns or other injuries.



Do not do

Do not place the source of an open flame, such as a lit candle, on or near the projector.



Do not do

Unplug the projector when it will not be used for extended periods. The insulation may deteriorate, which may result in fire.



Disconnect
the plug from
the outlet

Be sure to check that the power is turned off, the plug is disconnected from the outlet and all cables are disconnected before moving the projector.

Fire or electric shock may result.



Disconnect
the plug from
the outlet

Unplug the projector from the outlet before cleaning.

This avoids electric shock during cleaning.



Disconnect
the plug from
the outlet

Use a dry cloth (or, for stubborn dirt or stains, a moist cloth that has been wrung dry) for cleaning. Do not use liquid, aerosol cleaners, or solvents such as alcohol, thinner or benzene.

Water infiltration or deterioration and breakage of the projector housing could result in electric shock.



Instructions

Caution

Incorrect battery usage may cause leakage of battery fluid and battery rupture, which could result in fire, injury or corrosion of the projector. When replacing batteries, take the following precautions.



Instructions

- Insert batteries so that the polarities (+ and -) are correct.
- Do not use batteries of different types or mix old and new batteries.
- Do not use any batteries other than those specified in the *User's Guide*.
- If the batteries leak, wipe away battery fluid with a soft cloth. If fluid gets on your hands, wash them immediately.
- Replace the batteries as soon as they run out.
- Remove the batteries if you will not be using the projector for a long period of time.
- Do not expose batteries to heat or flame and do not put them in water.
- Dispose of used batteries according to local regulations.
- Keep these batteries out of the reach of children. Batteries are choking hazards and are very dangerous if swallowed.

Follow the maintenance schedule for this projector. If the interior of the projector has not been cleaned for a long time, dust may build up, which could cause fire or electric shock.



Instructions

Replace your air filter periodically as needed.

Contact your dealer to clean the interior of the projector as needed.

Do not use the projector in places where corrosive gas, such as sulfurous gas from hot springs, may be present.



Do not do

Malfunction may result.

Do not start the projector while the volume is too high. (only models with built-in speaker)



Instructions

Loud sounds may cause loss of hearing. Always lower the volume before turning off the projector. Gradually increase the volume after turning on the projector.

Avoid standing in front of the projector so you do not block the projected images and the bright light does not shine in your eyes.



Instructions


Looking into the projector's light can damage your eyesight.

Notes on Handling and Storage


Be sure to observe the following precautions to avoid malfunctions, operating errors or damage to the projector.

Notes on Handling and Storage

- Do not use or store the projector in places where it might be subjected to high and low extremes of temperature. Furthermore, avoid places where the temperature may change suddenly.
- Be sure to observe the operating temperatures and storage temperatures given in the User's Guide when using and storing the projector.
- Do not set up the projector in places where it might be subjected to vibration or shock.
- Do not set up the projector near high-voltage electrical wires or sources of magnetic fields.
These may interfere with correct operation.
- Do not operate the projector under any of the following conditions. If this is not observed, problems with operation or accidents may result.



While the projector is standing on its side.



While the projector is tilted one side.

- Do not tilt the projector forwards or backwards at an angle that is greater than specified in the User's Guide. Doing so may damage the projector or cause an accident.
- Do not touch the lens with bare hands.
- Always attach the lens cover to the lens when not using the projector, to prevent the lens from becoming dirty or damaged.
- Remove the batteries from the remote control before storage.
If the batteries are left in the remote control for long periods, they may leak.
- Do not use or store the projector in places where smoke from oil or cigarettes may be present, as it can adversely affect the quality of the projected images.
- Contact your dealer to clean the interior of the projector. If the interior of the projector has not been cleaned for a long time, dust may build up, which could cause fire or electric shock.

- Epson takes no responsibility for loss or damage caused by damage to the projector or lamp failures outside service warranty conditions.
- When a still image is displayed for a long period of time, image retention may occur on the screen. Do not display images in the exact same position for long periods.

Projection Lamp

A mercury lamp with high internal pressure is used as the projector's light source. The characteristics of the mercury lamp are:

- The intensity of the lamp decreases with use.
- When it is time for replacement, the lamp will no longer light or may break with a loud noise.
- The interval of lamp replacement may vary greatly depending on the individual lamp characteristics and the operating environment. You should always have a spare lamp ready in case it is needed.
- Do not turn the projector on immediately after turning it off. Turning the projector on and off frequently may shorten the life of the lamp.
- Once the lamp replacement period has elapsed, the possibility of the lamp breakage becomes greater. When the lamp replacement message appears, replace the lamp with a new one as soon as possible.

LCD Panel

The LCD panel is manufactured using extremely high-precision technology. However, black dots may appear on the panel, or some red, blue or green dots may light up extremely brightly at times. Furthermore, sometimes striped color irregularities or brightness irregularities may also appear. They are caused by the characteristics of the LCD panel, and are not a sign of a malfunction.

Notes on Carrying the Projector

- Turn off the projector power and then disconnect the power cable from the outlet.
Furthermore, check that all other cables have been disconnected.
- Attach the lens cover to the lens.
- Retract the adjustable foot.
- If your model of projector has a handle, hold the projector by the handle when carrying it.

When transporting the projector to the manufacturer for repairs

The internal projector components consist of many glass parts and high-precision parts. When transporting the projector, take the following measures to protect the projector from any damage that might result from shock.

Enclose the projector securely in buffer material to protect it from shock, and place it into a strong cardboard container. Be sure to notify the carrier company that the contents are fragile.

Power cables for Overseas Use

The power cable that is supplied with this projector conforms to electrical safety regulations. Do not use a power cable other than the one supplied with the projector.

If using the projector overseas, check the power supply voltage, outlet shape and electrical rating of the projector that conform to the local standards, and purchase a proper power cable in the country.

Contact an authorized Epson dealer in one of the countries listed on page 17 for details on obtaining a proper power cable.

General power cable specifications

The following conditions must be observed regardless of the country of use.

- The power cable must have the approval marks from the standards authority of the country where the projector is to be used.
- The plug must be of the same shape as the outlets in the country of use.

Examples of standards authorities or certification marks for different countries

Country name	Standards authority or certification mark	Country name	Standards authority or certification mark
United States of America	UL	Norway	NEMKO
Canada	CSA	Finland	FIMKO
United Kingdom	BSI	France	LCIE
Italy	IMQ	Netherlands	KEMA
Australia	SAA	Belgium	CEBEC
Austria	OVE	Japan	PSE
Switzerland	SEV	Korea	EK
Sweden	SEMKO	China	CCC
Denmark	DEMKO	Singapore	PSB
Germany	VDE		

Utility Software

The software contained in the software CD-ROM that is supplied with the projector can also be downloaded from the Epson web site (<http://www.epson.com>). If the software is updated, the latest versions of the software will also be available from this web site.

Please check the Epson web site (<http://www.epson.com>) for the latest software upgrades.

If your projector develops a problem, make a copy of these check sheets and use them to explain the problem symptoms more clearly when calling for service.

Problems

- ☐ Power does not turn on
- ☐ Nothing appears on the screen
- ☐ A message appears
 - ☐ No image signal is being input
 - ☐ These signals cannot be handled by this projector.
- ☐ Blue screen (blue background)
- ☐ Black screen (black background)
- ☐ Projected images
- ☐ User's logo (no message appears)

Image is truncated or small

- ☐ Only part of the image is displayed
- ☐ Image is smaller than size of screen
- ☐ Image has keystone distortion
- ☐ Several pixels are missing

Image quality is poor

- ☐ Image is blurry and out of focus
- ☐ Image contains striped patterns
- ☐ Image flickers
- ☐ Characters appear to be missing

Audio (only models with built-in speaker)

- ☐ No sound is heard
- ☐ Volume is low
- ☐ Sound is distorted
- ☐ Wrong sound is heard
- ☐ Has the connected equipment been set to output audio?
- ☐ Does the sound come out when external speakers are connected? (if equipped with an Audio Out port)

Color is poor or too dark

- ☐ Too dark
- ☐ Color is poor or too dark (video)
- ☐ Color is poor or too dark (computer)
- ☐ Color different from TV/CRT

Menus

- ☐ Menus appear
 - Setting ☐ Sleep Mode : ON
- ☐ About (Video)
 - Lamp h
 - Video Signal ☐ AUTO
 - ☐ NTSC
 - ☐ Other
- ☐ About (Computer)
 - Lamp h
 - Frequency H Hz
 - V Hz
 - SYNC Polarity H ☐ Positive
 - ☐ Negative
 - V ☐ Positive
 - ☐ Negative
 - SYNC Mode ☐ Separate
 - ☐ Composite
 - ☐ Sync on Green
 - Resolution ×
 - Refresh Rate Hz

Menus





- ☐ Menus appear
 - ☐ Audio
 - Audio input ()
 - Volume ()

Problem Check Sheets

Write symptoms here:

EMP-
EH-
EB-
Serial number

Purchase date: / /
Indicators
(Write down colors and status of
each indicator)

 Indicator ☐
 Indicator ☐
 Indicator ☐
 Indicator ☐

Power cable
☐ Is the cable securely connected?
☐ Power switch ON (depends on model)


Connector
☐ Is the connector securely connected?

Computer settings
(Display properties)
☐ LCD display
Resolution
(×)
Refresh rate
(Hz)

☐ Computer
Win/Mac/EWS
Manufacturer
()
Model
()
Laptop/Desktop/Integrated
Panel resolution
(×)
Video mode
()

☐ Video equipment
VCR/DVD/Camera
Manufacturer ()
Model ()

Connectors
☐ Is the connector securely
connected?
☐ What is the name of the port
used for connection?
()



Connection cable
☐ Genuine
☐ Extension m
Part No. ()
☐ Distributor/amplifier
Part No. ()
☐ Switch
Part No. ()

When does the problem occur? ☐ Before use ☐ Immediately after starting to use ☐ During use
e.g. always when is done
☐ Other ()

Frequency of problem ☐ Always ☐ Sometimes (..... times during)
e.g. always when is done
☐ Other ()

Epson Projector Contact List



This address list is current as of August 2012.

A more up-to-date contact address can be obtained from the corresponding website listed here. If you do not find what you need on any of these pages, please visit the main Epson home page at www.epson.com.

< EUROPE, MIDDLE EAST & AFRICA >

ALBANIA :

ITD Sh.p.k.
Gjergji Center
Rr Murat Toptani
04000 Tirana
Albania
Tel: 00355 4 2256031
Fax: 00355 4 2256013
<http://www.itd-al.com>

AUSTRIA :

Epson Deutschland GmbH
Buopark Donau Inkustrasse
1-7 / Stg. 6 / 2. OG
A-3400 Klosterneuburg
Austria
Tel: +43 (0) 2243 - 40 181 - 0
Fax: +43 (0) 2243 - 40 181 - 30
<http://www.epson.at>

BELGIUM :

**Epson Europe B.V.
Branch office Belgium**
Belgicastraat 4 - Keiberg,
B-1930 Zaventem
Belgium
Tel: +32 2/ 7 12 30 10
Fax: +32 2/ 7 12 30 20
Hotline: 070 350120
<http://www.epson.be>

BOSNIA AND HERZEGOVINA :

NET d.o.o. Computer Engineering
Vukovarska 24
88000 Mostar
Bosnia and Herzegovina
Tel: 00387 36449660
Fax: 00387 36449669
E-mail: info@net.com.ba
<http://www.net.com.ba>

BULGARIA :

Epson Service Center Bulgaria
c/o ProSoft Central Service
Akad. G. Bonchev SRT. bl.6
1113 Sofia, Bulgaria
Tel: 00359 2 979 30 75
Fax: 00359 2 971 31 79
E-mail: info@prosoft.bg
<http://www.prosoft.bg>

CROATIA :

MR servis d.o.o.
Dugoselska cesta 5
10370 Rugvica, Croatia
Tel: 00385 16401111
Fax: 03485 13654982
E-mail: info@mrsevis.hr
<http://www.mrservis.hr>

CYPRUS :

Mechatronic Ltd.
88 Digenis Akritas Avenue
"Loizides Centre 2" 2nd Floor
CY-1061 Nicosia, Cyprus
Tel: 00357 22582258
Fax: 00357 22582222
<http://www.mechatronic.com.cy>

CZECH REPUBLIC :

**Epson Europe B.V.
Branch Office Czech Republic**
Slavickova 1a 63800 Brno
Czech Republic
Hotline: 800 142 052
E-mail: info@epson.cz
<http://www.epson.cz>

DENMARK :

Epson Denmark
Transformervej 6
2730 Herlev, Denmark
Tel: 44508585
Fax: 44508586
Hotline: 80808047
E-mail: danmark@epson.dk
<http://www.epson.dk>

ESTONIA :

Epson Service Center Estonia
c/o Kulbert Ltd.
Sirge 4,
10618 Tallinn, Estonia
Tel: 00372 671 8160
Fax: 00372 671 8161
<http://www.epson.ee>

FINLAND :

Epson Finland
Rajatorpantie 41 C FI-01640
Vantaa, Finland
Hotline: 0201 552090
<http://www.epson.fi>

FRANCE & DOM-TOM TERRITORY :

Epson France S.A.
150 rue Victor Hugo BP 320
92305 Levallois Perret
Cedex, France
Hotline: 0821017017
<http://www.epson.fr>

GERMANY :

Epson Deutschland GmbH

Otto-Hahn-Strasse 4 D-40670
Meerbusch, F.R. Germany
Tel: +49-(0) 2159-538 0
Fax: +49-(0) 2159-538 3000
Hotline: 01805 2341 10
<http://www.epson.de>

GREECE :

Oktabit S.A.

Gounari 26,
15343 Agia Paraskevi
Greece
Tel: 0030 210 6067181
Fax: 0030 210 6067180
<http://www.oktabitgr.com>

HUNGARY :

Epson Europe B.V.

Branch Office Hungary
Infopark Setany 1.
HU-1117 Budapest, Hungary
Hotline: 06 800 14 783
E-mail: infoline@epson.hu
<http://www.epson.hu>

IRELAND :

Epson (UK) Ltd.

Westside, London Road
Hemel Hempstead
Herts HP3 9TD, U.K.
Hotline: 01 679 9015
<http://www.epson.ie>

ISRAEL :

Epson Israel

2 Habonim st.
Ramat Gan, Israel
Tel: +972-3-5751833
Fax: +972-3-575161
<http://www.epson.co.il>

ITALY :

Epson Italia s.p.a.

Via M. Viganò de Vizzi, 93/95
20092 Cinisello Balsamo
Mirano, Italy
Tel: +39 02. 660321
Fax: +39 02. 6123622
Hotline: +39 06.60521503
<http://www.epson.it>

KAZAKHSTAN :

Epson Kazakhstan Rep. Office

97, Samal-2, bldg A1, 5th floor
Business Center
"Samal Towers"
Almaty 050051, Kazakhstan
Tel: +7 727 3560260
Fax: +7 727 3560260
<http://www.epson.kz>

LATVIA :

Epson Service Center Latvia

c/o ServiceNet LV
Jelgavas 36
1004 Riga, Latvia
Tel: 00 371 746 0399
Fax: 00 371 746 0299
<http://www.epson.lv>

LITHUANIA :

Epson Service Center Lithuania

c/o ServiceNet
Gaiziunu 3
50128 Kaunas, Lithuania
Tel: 00 370 37 400 160
Fax: 00 370 37 400 161
<http://www.epson.lt>

LUXEMBURG :

Epson Europe B.V. Branch office Belgium

Belgicastraat 4-Keiberg
B-1930 Zaventem
Belgium
Tel: +32 2/ 7 12 30 10
Fax: +32 2/ 7 12 30 20
Hotline: 0900 43010
<http://www.epson.be>

MACEDONIA :

Digit Computer Engineering

Bul. Partizanski Odredi
62 Vlez II mezanin
1000 Skopje, Macedonia
Tel: 00389 2 3093393
Fax: 00389 2 3093393
E-mail: digit@digit.com.mk
<http://www.digit.com.mk>

NETHERLANDS :

Epson Europe B.V. Benelux sales office

Entrada 701
NL-1096 EJ Amsterdam
Netherlands
Tel: +31 20 592 65 55
Fax: +31 20 592 65 66
Hotline: 0900 5050808
<http://www.epson.nl>

NORWAY :

Epson Norway

Fjordveien 3
1363 Høvik, Norway
Tel: 4780030030
E-mail: ksbl@telenor.com
<http://www.epson.no>

POLAND :

Epson Europe B.V.

Branch Office Poland
Ul. Bukserska 66 PL-02-690
Warszawa, Poland
Hotline: (0) 801-646453
<http://www.epson.pl>

PORTUGAL :

Epson Ibérica S.A.U.

Branch Office Portugal
Rua Gregorio Lopes, Lote 1514,
Restelo, 1400 Lisboa, Portugal
Tel: 213035400
Fax: 213035490
Hotline: 707 222 000
<http://www.epson.pt>

ROMANIA :

Epson Europe B.V.

Branch Office Romania
Strada Ion Urdareanu nr. 34
Sector 5, 050688 Bucuresti
Romania
Tel: 00 40 21 4025024
Fax: 00 40 21 4025020
<http://www.epson.ro>

RUSSIA :

Epson CIS

Schepkina street, 42,
Bldg 2A, 3rd floor
129110, Moscow, Russia
Tel: +7 (495) 777-03-55
Fax: +7 (495) 777-03-57
<http://www.epson.ru>

UKRAINE :

Epson Kiev Rep. Office

Pimonenko street, 13,
Bldg 7B, Office 15
04050, Kiev, Ukraine
Tel: +38 (044) 492 9705
Fax: +38 (044) 492 9706
<http://www.epson.ua>

SERBIA :

AVG d.o.o. Beograd

Prve pruge 31c
11080 Zemun, Beograd
Republic of Serbia
Tel: 00381 11 3191868
E-mail: office@a-v-g.rs
<http://www.a-v-g.rs>

SLOVAKIA :

Epson Europe B.V. Branch Office Czech Republic

Slavickova 1a 63800 Brno
Czech Republic
Hotline: 0850 111 429
(national costs)
E-mail: infoline@epson.sk
<http://www.epson.sk>

SLOVENIA :

Birotehnna d.o.o.

Litijska Cesta 259
1261 Ljubljana - Dobrunje
Slovenia
Tel: 00 386 1 5853 410
Fax: 00386 1 5400130
E-mail: info@birotehnna.si
<http://www.birotehnna.si>

SPAIN :

Epson Ibérica, S.A.U.

Av. de Roma, 18-26
08290 Cerdanyola del Vallès
Barcelona, Spain
Tel: 93 582 15 00
Fax: 93 582 15 55
Hotline: 902 28 27 26
<http://www.epson.es>

SWEDEN :

Epson Sweden

Box 329 192 30 Sollentuna
Sweden
Tel: 0771-400134
<http://www.epson.se>

SWITZERLAND :

Epson Deutschland GmbH

Branch office Switzerland
Zweigniederlassung Kloten
Steinackerstrasse 34
CH-8302 Kloten
Switzerland
Tel: +41 (0) 43 255 70 20
Fax: +41 (0) 43 255 70 21
Hotline: 0848448820
<http://www.epson.ch>

TURKEY :

Tecpro Bilgi Teknolojileri Tic. ve San. Ltd. Sti.

Telsizler Mah. Zincirli
Cad.No: 10 Kat 1-2
Kagithane 34410 Istanbul
Turkey
Tel: 0090 212 2684000
Fax: 0090 212 2684001
E-mail: epson@tecpro.com.tr
<http://www.tecpro.com.tr>

UK :

Epson (UK) Ltd.

Westside, London Road
Hemel Hempstead
Herts HP3 9TD, UK
Tel: (01442) 261144
Fax: (01442) 227227
Hotline: 08704437766
<http://www.epson.co.uk>

AFRICA :

Contact your dealer
Email: support@epson.co.za
<http://www.epson.co.za>
or
<http://www.epson.fr>

SOUTH AFRICA :

Epson South Africa

Grnd. Floor,
Durham Hse, Block 6
Fourways Office Park
Cnr. Fourways Blvd. & Roos Str.
Fourways, Gauteng
South Africa
Tel: +27 11 465 9621
Fax: +27 11 465 1542
Helpdesk: 0860 337766
or +27 11 201 7741
Email: support@epson.co.za
<http://www.epson.co.za>

MIDDLE EAST :

Epson (Middle East)

P.O. Box: 17383 Jebel Ali Free
Zone Dubai
UAE (United Arab Emirates)
Tel: +971 4 88 72 1 72
Fax: +971 4 88 18 9 45
Email: supportme@epson.eu
<http://www.epson.ae>

< NORTH, CENTRAL AMERICA & CARIBBEAN ISLANDS >

CANADA :

Epson Canada, Ltd.
185 Renfrew Drive
Markham, Ontario
L3R 6G3
Canada
Tel: 905-709-9475
or 905-709-3839
<http://www.epson.ca>

COSTA RICA :

Epson Costa Rica, S.A.
De la Embajada Americana
200 Sur y 300 Oeste
Pavas, San Jose
Costa Rica
Tel: 800-EPSONCR
(800-3776627)
<http://www.epson.co.cr>

MEXICO :

Epson Mexico, S.A. de C.V.
Boulevard Manuel Avila
Camacho 389
Edificio 1, Conjunto Legaria
Col Irrigación, C.P. 11500
México, DF
Tel: (52 55) 1323-2052
/ (52 55) 1323-2096
/ (52 55) 1323-2127
<http://www.epson.com.mx>

ECUADOR :

Epson Ecuador
Tel: 604-4220 (Guayaquil)
Tel: 04-604-4220
(otras ciudades)
<http://www.epson.com.ec>

U. S. A. :

Epson America, Inc.
3840 Kilroy Airport Way
Long Beach, CA 90806
USA
Tel: 562-276-4394
<http://www.epson.com>

< SOUTH AMERICA >

ARGENTINA :

Epson Argentina S.R.L.
Ave. Belgrano 970
(1092) Buenos Aires
Argentina
Tel: (5411) 5167-0300
<http://www.epson.com.ar>

BRAZIL :

Epson do Brasil
Av. Tucunará,
720 Tamboré Barueri,
Sao Paulo, SP 06460-020
Brazil
Tel: (55 11) 3956-6868
<http://www.epson.com.br>

CHILE :

Epson Chile S.A.
La Concepción 322, Piso 3
Providencia, Santiago, Chile
Tel: (562) 484-3400
<http://www.epson.cl>

COLOMBIA :

Epson Colombia Ltd.
Calle 100 No 19-54 Piso 7
Bogota, Colombia
Tel: (571) 523-5000
<http://www.epson.com.co>

PERU :

Epson Peru S.A.
Av. Canaval y Moreyra 590
San Isidro, Lima, Perú
Tel: (511) 418 0210
<http://www.epson.com.pe>

VENEZUELA :

Epson Venezuela S.A.
Calle 4 con Calle 11-1
La Urbina Sur.
Caracas, Venezuela
Tel: (58 212) 240-1111
<http://www.epson.com.ve>

< ASIA & OCEANIA >

AUSTRALIA :

Epson Australia Pty. Ltd.
3 Talavera Road,
North Ryde, NSW 2113,
Australia
Tel: 1300 361 054
<http://www.epson.com.au>

CHINA :

Epson (China) Co., Ltd.
7F, Jinbao Building,
No.89 Jinbao Street,
Dongcheng District,
Beijing,
China, 100005
Tel: (86-10) 85221199
Fax: (86-10) 85221123
Hotline: 400-810-9977
<http://www.epson.com.cn>

HONG KONG :

Epson Hong Kong Ltd.
Unit 715-723, Trade Square,
681 Cheung Sha Wan Road,
Cheung Sha Wan, Kowloon,
Hong Kong
Support Hotline:
(852) 2827 8911
Fax: (852) 2827 4383
<http://www.epson.com.hk>

INDIA :**Epson India Pvt., Ltd.**

12th Floor, The Millenia,
Tower A,
No. 1, Murphy Road,
Ulsoor,
Bangalore 560008
India
Tel: 1800 425 0011
/1860 3000 1600
<http://www.epson.co.in>

INDONESIA :**PT. Epson Indonesia**

Wisma Keiai, 16th Floor,
Jalan Jenderal Sudirman Kav. 3,
Jakarta 10220, Indonesia
Tel: 021-5723161
Fax: 021-5724357
<http://www.epson.co.id>

JAPAN :**Seiko Epson Co.****Toyoshina Plant**

VP Customer Support Group:
6925 Toyoshinatazawa,
Azumino-shi, Nagano-ken,
399-8285 Japan
Tel: 0263-87-5814
Fax: 0263-87-5813
<http://www.epson.jp>

KOREA :**Epson Korea Co., Ltd.**

11F Milim Tower,
825-22 Yeoksam-dong,
Gangnam-gu, Seoul,
135-934 Korea
Tel : 82-2-558-4270
Fax: 82-2-558-4272
<http://www.epson.co.kr>

MALAYSIA :**Epson Malaysia Sdn. Bhd.**

3rd Floor, East Tower,
Wisma Consplant 1,
No.2, Jalan SS 16/4,
47500 Subang Jaya,
Malaysia
Tel: 03 56 288 288
Fax: 03 56 212 088
<http://www.epson.com.my>

NEW ZEALAND :**Epson New Zealand**

Level 2,
7-9 Fanshawe Street,
Auckland Central, 1010
New Zealand
Tel: 09 366 6855
Fax: 09 366 6865
<http://www.epson.co.nz>

PHILIPPINES :**Epson Philippines Co.**

8th Floor, Anson's Center,
#23 ADB Avenue,
Pasig City 1605,
Philippines
Tel: 632-7062609
Fax: 632-7062663
<http://www.epson.com.ph>

SINGAPORE :**Epson Singapore Pte. Ltd.**

1 HarbourFront Place,
#03-02 HarbourFront Tower 1,
Singapore 098633
Tel: 6586 3111
<http://www.epson.com.sg>

TAIWAN :**Epson Taiwan****Technology & Trading Ltd.**

14F, No. 7, Song Ren Road,
Taipei, Taiwan
Tel: (02) 8786-6688
Fax: (02) 8786-6633
<http://www.epson.com.tw>

THAILAND :**Epson (Thailand) Co.,Ltd.**

195 Empire Tower, 42nd Floor,
South Sathorn Road,
Yannawa, Sathorn,
Bangkok 10120, Thailand
Tel: 02 685 9888
Fax: 02 685 9889
<http://www.epson.co.th>