

Supplemental Information for CD-ROMs

This sheet contains supplemental information about the EPSON Stylus Scan Software CD-ROM and other application software CD-ROMs. It is divided into the following sections:

1. About the online manuals
2. Software Installation Instructions

The applications come with either an online manual or an introductory guide that contains information you should read before installing the software.

An explanation of how to read PDF files is in "1. About the online manuals for the software". Please note that some of the software manuals include instructions for the retail version of the software. There may be some minor differences between the software described and what is on the CD-ROMs. Please read "2. Software Installation Instructions" for supplemental information about the installation procedure.

Note:

Depending on your location, not all of the described software may be included.

1. About the online manuals

In the following application, see the On-line Manual before installing the software.

- Adobe® PhotoDeluxe® Business Edition

In the following applications, the On-line manual is installed at the same time the software is installed.

- EPSON SMART PANEL (for Windows)
- WinFax BASIC EDITION (for Windows)
- Presto!™ PageManager for EPSON (for Macintosh)

The following application does not include an On-line Manual. Please see On-line Help.

- Personal Copy (for Macintosh)
- EPSON Scan! 2

How to install Acrobat® Reader

It is necessary to have Acrobat Reader installed to view a PDF file. Please install Acrobat Reader using the following procedure.

For Windows

Load the EPSON Stylus Scan Software CD-ROM in the CD-ROM drive. Then select Acrobat Reader to install it from the EPSON Software Setup which starts automatically.

For Macintosh

1. Load the EPSON Stylus Scan Software CD-ROM in the CD-ROM drive.
2. Double click the Acrobat Reader folder and open the language folder.
3. Double clicking on the Installer starts the installation process.
4. Afterward, please follow the instructions which appear on the screen.

Where to find the online guides

- Adobe PhotoDeluxe Business Edition
Insert the Adobe PhotoDeluxe Business Edition CD-ROM into your CD-ROM drive. After the opening sequence, Click Step 2: PhotoDeluxe Business Edition Documentation, then Getting Started Guide.
- EPSON SMART PANEL (for Windows)
After the software has been installed, select the On-line Manual in the EPSON SMART PANEL in the Start Menu in the lower left corner of the Windows screen.
- Presto! PageManager for EPSON (for Macintosh)
Insert the EPSON Stylus Scan Software CD-ROM into your CD-ROM drive, and install Presto! PageManager. The user's guide for PageManager, "PageManager User's Manual", appears in the "Presto! PageManager for EPSON" folder.

2. Software Installation Instructions

The following instructions explain how to install the software included on the EPSON Stylus Scan Software CD-ROM and other CD-ROMs. Installation instructions are included in the software manuals or the affiliated online guides. Be aware that some software manuals include instructions for the retail version. There may be minor differences between the software described and what is on this CD-ROM. If the instructions in the software manual differ from the following, please follow the instructions below:

How to install software

- Software on the EPSON Stylus Scan Software CD-ROM
Load the EPSON Stylus Scan Software CD-ROM in the CD-ROM drive. Then install the application using the EPSON Software Setup, which starts automatically. For details, please see the *Setup Guide*.
EPSON Scan! 2 is not installed by the EPSON Software Setup Utility. Install it by the following method.
 1. Load the EPSON Stylus Scan Software CD-ROM in the CD-ROM drive to display the contents of the CD-ROM.
 2. Double click on the Language folder under EPSCAN2 and open it, then double click Setup.exe.
- Adobe PhotoDeluxe Business Edition
 1. Insert the PhotoDeluxe CD-ROM that includes your preferred language version in your CD-ROM drive.
 2. Click Step 1: Install PhotoDeluxe..., and then Install PhotoDeluxe... in the dialog box that appears. Then follow the on-screen messages. If the dialog box does not appear, open the CD folder and double-click AutoPlay.exe.