

Supplemental Information for CD-ROMs

This booklet provides supplemental information about the Scanner Software CD-ROM and other software CD-ROMs, and includes the following sections.

- Reading PDF Online Manuals
- Software Installation Instructions

Before installing each application, please read the accompanying user documentation. For instructions on accessing and viewing online manuals, see "Reading PDF Online Manuals" below.

Note:

Some manuals include instructions for the retail version of the software. There may be minor differences between the software described and the software on the CD-ROMs. See "Software Installation Instructions" on page 3 for more information about the installation procedure.

Reading PDF Online Manuals

The following applications include PDF files that function as online manuals:

- EPSON SMART PANEL for Scanner
- Adobe PhotoDeluxe™ 4.0 HOME EDITION (Windows)
- Adobe PhotoDeluxe™ 2.0 (Macintosh)
- TextBridge® Pro 8.0 (Windows)
- TextBridge® Pro 8.5 (Macintosh)
- Adobe Photoshop® 5.0LE (For EPSON Perfection 1640SU Photo users only.)

Installing Acrobat Reader

To read PDF files, you need to install Acrobat Reader on your computer. Follow the directions below.

Windows

1. Insert the Scanner Software CD-ROM into your CD-ROM drive.
2. In the dialog box that appears, select your preferred language.
If a dialog box does not automatically appear, open the CD folder and double-click CDSETUP.exe, then select your preferred language.
3. Click the Add Software icon, then make sure that Adobe Acrobat Reader is listed with a check mark in the application list.
4. Click the OK button.

Macintosh

1. Insert the Scanner Software CD-ROM into your CD-ROM drive.
2. Double-click the Acrobat Reader folder.
3. Double-click the Reader Installer icon in the folder of your preferred language.
4. After installation, double-click any of the PDF files on the CD-ROM to read them.

Finding the PDF files

Windows

EPSON SMART PANEL for Scanner

You need to install EPSON SMART PANEL for Scanner before you can access the PDF manual for it. See the next section for installation instructions. After installation, User's Manual appears in the EPSON SMART PANEL for Scanner folder.

Adobe PhotoDeluxe 4.0 HOME EDITION

Insert the PhotoDeluxe CD-ROM into your CD-ROM drive and follow the instructions on the screen.

TextBridge Pro 8.0

You need to install TextBridge Pro before you can access the PDF manual for it. See the next section for installation instructions. After installation, User Guide appears in the TextBridge Pro 8.0 folder.

Adobe Photoshop 5.0LE

Insert the Photoshop CD-ROM into your CD-ROM drive. The user's guide for Photoshop is a file named User Guide.pdf which is located in your preferred language folder. Other PDF files contain support information.

Macintosh

EPSON SMART PANEL for Scanner

You need to install EPSON SMART PANEL for Scanner before you can access the PDF manual for it. See the next section for installation instructions. After installation, the user's guide, SMART PANEL for Scanner Manual, is located in the EPSON SMART PANEL for Scanner folder.

Adobe PhotoDeluxe 2.0

Insert the PhotoDeluxe CD-ROM into your CD-ROM drive. The user's guide for PhotoDeluxe, Getting Started.pdf, is located in the Open Me First! folder.

TextBridge Pro 8.5

1. Double-click the TextBridge[®] Pro-Documents folder that appears in the TextBridge[®] Pro folder.
2. Double-click your preferred language.
3. Double-click the GettingStarted.pdf icon.

Adobe Photoshop 5.0LE

1. Insert the Photoshop CD-ROM into your CD-ROM drive.
2. Double-click the Adobe® Photoshop® 5.0LE icon on the desktop.
3. Double-click your preferred language folder.
4. Double-click the User Guide.pdf icon.

Software Installation Instructions

The following instructions explain how to install the software included on the Scanner Software CD-ROM and other CD-ROMs. Installation instructions are also included in the software documentation.

Note:

There may be minor differences between the software described in your software documentation and what is on this CD-ROM. If the installation instructions in the software documentation differ from the following instructions, please follow the instructions below.

Installing the software

Windows

Programs on the Scanner Software CD-ROM

You can install most of the programs on the CD-ROM from the EPSON Software Setup dialog box that appears on your screen after you insert the CD-ROM into your CD-ROM drive. See Chapter 2 of the Perfection 1640SU *Startup Guide* for details.

To install EPSON Scan! II, double-click Setup.exe in the Epscan2 folder. See EPSON Scan! II's online help for operating instructions.

Adobe PhotoDeluxe 4.0 HOME EDITION

1. Insert the PhotoDeluxe CD-ROM in your CD-ROM drive.
2. Select your preferred language from the menu box that appears on the screen.
3. Click the install button.

Note:

Adobe PhotoDeluxe must be installed in order to use the "Scan for Creativity" function of EPSON SMART PANEL for Scanner.

TextBridge Pro 8.0

1. Insert the TextBridge Pro CD-ROM in your CD-ROM drive.
2. Select your preferred language from the menu box that appears on the screen.
3. Follow the instructions.

Adobe Photoshop 5.0LE

1. Insert the Photoshop CD-ROM in your CD-ROM drive.
2. Double-click My Computer.
3. Double-click the CD-ROM drive icon.
4. Double-click your preferred language folder.
5. Double-click the Photosle folder.
6. Double-click the setup.exe icon and follow the instructions on the screen.

Macintosh

EPSON SMART PANEL for Scanner

1. Insert the Scanner Software CD-ROM into your CD-ROM drive.
2. Select your preferred language folder from the Scanner Software CD-ROM folder.
3. Double-click the EPSON SMART PANEL for Scanner icon.

Adobe PhotoDeluxe 2.0

1. Insert the PhotoDeluxe CD-ROM in your CD-ROM drive.
2. Double-click the Adobe PhotoDeluxe™ Installer icon in the folder of your preferred language. Then follow the on-screen instructions.

Note:

Adobe PhotoDeluxe must be installed in order to use the "Scan for Creativity" function of EPSON SMART PANEL for Scanner.

TextBridge Pro 8.5

1. Insert the TextBridge Pro CD-ROM in your CD-ROM drive.
2. Double-click the Install TextBridge® Pro icon.
3. Select your preferred language from the menu box that appears on the screen.
4. Follow the instructions on the screen.

Adobe Photoshop 5.0LE

1. Insert the Photoshop CD-ROM in your CD-ROM drive.
2. Double-click the Adobe® Photoshop® 5.0LE icon.
3. Double-click your preferred language folder.
4. Double-click the Adobe Photoshop® 5.0LE folder.
5. Double-click the Install Photoshop® LE icon.
6. Follow the instructions on the screen.