





# Notations Used in This Guide



 <b>CAUTION</b>	Indicates procedures which may result in damage or injury if sufficient care is not taken.
 <b>TIP</b>	Indicates additional information and points.
	Indicates a page where useful information regarding a topic can be found. Click on the page number to display that page.
	Indicates that an explanation of the underlined word or words in front of this symbol appears in the glossary of terms. Click the underlined word or words to display the corresponding entry in the " <a href="#">Glossary</a> ".
<b>PROCEDURE</b>	Indicates operating methods and the order of operations. The procedure indicated should be carried out in the order of the numbers.
[(Name)]	Indicates names of buttons on the projector's control panel and on the remote control, and also names of the projector's input and output ports. Example: [Esc]
[(Menu name)]	Indicates buttons and menu names that appear on the screen. Example: "OK"

## ■ Meaning of "unit" and "projector"

When "unit" or "projector" appears in the text of this *Guide*, it may refer to items which are accessories or optional equipment in addition to the main projector unit itself.

## ■ Computer descriptions

In these manuals, operations that are the same for both Windows and Macintosh are given using Windows as an example. Separate explanations are given in cases where the operations are different.