

EPSON

MM PROJECTOR ULTI EDIA

EMP-S4

[Troubleshooting](#)[Notations Used in This Guide](#)[Index](#)[Understanding This Guide](#)[Glossary](#)[Saving This Guide on a Computer](#)

User's Guide

[Projector Features](#)

[Part Names and Functions](#)

[Adjusting and changing the image](#)

This explains how to adjust the quality of the image, the volume, the colour mode selection and so on, and also how to change the image.

[Useful Functions](#)

This explains useful functions for giving presentations and so on, and the security functions.

[Configuration Menu](#)

This explains how to use the configuration menu and its functions.

[Appendices](#)

This provides information on maintenance procedures to ensure the best level of performance from the projector.

[Optional Accessories and Consumables](#)

Safety Instructions

This explains how to use this unit safely. Read these notes carefully before using this unit.

[Safety Instructions](#)

[Notes on Handling and Storage](#)

World-Wide Warranty Terms

This explains support and service information for this unit.

[Utility Software](#)

[Problem Check Sheets](#)

[International Warranty Conditions](#)