



EPSON PERFECTION™ V500 PHOTO

Start her• Aloita tästä• Start her• Starta här•
 Začnite tukaj• Počnite ovdje• Почнете оттука•
 Započnite ovde

1.



2.



Tiislut ikke USB-kabelt endnu.
 Älä vielä kytke USB-kaapelia.
 Ikke koble til USB-kabelen ennå.
 Anslut inte USB-kabeln än.

Ne priključite še kabla USB.
 Nemojte još priključiti USB kabel.
 Сè уште не го поврзувајте USB кабелот.
 USB kabl još nemojte povezati.


3.



4.



Sådan finder du yderligere oplysninger• Lisätietojen saaminen•
 Mer informasjon• Skaffa mer information•
 Pridobite več informacij• Dobivanje više podataka•
 Побарај повеќе информација• Dobivanje više informacija



Epson® is a registered trademark and Epson Perfection™ and Exceed Your Vision are trademarks of Seiko Epson Corporation.
 Digital ICE is a trademark of Kodak.
 General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners.
 Epson disclaims any and all rights in those marks. © 2007 Seiko Epson Corporation. All rights reserved.