

## Check Tool for Network Projector

### DESCRIPTION


This tool is for confirming whether EMP NS Connection and Quick Wireless Connection are available on your computer.

**NOTE: This tool cannot guarantee that EMP NS Connection and Quick Wireless Connection can operate correctly on your computer.**

### SYSTEM REQUIREMENTS

- CPU Pentium M 1.6 GHz or higher
- Memory 512 MB or higher
- OS
  - Microsoft Windows Vista 32bit/Windows Vista SP1
  - Microsoft Windows XP 32bit/Windows XP SP1/Windows XP SP2/ Windows XP SP3
  - Microsoft Windows 2000 SP4


### PROCEDURE

- 1 Double-click the  [EB\_CHT.exe] file saved on your computer.
- 2 Read the contents of the [SOFTWARE LICENSE AGREEMENT], and click the [Agree] button.
- 3 A dialog indicating the program is starting opens.


This tool cuts off the network connection temporarily.  
Click the [Start] button to begin verification.



- 4 The Check tool dialog is displayed. It takes a few minutes for verification.



When two or more wireless LAN adapters are available on your computer, the adaptor selection dialog opens. Please select the desired wireless LAN adapter.



- 5 When the verification is complete, the result is displayed on the bottom of the dialog.

The result is stored in the same folder as the tool.

File Name : CheckInfo<\*\*\*\*\*>.log

\*\*\*\*\* indicates the created date and time.