


Update procedure

※CF card size that can be used for this update is 16MB to 8GB. SD card size that can be used for this update is from 16MB to 2GB. No limitation for SDHC.

IMPORTANT: If you want to update of Ver1.57 on temporary, PLEASE DO NOT TURN OFF DURING IPL UPDATE. MAIN BOARD NEEDS TO BE REPLACED IF FAILED.

- 1) Prepare memory card, and copy PSV5FIRM folder into memory card root folder (Top level folder in memory card). And connect AC adapter to viewer and insert battery to viewer. PLEASE DO NOT INSERT ANY MEMORY CARD INTO ANOTHER MEMORY CARD SLOT.
- 2) Check the AC adapter connection and battery insertion.
- 3) Please keep the memory card inserted, and turn on with OK + RATE(★) pressed. Release keys when you see the EPSON logo.
- 4) Main firmware update will start, and this takes about 3.5min.
- 5) SubCPU firmware update will start followed by main firmware release, and this takes about 3.5min. Blue LED is "NOT" blinking during this update, but this is correct behavior.
- 6) Update is successfully done when you see below screen.



- 7) Please turn off viewer by sliding PW switch.
- 8) Please turn on viewer by sliding PW switch. Please do not press any key when you turn on viewer.
- 9) Press MENU key, select [Settings]-[Delete all cache files] and press OK key.
- 10) A message suggesting AC adapter connection will be appeared. Confirm the AC connection and press OK key.
- 11) "Processing" dialog is displayed, and please wait for a while with AC adapter is connected.
- 12) "Set Date and Time" screen is displayed. So please set the date and time. Then the update is finished.

<Check the version number>

- 1) After setting date and time, HOME screen is displayed. Then select "Setup", and press OK.
- 2) Check that the "Device Information" is selected, and press OK.
- 3) Check that the "Firmware version" is selected, and press OK.
- 4) If the version is displayed as "01.71.7506-0110-0200-0112", all the update is finished normally.