

# Supplemental Information for CD-ROMs

This booklet provides supplemental information about the Perfection 610 Scanner Software CD-ROM and other software CD-ROMs, and includes the following sections:

- Reading PDF Online Manuals
- Software Installation Instructions

Before installing each application, please read the accompanying paper manual or PDF online manual. For instructions on accessing and viewing online manuals, see “Reading PDF Online Manuals” below.

## **Note:**

- Some manuals include instructions for the retail version of the software. There may be minor differences between the software described and the software on the CD-ROMs. Please read “Software Installation Instructions” on page 3 for supplemental information about the installation procedure.*
- In some locations, some of the software may be unavailable for certain scanner models.*

---

## **Reading PDF Online Manuals**

The following applications include PDF files that function as online manuals.

- Presto!™ PageManager for EPSON
- Adobe® PhotoDeluxe®

Please follow the instructions below to access to the PDF online manuals included in the CD-ROM.

## **Installing Acrobat Reader**

To read PDF files, you need to install Acrobat Reader on your computer. Follow the instructions below.

### *Windows*

1. Insert the Perfection 610 Scanner Software CD-ROM into your CD-ROM drive.
2. In the dialog box that appears, select your preferred language.  
  
If a dialog box does not automatically appear, open the CD folder and double-click Cdsetup.exe. In the dialog box that appears, select your preferred language.
3. Click the Add Software icon on the Software Setup dialog box, then make sure that “Acrobat Reader Ver.4.0” is listed with a check mark in the application list.

## **Note:**

*All the software comes with a check mark in the application list by default. If you want to read the PDF files before installing the other applications, you need to clear the check marks next to the applications you do not want to install.*

4. Click the OK button.

## *Macintosh*

1. Insert the Perfection 610 Scanner Software CD-ROM into your CD-ROM drive.
2. Double-click Reader Installer in the “Acrobat Reader\English” folder on the CD-ROM.

After you finish installation, you can read any of the online manuals by double-clicking the appropriate PDF file included in one of the CD-ROMs. See below to find the PDF file of the manual you want to read.

## **Finding the PDF files**

### *Windows*

#### ***Presto! PageManager for EPSON***

Before you can access its PDF manual, you need to install PageManager. See the next section for installation instructions. After installation, the user’s guide for PageManager, PageManager User’s Manual, appears in the “Presto! PageManager for EPSON” folder.

#### ***Adobe PhotoDeluxe***

Insert the PhotoDeluxe CD-ROM of your desired language into the CD-ROM drive. The user’s guide for PhotoDeluxe, GetStart.pdf, is in the “English” folder. Support information files can be found in the “Support” folder.

### *Macintosh*

#### ***Presto! PageManager for EPSON***

Before you can access its PDF manual, you need install PageManager. See the next section for installation instructions. After installation finishes, the user’s guide for PageManager, User’s Guide.pdf, is in the “Presto! PageManager for EPSON” folder.

#### ***Adobe PhotoDeluxe***

Insert the PhotoDeluxe CD-ROM into your CD-ROM drive. The user’s guide for PhotoDeluxe is a file named Getting Started.pdf in the “Open Me First!” folder.

---

## Software Installation Instructions

The following instructions explain how to install the software included on the Perfection 610 Scanner Software CD-ROM and other CD-ROMs. Installation instructions are also included in the software paper manuals or the included PDF online manuals.

### Note:

- ❑ *Some manuals include instructions for the retail version of the software. There may be minor differences between the software described and the software on the CD-ROMs. If installation instructions in the software documentation differs from the following instructions, please follow the instructions below.*
- ❑ *In some locations, some of the software may be unavailable for certain scanner models.*

## Installing the software

### Windows

#### **Programs on the Perfection 610 Scanner Software CD-ROM**

You can install most of the programs on the CD-ROM from the EPSON Software Setup dialog box that appears on your screen after you insert the CD-ROM into your CD-ROM drive. See Chapter 3 of the *Perfection 610 User's Guide* for details.

To install EPSON Scan! II, double-click Setup.exe in the "EPSCAN2\English" folder. See EPSON Scan! II's online help for operating instructions.

#### **Adobe PhotoDeluxe**

1. Insert the appropriate PhotoDeluxe CD-ROM in your CD-ROM drive.
2. In the dialog box that appears, select your preferred language.

If a dialog box does not automatically appear, open the CD folder and double-click Setup.exe in "English\Install" folder.

3. Follow the on-screen instructions.

### Macintosh

#### **Presto! PageManager for EPSON**

Insert the Perfection 610 Scanner Software CD-ROM in your CD-ROM drive. Double-click Presto! PageManager Installer#1 in the "Presto! PageManager\English\Presto! PageManager Disk1" folder.

#### **EPSON PersonalCopy**

Insert the Perfection 610 Scanner Software CD-ROM in your CD-ROM drive. Double-click the icon of your preferred language in the "EPSON PersonalCopy" folder.

#### **Adobe PhotoDeluxe**

1. Insert the PhotoDeluxe CD-ROM in your CD-ROM drive.
2. Double-click Adobe PhotoDeluxe™ Installer in the "English" folder.
3. Follow the on-screen instructions.

