

TRE133-60

EPSON

Technical Note

Quartz Crystal SAW Resonator FS555 Using Guide

SEIKO EPSON CORP.

Note the following points regarding the use of this guide:

1. The contents of this guide are subject to change without notice.
 2. Use of this guide in whole or in part for any other purpose, including copying or reproduction, without the permission of SEIKO-EPSON is strictly prohibited.
 3. The application circuits, programs, methods, etc., contained in this guide are provided solely for informational purposes. SEIKO-EPSON makes no warranty of any kind against violations or damages concerning the rights of third parties (including industrial property rights) that may arise from these items. Furthermore, this guide does not convey any industrial property rights belonging to third parties or to SEIKO-EPSON.
 4. When exporting products described in this guide that are considered strategic materials as stipulated under the Foreign Exchange and Foreign Trade Control Act, the export permits required under that Act must be obtained.
 5. The products described in this guide are intended for civilian use. They are not designed for applications that demand extremely high reliability, such as life support equipment. SEIKO-EPSON will bear no responsibility if these products are used in such an application.
- * The brand names and product names that appear in this manual are trademarks or registered trademarks of their respective owners.

This guide is valid until December, 1996.

CONTENTS

1. What is a SAW Resonator ?	1
2. Basic Structure and Principles of Operation	2
2.1 SAW Resonator Type	2
2.2 Structure and Operation of the Element	2
2.3 Package Construction	3
3. Equivalent Circuit and Basic Characteristics of the Resonator	3
3.1 Circle Diagram of Admittance during Resonance	3
3.2 Resonator Equivalent Circuit Diagram	4
3.3 Frequency Temperature Characteristics $P(\theta)$	4
3.4 Spurious modes	5
3.5 Drive Level Characteristics	5
4. Method of Use	6
4.1 Port Connections	6
4.2 Factors that Determine the Oscillating Frequency (f_{osc})	7
5. Measurement Methods	7
5.1 π Network Transmission Method	8
5.2 Impedance Measurement Method	9
6. Miscellaneous	10

EPSON

1. What is a SAW Resonator ?

While AT cut crystal resonators are currently well known and widely used, the first prototype SAW resonators were produced in 1974 by E.J. Staples as a frequency control element for even higher frequencies, namely, the VHF and UHF bands. Since then, SAW resonators have come to be used in RF modulators, CATV applications, faint radiowave applications, IF local oscillators, and voltage control oscillators (VCSO). SEIKO-EPSON's SAW resonators consist of a resonator (oscillator) that uses a Rayleigh wave that propagates across the crystal substrate (ST-X) surface to create a constant wave between a pair of reflectors.

The special characteristics of SAW resonators and of SEIKO-EPSON's products are described below.

Features of SAW Resonators

1. Because they are capable of basic wave oscillation, constructing circuits is easy; in addition, it is possible to avoid the unnecessary emissions that are generated when low frequencies are multiplied.
2. A low CI value can be easily obtained, making SAW resonators easy to utilize with little variation.
3. Because the frequencies are higher (250 to 500 MHz), operation is fast.

Features of the FS-555



1. The FS-555 is a compact, surface-mounted component. (Size: 5.2 x 4.8 x 1.5 mm)
2. Because the initial deviation of the frequency is low, the device offers excellent precision. (± 80 ppm)
3. Because the FS-555 is fully fixed in place all along its surface, it offers excellent impact resistance characteristics.
4. Because the FS-555 uses a crystal with a high Q value, it can be used to construct an oscillator circuit with excellent frequency stability (C/N).

2. Basic Structure and Principles of Operation

2.1 SAW Resonator Type


SEIKO-EPSON's FS-555 was designed using the one-port type.

2.2 Structure and Operation of the Element



EPSON

2.3 Package Construction




3. Equivalent Circuit and Basic Characteristics of the Resonator

3.1 Circle Diagram of Admittance during Resonance


$$Y(\omega) = G(\omega) + jB(\omega)$$

$$Y(\omega) = j\omega C_0 + 1 / \{R_1 + j(\omega L_1 - 1/\omega C_1)\} \quad (1)$$



3.2 Resonator Equivalent Circuit Diagram

An electrically equivalent circuit to the resonator is shown in the diagram below.



R_1 : Equivalent series resonance resistance

$R_1 = 1/G_s$

C_1 : Equivalent capacitance

L_1 : Equivalent inductance

C_0 : Parallel capacitance

R_r : Equivalent resistance

$R_r = 1/G_r$

$$\text{Series resonance frequency : } f_s = 1/(2\pi\sqrt{L_1 \cdot C_1}) \quad (2)$$

$$\text{Capacitance ratio: } \gamma = C_0/C_1$$

$$\text{Q value: } Q = 2\pi f_s L_1/R_1$$

3.3 Frequency Temperature Characteristics $P(\theta)$

SEIKO-EPSON's ST cut SAW resonator generally demonstrates frequency change of a second-order function. This change is expressed through the mathematical formula shown below.

$$P(\theta) = \Delta f/f_0 - \beta(\theta_0 - \theta_{\max})^2 + \beta(\theta - \theta_{\max})^2 \quad (\text{ppm}) \quad (3)$$

Where, $\Delta f/f_0$: Frequency deviation (ppm), (at 25 °C)

f_0 : Nominal frequency(Hz)

θ : Temperature(°C), $\theta_0 = 25$ (°C)

θ_{\max} : Turn-over temperature(°C)

β : Second-order temperature coefficient ,

$\beta = -3.5 \times 10^{-8} / ^\circ\text{C}^2$

EPSON

3.4 Suprious modes

The rectangular crystal substrate that forms the SAW resonator has a number of inherent resonance modes.

Those modes that have an actual effect are described below.

* **Longitudinally imharmonic mode** surface wave resonance:

Exist below the primary resonance frequency in a range of 1000 to several thousand ppm.

* **Transversely imharmonic mode** surface wave resonance:

Exist above the primary resonance frequency in a range of several hundred to several thousand ppm.

Because the equivalent resistance R_{sp} for the resonance caused by these modes is designed to be more than adequate for the primary resonance, oscillation does not normally occur at these frequencies.

Before ordering the resonator, carefully study the application for which it is to be used, especially when it is to be used in a variable frequency application, such as a VCISO.

3.5 Drive Level Characteristics

Like other electronic components, SAW resonators also have suitable levels for operating power that are appropriate drive levels. If the drive level is too high, a frequency shift may result; in an extreme case, the device could even be damaged.

The drive level characteristics indicate the resonator's frequency and the change in the equivalent series resistance for different levels of operating power supplied to the resonator. These characteristics are defined below:

* Maximum operating power (maximum drive level)

Range of power with which the resonator can be used and at which it will operate normally.

* Recommended drive level (testing drive level)

Level of operating power that will satisfy the standards indicated in the specifications.

* Operating power

$$P_w = R_L \cdot I^2 \quad (W) \quad (4)$$

R_L : Effective equivalent resistance of the resonator when it is operating
(Ω)

I : Current that flows through the resonator when it is operating (A)


SEIKO-EPSON's FS-555 has a recommended operating power of 2 mW, a maximum operating power of 10 mW, and, within its maximum operating power range a rate of change of frequency (f_r) and equivalent resistance change ($\Delta R_r/R_r$) of 5 ppm and 5%, respectively. In general, the FS-555 should be used at low power as much as possible.

4. Method of Use

Keep the following points in mind when using a SEIKO-EPSON SAW resonator in an oscillating circuit.

4.1 Port Connections

Connect the FS-555 as shown in the diagram below. Avoid the application of large DC voltages between input ports C and G.



EPSON


4.2 Factors that Determine the Oscillating Frequency (fosc)

The factors that determine the oscillating frequency differ in the following two cases, depending on how the SAW resonator load is set. The formulas given below also give an approximate value for fosc.

a) Capacitance load (fosc = f_{CL})

$$f_{osc} = f_s \{1 + C_1/2(C_0 + C_L)\} \quad (5)$$

$$R_L = R_r (1 + C_0/C_L)^2 \quad (6)$$



SAWR

Amplifier circuit

Fig.7

The negative resistance -R of the amplifier circuit must be set with adequate margin from R_L.


b) When using a coil for extension pull range

$$f_{osc} = f_{sL} \{1 + C_1/2(C_0 + C_L)\} \quad (7)$$

$$f_{sL} = 1/(2\pi\sqrt{L_{1p} \cdot C_1})$$

$$L_{1p} = L_1 + L$$

(8)



SAWR

Amplifier circuit

Fig.8

Notes

- * The floating capacitance and inductance of the substrate can affect the actual oscillation frequency; check the oscillation frequency in the actual unit.
- * Make sure that L of the extension coil is adequately smaller than L₁ of the SAW resonator. Less than -500 ppm from F_s is desirable. Stability suffers if L is too large.

5. Measurement Methods

Methods for measuring the frequency f_r (f_s) and the equivalent resistance R_r, both of which are important for evaluating SAW resonators, are described in this section. There are basically two methods that can be used to measure these values.

SEIKO-EPSON uses the π network based on the IEC standards for taking measurements.



5.1 π Network Transmission Method

Using the test circuit configuration shown in the figure below, f_r is the resonance frequency at which the transmission characteristics S_{21}^{-1} reaches phase zero. The equivalent resistance R_r is derived from the value of $S_{21}^{-1}(f_r)$ at that moment according to the following formula:

$$R_r = (KS_{21}^{-1} - 1) \cdot 25 \quad (\Omega) \quad (9)$$

where, $S_{21}^{-1} = V_A/V_B$
 $K = V_{BS}/V_{AS}$

V_{BS} and V_{AS} are the voltages V_B and V_A when the test pin is shorted.



EPSON

Regarding test samples, assuming ΔP as the difference for correcting from your oscillating circuit frequency f_{osc} , the following relationship exists (at 25°C).

$$\Delta P = -(f_{osc} - f_r) / f_0 \quad (\text{ppm}) \quad (\text{at } 25^\circ\text{C}) \quad (10)$$

where, $f_r = f_0$

f_0 : Oscillating frequency target value (Hz)

f_r : SEIKO-EPSON's measured resonance frequency
(when CL = infinity)

We can provide a π test jig for a fee.

5.2 Impedance Measurement Method

Use an impedance tester (HP4195A, HP4291A etc.) on the market to measure the SAW resonator impedance $Z(\omega) = 1/Y(\omega)$.

6. Miscellaneous

This guide provides explanations of basic matter regarding the use of SEIKO-EPSON's SAW resonator. Consult the product specifications for specific values regarding specifications mentioned in this guide. If you have any questions concerning the information provided in this guide, contact SEIKO-EPSON at:

8548 Nakaminowa, Minowa-machi, Kamiina-gun, Nagano-ken 399-46 Japan

SEIKO EPSON CORP. Ina Plant

Quartz Device Division

QD Design Engineering Department

Phone: 0265-79-2481, Fax: 0265-79-0046

Sales Offices*International*

Region	Country	Company Name	Telephone
North America	USA	Epson America, Inc.	1-310-782-0770
Europe	Germany	Epson Europe Electronics GmbH.	49-89-14005-0
Asia	Taiwan	Epson Electronics Trading LTD, Taiwan Branch	886-2-717-7360
	Hong Kong	Epson Electronics Trading LTD.	852-5854600
	Korea	Seiko Epson Corp. Korea Office	82-2-784-6027
	Singapore	Epson Singapore PTE. LTD.	65-533-0477

Issued on Mar. 1996

SEIKO EPSON CORPORATION
QD Sales Engineering Group

EPSON

Technical Note

Quartz Crystal SAW Resonator FS555 Using Guide

SEIKO EPSON CORP.

Quartz Device Division

8548 Nakaminowa, Minowa-machi, kamiina-gun, Naganoken, 399-46 Japan

Phone:(81)265-70-5254(DIR.) Fax:(81)265-79-9492