

CMOS 4-BIT SINGLE CHIP MICROCOMPUTER **E0C6233**

DEVELOPMENT TOOL MANUAL
(EVA6S32R Support)



NOTICE

No part of this material may be reproduced or duplicated in any form or by any means without the written permission of Seiko Epson. Seiko Epson reserves the right to make changes to this material without notice. Seiko Epson does not assume any liability of any kind arising out of any inaccuracies contained in this material or due to its application or use in any product or circuit and, further, there is no representation that this material is applicable to products requiring high level reliability, such as medical products. Moreover, no license to any intellectual property rights is granted by implication or otherwise, and there is no representation or warranty that anything made in accordance with this material will be free from any patent or copyright infringement of a third party. This material or portions thereof may contain technology or the subject relating to strategic products under the control of the Foreign Exchange and Foreign Trade Control Law of Japan and may require an export license from the Ministry of International Trade and Industry or other approval from another government agency. Please note that "E0C" is the new name for the old product "SMC". If "SMC" appears in other manuals understand that it now reads "E0C".

MS-DOS and EDLIN are registered trademarks of Microsoft Corporation, U.S.A.

PC-DOS, PC/AT, VGA, EGA and IBM are registered trademarks of International Business Machines Corporation, U.S.A.

NEC PC-9801 Series and NEC are registered trademarks of NEC Corporation.

All other product names mentioned herein are trademarks and/or registered trademarks of their respective owners.

E0C6233 Development Tool Manual

PREFACE

This manual mainly explains the outline of the development support tool for the 4-bit Single Chip Micro-computer E0C6233.

Refer to the "E0C62 Family Development Tool Reference Manual" for the details (common to all models) of each development support tool. Manuals for hardware development tools are separate, so you should also refer to the below manuals.

<i>Development tools</i>	☞ E0C62 Family Development Tool Reference Manual EVA6S32R Manual ICE62R (ICE6200) Hardware Manual
<i>Development procedure</i>	☞ E0C62 Family Technical Guide
<i>Device (E0C6233)</i>	☞ E0C6233 Technical Manual
<i>Instructions</i>	☞ E0C6200/6200A Core CPU Manual

CONTENTS

1 COMPOSITION OF DEVELOPMENT SUPPORT TOOL	1
1.1 Configuration of DEV6233	1
1.2 Developmental Environment	1
1.3 Development Flow	2
1.4 Production of Execution Disk	3
2 DEVELOPMENT TOOL MANAGEMENT SYSTEM DMS6200	4
2.1 DMS6200 Outline	4
2.2 DMS6200 Quick Reference	4
3 CROSS ASSEMBLER ASM6233	5
3.1 ASM6233 Outline	5
3.2 E0C6233 Restrictions	5
3.3 ASM6233 Quick Reference	6
4 FUNCTION OPTION GENERATOR FOG6233	8
4.1 FOG6233 Outline	8
4.2 E0C6233 Option List	8
4.3 Option Specifications and Selection Message	10
4.4 FOG6233 Quick Reference	17
4.5 Sample File	19
5 SEGMENT OPTION GENERATOR SOG6233	22
5.1 SOG6233 Outline	22
5.2 Option List	22
5.3 Segment Ports Output Specifications	23
5.4 SOG6233 Quick Reference	24
5.5 Sample Files	26

CONTENTS

6 ICE CONTROL SOFTWARE ICS6233	28
6.1 ICS6233 Outline	28
6.2 ICS6233 Restrictions	28
6.3 ICS6233 Quick Reference	30
7 MASK DATA CHECKER MDC6233	33
7.1 MDC6233 Outline	33
7.2 MDC6233 Quick Reference	33
APPENDIX A. E0C6233 INSTRUCTION SET	36
B. E0C6233 RAM MAP	40
C. E0C6233 I/O MEMORY MAP	43
D. TROUBLESHOOTING	45

1 COMPOSITION OF DEVELOPMENT SUPPORT TOOL

Here we will explain the composition of the software for the development support tools, developmental environment and how to generate the execution disk.

1.1 Configuration of DEV6233

The below software are included in the product of the E0C6233 development support tool DEV6233.

1. Development Tool Management System DMS6200 Menu selection for each software / start-up software
2. Cross Assembler ASM6233 Cross assembler for program preparation
3. Function Option Generator FOG6233 Function option data preparation program
4. Segment Option Generator SOG6233 Segment option data preparation program
5. ICE Control Software ICS6233 ICE control program
6. Mask Data Checker MDC6233 Mask data preparation program

1.2 Developmental Environment

The software product of the development support tool DEV6233 operates on the following host systems:

- IBM PC/AT (at least PC-DOS Ver. 2.0)
- NEC PC-9801 Series (at least MS-DOS Ver. 3.1)

When developing the E0C6233, the above-mentioned host computer, editor, P-ROM writer, printer, etc. must be prepared by the user in addition to the development tool which is normally supported by Seiko Epson.




Fig. 1.2.1 System configuration

Note The DEV6233 system requires a host computer with a RAM capacity of about 140K bytes. Since the ICE62R (ICE6200) is connected to the host computer with a RS-232C serial interface, adapter board for asynchronous communication will be required depending on the host computer used.

1.3 Development Flow

Figure 1.3.1 shows the development flow through the DEV6233.




Fig. 1.3.1 DEV6233 development flow

Concerning file names

All the input-output file name for the each development support tool commonly use "C233XXX". In principle each file should be produced in this manner. Seiko Epson will designate the "XXX" for each customer.

Reference Manual

- *1 E0C6233 Technical Hardware Manual
- *2 E0C6233 Technical Software Manual
- *3 E0C6200/6200A Core CPU Manual
- *4 E0C62 Family Development Tool Reference Manual
- *5 E0C6233 Development Tool Manual (this manual)
- *6 EVA6S32R Manual
- *7 ICE62R (ICE6200) Hardware Manual

1.4 Production of Execution Disk

Execution files for each software development support tool and batch and parameter files for the ICE62R (ICE6200) are recorded in the DEV6233 floppy disk.

The content of the files contained in the DEV6233 floppy disk are shown below.

PC-DOS version	MS-DOS version	Contents
ASM6233.EXE	ASM6233.EXE	Cross Assembler execution file
DMS6200.EXE	DMS6200.EXE	Development Tool Management System execution file
FOG6233.EXE	FOG6233.EXE	Function Option Generator execution file
ICS6233B.BAT	ICS6233.BAT	ICE Control Software batch file
ICS6233W.EXE	ICS6233J.EXE	ICE Control Software execution file
ICS6233P.PAR	ICS6233P.PAR	ICE Control Software parameter file
MDC6233.EXE	MDC6233.EXE	Mask Data Checker execution file
SOG6233.EXE	SOG6233.EXE	Segment Option Generator execution file

- First copy the entire content of this disk using commands such as DISKCOPY then make the execution disk. Carefully conserve the original floppy disk for storage purposes.
When copying into a hard disk, make a subdirectory with an appropriate name (DEV6233, etc.) then copy the content of the floppy disk into that subdirectory using the COPY command.
- Next make a CONFIG.SYS file using Editor or the like.
When a CONFIG.SYS has previously been made using a hard disk system, check the setting of the FILES within it. (If there is none add it.)
Set the number of files to be described in CONFIG.SYS at 10 or more, so that the Mask Data Checker MDC6233 will handle many files.

Note The driver for the RS-232C must be included in CONFIG.SYS by the host computer.

- It is a good idea to copy the editor into the disk to be copied and the subdirectory so you can also select the editor from the DMS6200 menu.
- In "ICS6233(B).BAT" the batch process is indicated such that the ICS6233J(W).EXE is executed after the execution of the command for the setting of the RS-232C communication parameters. When first executing the ICE Control Software after resetting the host computer, select then activate this batch file from the DMS6200 menu.
The SPEED (MS-DOS) or MODE (PC-DOS) command is used for setting the RS-232C, so you should copy these commands into the disk to be executed or specify a disk or directory with the command using the PATH command.

Note The DMS6200 prepares a menu from files that are in the current directory. Consequently, be sure to arrange the above mentioned files in the same disk or the same directory.

Example:

Copying into a floppy disk

Insert the original disk into the A drive and the formatted disk to be copied into B drive, then execute the DISKCOPY command.

```
A>DISKCOPY A: B: [ ]
```

Copying into a hard disk (C drive)

Make a subdirectory (DEV6233), then insert the original disk into the A drive and execute the COPY command.

```
C>MD DEV6233 [ ]
```

```
C>CD DEV6233 [ ]
```

```
C\DEV6233>COPY A:*. * [ ]
```

Example:

Setting of FILES (CONFIG.SYS)

```
C>TYPE CONFIG.SYS [ ]
```

```
:
```

```
FILES=20
```

```
:
```

RS-232C Setting (PC-DOS version)

```
MODE COM1: 4800, n, 8, 1, p
```

RS-232C Setting (MS-DOS version)

```
SPEED R0 9600 B8 PN S1
```

2 DEVELOPMENT TOOL MANAGEMENT SYSTEM DMS6200

2.1 DMS6200 Outline

The DMS6200 (Development Tool Management System) is a software which selects the DEV6233 software development support tool and the program such as an editor in menu form and starts it. In this way the various software frequently executed during debugging can be effectively activated.




Fig. 2.1.1
DMS6200
execution flow

Refer to the "E0C62 Family Development Tool Reference Manual" for details of the operation.

2.2 DMS6200 Quick Reference

■ Starting command

Execution file: **DMS6200.EXE**

Starting command: **DMS6200**

indicates the Return key.

■ Display examples

```

*** E0C6200 Development tool Management System. --- Ver 1.0 ***
EEEEEEEEEE PPPPPPPP SSSSSSS 00000000 NNN NNN
EEEEEEEEEE PPPPPPPP SSS SSSS 000 000 NNNN NNN
EEE PPP PPP SSS SSS 000 000 NNNNN NNN
EEE PPP PPP SSS 000 000 NNNNNN NNN
EEEEEEEEEE PPPPPPPP SSSSSS 000 000 NNN NNN NNN
EEEEEEEEEE PPPPPPPP SSSS 000 000 NNN NNNNN
EEE PPP SSS 000 000 NNN NNNNN
EEE PPP SSS SSS 000 000 NNN NNNN
EEEEEEEEEE PPP SSS SSS 000 000 NNN NNN
EEEEEEEEEE PPP SSSSSS 00000000 NNN NN
          (C) Copyright 1991 SEIKO EPSON CORP.
          STRIKE ANY KEY.
  
```

Start message

When DMS6200 is started, the following message is displayed. For "STRIKE ANY KEY.", press any key to advance the program execution.

To suspend execution, press the "CTRL" and "C" keys together: the sequence returns to the DOS command level.

```

DMS6200 Version 1.0 Copyright(C) SEIKO EPSON CORP. 1991.
1) ASM6233 .EXE
2) FOG6233 .EXE
3) ICS6233B.BAT
4) ICS6233W.EXE
5) MDC6233 .EXE
6) SOG6233 .EXE
Input Number ? [1 ]
  
```

Menu screen (PC-DOS Version)

A list of all executable files will appear on this menu screen.

Input the number of the development support tool you wish to start and then press the "RETURN" key. To return to DOS at this point, press the "ESC" key.

```

DMS6200 Version 1.0 Copyright(C) SEIKO EPSON CORP. 1991.
1) C233XXX .DAT
2) C233XXX .PRN
3) C233XXX .SEG
:
:
10) C6233XXX.PA0
Input Number ? [1 ]
Edit > [ASM6233 C233XXX ]
  
```

Source file selection screen

To starting ASM6233, select the source file on this screen. When the source file is selected by number, the edit line enclosed in [] will appear; enter the option parameter if necessary. Press the "RETURN" key when input is completed. When starting, press the "RETURN" key twice particularly for the support tools which do not require source files. To return to DOS at this point, press the "ESC" key.

3 CROSS ASSEMBLER ASM6233

3.1 ASM6233 Outline

The ASM6233 cross assembler is an assembler program for generating the machine code used by the E0C6233 4-bit, single-chip microcomputers. The Cross Assembler ASM6233 will assemble the program source files which have been input by the user's editor and will generate an object file in Intel-Hex format and assembly list file. In this assembler, program modularization has been made possible through macro definition functions and programming independent of the ROM page structure has been made possible through the auto page set function. In addition, consideration has also been given to precise error checks for program capacity (ROM capacity) overflows, undefined codes and the like, and for debugging of such things as label tables for assembly list files and cross reference table supplements.




Fig. 3.1.1 ASM6233 execution flow

☞ The format of the source file and its operating method are same as for the E0C62 Family. Refer to the "E0C62 Family Development Tool Reference Manual" for details.

3.2 E0C6233 Restrictions

Note the following when generating a program by the E0C6233:

■ ROM area

The capacity of the E0C6233 ROM is 3K steps (0000H to 0BFFH).

Therefore, the specification range of the memory setting pseudo-instructions and PSET instruction is restricted.

Memory configuration:

Bank: Only bank 0, Page: 12 pages (0 to 0BH), each 256 steps

Significant specification range:

ORG pseudo-instruction: 0000H to 0BFFH

PAGE pseudo-instruction: 00H to 0BH

BANK pseudo-instruction: Only 0H

PSET instruction: 00H to 0BH

■ RAM area

The capacity of the E0C6233 RAM is 320 words (000H to 1FEH, 4 bits/word).

However, note the following points when programming.

- (1) The following addresses become unused area. Memory access is invalid when the unused area is specified. 0A0H–0BFH, (0C0H–0EFH), 0F4H, 0F5H, 0FAH, 0FBH, 180H–1EFH, 1F4H, 1F5H, 1FAH, 1FBH
- (2) When 0C0H–0EFH has been specified as the segment data memory through the mask option, that area becomes write-only.
- (3) Since RAM is set for up to 1 page, only the subordinate 1 bit of the page section of the index register which specifies address is effective. (The 3 superordinate bits are ignored.)

Example:

```
LD A, 2
LD XP, A
LD X, 0F5H
```

0F5H is loaded into the IX register, but an unused area has been specified so that the memory accessible with the IX register (MX) is invalid.

■ Undefined codes

The SLP instruction has not been defined in the E0C6233 instruction sets.

3.3 ASM6233 Quick Reference

Starting command and input/output files

_ indicates a blank.
 indicates the Return key.
 A parameter enclosed by [] can be omitted.

Execution file: ASM6233.EXE

Starting command: **ASM6233_ [drive-name:] source-file-name [.shp] _ [-N]**

- Option:**
- .shp Specifies the file I/O drives.
 - s Specifies the drive from which the source file is to be input. (A–P, @)
 - h Specifies the drive to which the object file is to be output. (A–P, @, Z)
 - p Specifies the drive to which the assembly listing file is to be output. (A–P, @, Z)
 @: Current drive, Z: File is not generated
 - N The code (FFH) in the undefined area of program memory is not created.

Input file: C233XXX.DAT (Source file)

Output file:
 C233XXXL.HEX (Object file, low-order)
 C233XXXH.HEX (Object file, high-order)
 C233XXX.PRN (Assembly listing file)

Display example

```

*** E0C6233 CROSS ASSEMBLER. --- Ver 2.00 ***
EEEEEEEEEE PPPPPPPP SSSSSSS 00000000 NNN NNN
EEEEEEEEEE PPPPPPPPPP SSS SSSS 000 000 NNNN NNN
EEE PPP PPP SSS SSS 000 000 NNNNN NNN
EEE PPP PPP SSS 000 000 NNNNNN NNN
EEEEEEEEEE PPPPPPPPPP SSSSSS 000 000 NNN NNN NNN
EEEEEEEEEE PPPPPPPP SSSS 000 000 NNN NNNNNN
EEE PPP SSS SSS 000 000 NNN NNNNN
EEE PPP SSS SSS 000 000 NNN NNNN
EEEEEEEEEE PPP SSSS SSS 000 000 NNN NNN
EEEEEEEEEE PPP SSSSSS 00000000 NNN NN

(C) COPYRIGHT 1991 SEIKO EPSON CORP.
SOURCE FILE NAME IS " C233XXX.DAT "
THIS SOFTWARE MAKES NEXT FILES.
C233XXXH.HEX ... HIGH BYTE OBJECT FILE.
C233XXXL.HEX ... LOW BYTE OBJECT FILE.
C233XXX.PRN ... ASSEMBLY LIST FILE.

DO YOU NEED AUTO PAGE SET? (Y/N) Y ... (1)
DO YOU NEED CROSS REFERENCE TABLE? (Y/N) Y ... (2)
    
```

When ASM6233 is started, the start-up message is displayed.

At (1), select whether or not the auto-page-set function will be used.

- Use Y
- Not use N

If the assembly listing file output is specified, message (2) is displayed. At this stage, cross-reference table generation may be selected.

- Generating Y
- Not generating N

When the above operation is completed, ASM6233 assembles the source file. To suspend execution, press the "CTRL" and "C" keys together at stage (1) or (2).

Operators

Arithmetic operators		Logical operators	
+a	Monadic positive	a_AND_b	Logical product
-a	Monadic negative	a_OR_b	Logical sum
a+b	Addition	a_XOR_b	Exclusive logical sum
a-b	Subtraction	NOT_a	Logical negation
a*b	Multiplication	Relational operators	
a/b	Division	a_EQ_b	True when a is equal to b
a_MOD_b	Remainder of a/b	a_NE_b	True when a is not equal to b
a_SHL_b	Shifts a b bits to the left	a_LT_b	True when a is less than b
a_SHR_b	Shifts a b bits to the right	a_LE_b	True when a is less than or equal to b
HIGH_a	Separates the high-order eight bits from a	a_GT_b	True when a is greater than b
LOW_a	Separates the low-order eight bits from a	a_GE_b	True when a is greater than or equal to b

■ Pseudo-instructions

Pseudo-instruction	Meaning	Example of use
EQU (Equation)	To allocate data to label	ABC EQU 9 BCD EQU ABC+1
SET (Set)	To allocate data to label (data can be changed)	ABC SET 0001H ABC SET 0002H
DW (Define Word)	To define ROM data	ABC DW 'AB' BCD DW 0FFBH
ORG (Origin)	To define location counter	ORG 100H ORG 256
PAGE (Page)	To define boundary of page	PAGE 1H PAGE 3
SECTION (Section)	To define boundary of section	SECTION
END (End)	To terminate assembly	END
MACRO (Macro)	To define macro	CHECK MACRO DATA LOCAL LOOP
LOCAL (Local)	To make local specification of label during macro definition	LOOP CP MX, DATA JP NZ, LOOP ENDM
ENDM (End Macro)	To end macro definition	CHECK 1

■ Error messages

Error message	Explanation
S (Syntax Error)	An unrecoverable syntax error was encountered.
U (Undefined Error)	The label or symbol of the operand has not been defined.
M (Missing Label)	The label field has been omitted.
O (Operand Error)	A syntax error was encountered in the operand, or the operand could not be evaluated.
P (Phase Error)	The same label or symbol was defined more than once.
R (Range Error)	<ul style="list-style-type: none"> The location counter value exceeded the upper limit of the program memory, or a location exceeding the upper limit was specified. A value greater than that which the number of significant digits of the operand will accommodate was specified.
! (Warning)	<ul style="list-style-type: none"> Memory areas overlapped because of a "PAGE" or "ORG" pseudo-instruction or both. A statement exceeded a page boundary although its location was not specified.
FILE NAME ERROR	The source file name was longer than 8 characters.
FILE NOT PRESENT	The specified source file was not found.
DIRECTORY FULL	No space was left in the directory of the specified disk.
FATAL DISK WRITE ERROR	The file could not be written to the disk.
LABEL TABLE OVERFLOW	The number of defined labels and symbols exceeded the label table capacity (4000).
CROSS REFERENCE TABLE OVERFLOW	The label/symbol reference count exceeded the cross-reference table capacity (only when the cross-reference table is generated).

4 FUNCTION OPTION GENERATOR FOG6233

4.1 FOG6233 Outline

With the 4-bit single-chip E0C6233 microcomputers, the customer may select 19 hardware options. By modifying the mask patterns of the E0C6233 according to the selected options, the system can be customized to meet the specifications of the target system.

The Function Option Generator FOG6233 is a software tool for generating data files used to generate mask patterns. It enables the customer to interactively select and specify pertinent items for each hardware option. From the data file created with FOG6233, the E0C6233 mask pattern is automatically generated by a general purpose computer. The HEX file for the evaluation board (EVA6S32R) hardware option ROM is simultaneously generated with the data file.

The operating method is same as for the E0C62 Family. Refer to the "E0C62 Family Development Tool Reference Manual" for details.




Fig. 4.1.1 FOG6233 execution flow

4.2 E0C6233 Option List

Multiple specifications are available in each option item as indicated in the Option List. Using "4.3 Option Specifications and Selection Message" as reference, select the specifications that meet the target system. Be sure to record the specifications for unused ports too, according to the instructions provided.

1. DEVICE TYPE

- 1. E0C6233 (Normal Type)
- 2. E0C62L33 (Low Power Type)
- 3. E0C62A33 (Twin Clock Type)

2. OSC1 SYSTEM CLOCK (only for E0C62A33)

- 1. CR 2. Ceramic

3. MULTIPLE KEY ENTRY RESET

- COMBINATION 1. Not Use
 - 2. Use K00, K01
 - 3. Use K00, K01, K02
 - 4. Use K00, K01, K02, K03
- TIME AUTHORIZE 1. Use 2. Not Use

4. WATCH DOG TIMER

- 1. Use 2. Not Use

5. INTERRUPT NOISE REJECTOR

- K00-K03 1. Use 2. Not Use
- K10 1. Use 2. Not Use

6. INPUT PORT PULL DOWN RESISTOR

- K00 1. With Resistor 2. Gate Direct
- K01 1. With Resistor 2. Gate Direct
- K02 1. With Resistor 2. Gate Direct
- K03 1. With Resistor 2. Gate Direct
- K10 1. With Resistor 2. Gate Direct

7. OUTPUT PORT SPECIFICATION (R00–R03)

- R00 1. Complementary 2. Pch-OpenDrain
- R01 1. Complementary 2. Pch-OpenDrain
- R02 1. Complementary 2. Pch-OpenDrain
- R03 1. Complementary 2. Pch-OpenDrain

8. R10 SPECIFICATION

- OUTPUT SPECIFICATION 1. Complementary 2. Pch-OpenDrain
- OUTPUT TYPE 1. DC Output 2. Buzzer Output

9. R11 SPECIFICATION

- OUTPUT SPECIFICATION 1. Complementary 2. Pch-OpenDrain

10. R12 SPECIFICATION

- OUTPUT SPECIFICATION 1. Complementary 2. Pch-OpenDrain
- OUTPUT TYPE 1. DC Output
- 2. FOUT 32768 [Hz]
- 3. FOUT 16384 [Hz]
- 4. FOUT 8192 [Hz]
- 5. FOUT 4096 [Hz]
- 6. FOUT 2048 [Hz]
- 7. FOUT 1024 [Hz]
- 8. FOUT 512 [Hz]
- 9. FOUT 256 [Hz]

11. R13 SPECIFICATION

- OUTPUT SPECIFICATION 1. Complementary 2. Pch-OpenDrain
- OUTPUT TYPE 1. DC Output
- 2. Buzzer Inverted Output (R13 Control)
- 3. Buzzer Inverted Output (R10 Control)

12. I/O PORT SPECIFICATION

- P00 1. Complementary 2. Pch-OpenDrain
- P01 1. Complementary 2. Pch-OpenDrain
- P02 1. Complementary 2. Pch-OpenDrain
- P03 1. Complementary 2. Pch-OpenDrain
- P10 1. Complementary 2. Pch-OpenDrain
- P11 1. Complementary 2. Pch-OpenDrain
- P12 1. Complementary 2. Pch-OpenDrain
- P13 1. Complementary 2. Pch-OpenDrain

13. EVENT COUNTER NOISE REJECTOR

- 1. 2048 [Hz] 2. 256 [Hz]

14. LCD COMMON DUTY

- 1. 1/4 Duty 2. 1/3 Duty

15. SEGMENT MEMORY ADDRESS

- 1. 4*–6* (R/W) 2. C*–E* (W)

16. SIN PULL DOWN RESISTOR

- 1. With Resistor 2. Gate Direct

17. SOUT OUTPUT SPECIFICATION

- 1. Complementary 2. Pch-OpenDrain

18. SCLK SPECIFICATION

- PULL DOWN RESISTOR 1. With Resistor 2. Gate Direct
- OUTPUT SPECIFICATION 1. Complementary 2. Pch-OpenDrain
- LOGIC 1. Positive 2. Negative

19. SIO DATA PERMUTATION

- 1. MSB First 2. LSB First

4.3 Option Specifications and Selection Message

Screen that can be selected as function options set on the E0C6233 are shown below, and their specifications are also described.

1 Device type

```

*** OPTION NO.1 ***
--- DEVICE TYPE ---

      1. E0C6233 ( NORMAL TYPE )
      2. E0C62L33 ( LOW POWER TYPE )
      3. E0C62A33 ( TWIN CLOCK TYPE )

PLEASE SELECT NO.(1) ? 3 [ ]

      3. E0C62A33 ( TWIN CLOCK TYPE )  SELECTED
    
```

Select the chip specification. E0C6233, E0C62L33, and E0C62A33 denote 3 V power source voltage specification, LOW POWER specification for 1.5 V power source voltage, and TWIN CLOCK specification, respectively. When E0C6233 and E0C62L33 are selected, oscillation circuit OSC3 is fixed at CR oscillation. However, it can not be used.

2 OSC3 system clock

```

*** OPTION NO.2 ***
--- OSC3 OSCILLATOR ---

      1. CR
      2. CERAMIC

PLEASE SELECT NO.(1) ? 1 [ ]

      1. CR  SELECTED
    
```

Select oscillation circuit that uses OSC3 and OSC4. To minimize external components, CR oscillation circuit would be suitable; to obtain a stable oscillation frequency, ceramic oscillation circuit would be suitable. When CR oscillation circuit is selected, only resistors are needed as external components since capacities are built-in. On the other hand, when ceramic oscillation circuit is selected, ceramic oscillator, gate capacity and drain capacity are needed as external components. Although when ceramic oscillation circuit is selected, it is fixed at 455 kHz, when CR oscillation circuit is selected, frequency may be modified to a certain extent depending on the resistance of external components.

* The above selection is only possible with 62A33.

3 Multiple key entry reset

```

*** OPTION NO.3 ***
--- MULTIPLE KEY ENTRY RESET ---

COMBINATION      1. NOT USE
                  2. USE K00,K01
                  3. USE K00,K01,K02
                  4. USE K00,K01,K02,K03

PLEASE SELECT NO.(1) ? 1 [ ]

TIME AUTHORIZE   1. USE
                  2. NOT USE

PLEASE SELECT NO.(1) ? 1 [ ]

COMBINATION      1. NOT USE  SELECTED
TIME AUTHORIZE   1. USE     SELECTED
    
```

The reset function and time authorize circuit are set when K00 through K03 are entered. When "Not Use" is set for the combination, the reset function is not activated even if K00 through K03 are entered. When "Use K00, K01" is set, the system is reset immediately the K00 and K01 inputs go high at the same time. Similarly, the system is reset as soon as the K00 through K02 inputs or the K00 through K03 inputs go high. When "Use" is set for the time authorize circuit, a simultaneous high input time is authorized. The system is reset when a signal is input for more than 1 to 3 sec. If the time authorize circuit is not used, the system is reset when a high signal is input for more than 6 msec.

* If "Not Use" is set for the combination, the time authorize selection is required.

The system reset circuit is shown in Figure 4.3.1.




Fig. 4.3.1 System reset circuit

4 Watchdog timer

```

*** OPTION NO.4 ***
--- WATCH DOG TIMER ---

                                1. USE
                                2. NOT USE

PLEASE SELECT NO.(1) ? 1 

                                1. USE   SELECTED

```

Select whether the watchdog timer built-in to detect CPU runaways will be used or not.

When the watchdog timer is not reset by the program within 3 to 4 second cycles, the CPU is initially reset.

5 Input interrupt noise rejector

```

*** OPTION NO.5 ***
--- INTERRUPT NOISE REJECTOR ---

    K00-K03          1. USE
                   2. NOT USE

PLEASE SELECT NO.(1) ? 1 

    K10              1. USE
                   2. NOT USE

PLEASE SELECT NO.(1) ? 1 

    K00-K03          1. USE   SELECTED
    K10              1. USE   SELECTED

```

Select whether noise rejector will be supplemented to the input interruptor of K00–K03 and K10. When "Use" is selected, the entry signal will pass the noise rejector, and occurrence of interrupt errors due to noise or chattering can be avoided. Note, however, that because the noise rejector performs entry signal sampling at 4 kHz, "Not Use" should be selected when high speed response is required.

6 Input port pull down resistor

```

*** OPTION NO.6 ***
--- INPUT PORT PULL DOWN RESISTOR ---

    K00              1. WITH RESISTOR
                   2. GATE DIRECT

PLEASE SELECT NO.(1) ? 1 

    K01              1. WITH RESISTOR
                   2. GATE DIRECT

PLEASE SELECT NO.(1) ? 1 

    K02              1. WITH RESISTOR
                   2. GATE DIRECT

PLEASE SELECT NO.(1) ? 1 

    K03              1. WITH RESISTOR
                   2. GATE DIRECT

PLEASE SELECT NO.(1) ? 1 

    K10              1. WITH RESISTOR
                   2. GATE DIRECT

PLEASE SELECT NO.(1) ? 1 

    K00              1. WITH RESISTOR   SELECTED
    K01              1. WITH RESISTOR   SELECTED
    K02              1. WITH RESISTOR   SELECTED
    K03              1. WITH RESISTOR   SELECTED
    K10              1. WITH RESISTOR   SELECTED

```

Select whether input ports (K00–K03 and K10) will each be supplemented with pull down resistors or not. When "Gate Direct" is selected, see to it that entry floating state does not occur. Select "With Resistor" pull down resistor for unused ports. Moreover, the input port status is changed from high level (VDD) to low (VSS) with pull down resistors, a delay of approximately 1 msec in waveform rise time will occur depending on the pull down resistor and entry load time constant. Because of this, when input reading is to be conducted, ensure the appropriate wait time with the program.

The configuration of the pull down resistor circuit is shown in Figure 4.3.2.




Fig. 4.3.2 Configuration of pull down resistor

7 Output port output specification (R00–R03)

```

*** OPTION NO.7 ***
--- OUTPUT PORT SPECIFICATION (R00-R03) ---
      R00          1. COMPLEMENTARY
                  2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1 
      R01          1. COMPLEMENTARY
                  2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1 
      R02          1. COMPLEMENTARY
                  2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1 
      R03          1. COMPLEMENTARY
                  2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1 
      R00          1. COMPLEMENTARY  SELECTED
      R01          1. COMPLEMENTARY  SELECTED
      R02          1. COMPLEMENTARY  SELECTED
      R03          1. COMPLEMENTARY  SELECTED
    
```

Select the output specification for the output ports (R00–R03).

Either complementary output or Pch open drain output may be selected.

When output port is to be used on key matrix configuration, select Pch open drain output.

For unused output ports, select complementary output.

The output circuit configuration is shown in Figure 4.3.3.




Fig. 4.3.3 Configuration of output circuit

8 R10 specification

```

*** OPTION NO.8 ***
--- R10 SPECIFICATION ---
      OUTPUT SPECIFICATION 1. COMPLEMENTARY
                          2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1 
      OUTPUT TYPE          1. D.C.
                          2. BUZZER
PLEASE SELECT NO.(1) ? 2 
      OUTPUT SPECIFICATION 1. COMPLEMENTARY  SELECTED
      OUTPUT TYPE          2. BUZZER        SELECTED
    
```

Select the output specification for R10 terminal. Either complementary output or Pch open drain output may be selected.

When DC output is selected, R10 becomes a regular output port. When buzzer output is selected, by writing "1" to the R10 register, buzzer drive (oscillation output) signal is output from the R10 terminal.

* When DC output is selected, R13 terminal output type (see Option 11, "R13 specification") selection is limited to DC output only.

The circuit configuration is the same as that of output ports (R00–R03 shown in Figure 4.3.3). Refer to Figure 4.3.6 for buzzer output waveform.

9 R11 specification

```

*** OPTION NO.9 ***
--- R11 SPECIFICATION ---
      OUTPUT SPECIFICATION 1. COMPLEMENTARY
                          2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1 
      OUTPUT SPECIFICATION 1. COMPLEMENTARY  SELECTED
    
```

Select the output specification for R11 terminal. Either complementary output or Pch open drain output may be selected.

The circuit configuration is the same as that of output ports (R00–R03 shown in Figure 4.3.3).

10 R12 specification

```

*** OPTION NO.10 ***
--- R12 SPECIFICATION ---
    OUTPUT SPECIFICATION 1. COMPLEMENTARY
                        2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1
    OUTPUT TYPE         1. D.C.
                        2. FOUT 32768 [HZ]
                        3. FOUT 16384 [HZ]
                        4. FOUT 8192 [HZ]
                        5. FOUT 4096 [HZ]
                        6. FOUT 2048 [HZ]
                        7. FOUT 1024 [HZ]
                        8. FOUT 512 [HZ]
                        9. FOUT 256 [HZ]
PLEASE SELECT NO.(1) ? 1
    OUTPUT SPECIFICATION 1. COMPLEMENTARY  SELECTED
    OUTPUT TYPE         1. D.C.  SELECTED
    
```

Select the output specification for R12 terminal. Either complementary output or Pch open drain output may be selected.

When DC output is selected, R12 becomes a regular output port. When FOUT is selected, clock with frequency selected from R12 terminal is generated by writing "1" to the R12 register.

- When DC output is selected
When R12 register is set to "1", the R12 terminal output goes high (VDD), and goes low (VSS) when set to "0".
Output waveform is shown in Figure 4.3.4.




Fig. 4.3.4 Output waveform at DC output selection

- When FOUT output is selected
When FOUT bit (R12 register) is set to "1", 50% duty and VDD–VSS amplitude square wave is generated at the specified frequency. When set to "0", the FOUT terminal goes low (VSS). A FOUT frequency may be selected from among 8 types, ranging from 256 Hz to 32,768 Hz.
FOUT output is normally utilized to provide clock to other devices but since hazard occurs at the square wave breaks, great caution must be observed when using it.
Output waveform is shown in Figure 4.3.5.




Fig. 4.3.5 Output waveform at R12 FOUT output selection

11 R13 specification

```

*** OPTION NO.11 ***
--- R13 SPECIFICATION ---
    OUTPUT SPECIFICATION 1. COMPLEMENTARY
                        2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1
    OUTPUT TYPE         1. D.C.
                        2. BUZZER OUTPUT R13
                        3. BUZZER OUTPUT R10
PLEASE SELECT NO.(1) ? 1
    OUTPUT SPECIFICATION 1. COMPLEMENTARY  SELECTED
    OUTPUT TYPE         1. D.C.  SELECTED
    
```

Select the output specification for R13 terminal. Either complementary output or Pch open drain output may be selected.

When DC output is selected, R13 becomes a regular output port. When "Buzzer Inverted Output" is selected, inverted waveform of R10 buzzer output is generated from R13 terminal. R13 and R10 control bits become buzzer inverted output when "1" is written to R13 and R10 registers, respectively.

- * The buzzer inverted output may not be selected when the output type R10 terminal (see Option 8, "R10 specification") is not set to buzzer. Moreover, at this point, when the output type of R10 terminal is reselected after selecting buzzer inverted output, the output type of R10 is fixed at buzzer output.

Buzzer output waveform is shown in Figure 4.3.6.




Fig. 4.3.6 Buzzer output waveform

12 I/O port specification

```

*** OPTION NO.12 ***
--- I/O PORT OUTPUT SPECIFICATION ---

P00          1. COMPLEMENTARY
              2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1 [ ]

P01          1. COMPLEMENTARY
              2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1 [ ]

P02          1. COMPLEMENTARY
              2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1 [ ]

P03          1. COMPLEMENTARY
              2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1 [ ]

P10          1. COMPLEMENTARY
              2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1 [ ]

P11          1. COMPLEMENTARY
              2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1 [ ]

P12          1. COMPLEMENTARY
              2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1 [ ]

P13          1. COMPLEMENTARY
              2. PCH-OPENDRAIN
PLEASE SELECT NO.(1) ? 1 [ ]

P00          1. COMPLEMENTARY  SELECTED
P01          1. COMPLEMENTARY  SELECTED
P02          1. COMPLEMENTARY  SELECTED
P03          1. COMPLEMENTARY  SELECTED
P10          1. COMPLEMENTARY  SELECTED
P11          1. COMPLEMENTARY  SELECTED
P12          1. COMPLEMENTARY  SELECTED
P13          1. COMPLEMENTARY  SELECTED
    
```

Select the output specification to be used during I/O ports (P00–P03 and P10–P13) output mode selection.

Either complementary output or Pch open drain output may be selected.

The circuit configuration of the output driver is the same as that of output ports (R00–R03 shown in Figure 4.3.3).

Select complementary output for unused ports.

The I/O ports can control the input/output direction according to the IOC bit (7E address, D0 bit, and FE, D0 bit); at "1" and "0" settings, it is set to output port and input port, respectively.

The pull down resistor of this port is turned on by the read signal and is normally turned off to minimize leak current.

Because of this, when the port is set for input, take care that a floating state does not occur in the terminal.

The I/O port circuit configuration is shown in Figure 4.3.7.




Fig. 4.3.7 Circuit configuration of I/O port

13 Event counter noise rejector

```

*** OPTION NO.13 ***
--- EVENT COUNTER NOISE REJECTOR ---

              1. 2048 [HZ]
              2.  256 [HZ]
PLEASE SELECT NO.(1) ? 1 [ ]

              1. 2048 [HZ]  SELECTED
    
```

The system is equipped with built-in noise rejector to prevent operational errors by the event counter caused by noise and chattering in the K02 and K03 terminals.

Either 2048 Hz or 256 Hz may be selected as the sampling frequency.

Select the one suitable for the input signal.

14 LCD common duty

```

*** OPTION NO.14 ***
--- LCD COMMON DUTY ---
                                1. 1/4 DUTY
                                2. 1/3 DUTY
PLEASE SELECT NO.(1) ? 1
                                1. 1/4 DUTY  SELECTED

```

Table 4.3.1 Common duty selection standard

Number of LCD segment drives			Common duty
1	–	120	1/3
121	–	160	1/4




Fig. 4.3.8
Drive waveform of
COM terminals

15 Segment memory address

```

*** OPTION NO.15 ***
--- SEGMENT MEMORY ADDRESS ---
                                1. 4* - 6* (R/W)
                                2. C* - E* (W)
PLEASE SELECT NO.(1) ? 1
                                1. 4* - 6* (R/W)  SELECTED

```

Select the segment memory area.

When "4* – 6*" is selected, the segment memory area is allocated "040H–06FH" and R/W access utilizing this RAM area becomes available.

When "C* – E*" is selected, the segment memory area is allocated "0C0H–0EFH" and becomes a write-only area.

16 SIN pull down resistor

```

*** OPTION NO.16 ***
--- SIN PULL DOWN RESISTOR ---
                                1. WITH RESISTOR
                                2. GATE DIRECT
PLEASE SELECT NO.(1) ? 1
                                1. WITH RESISTOR  SELECTED

```

Select whether pull down resistor will be supplemented to SIN terminal (SIO data input terminal). When "Gate Direct" is selected, take care that input floating state does not occur. Select "With Resistor" for SIN terminal that will not be used.

17 SOUT specification

```

*** OPTION NO.17 ***
--- SOUT OUTPUT SPECIFICATION ---

                                1. COMPLEMENTARY
                                2. PCH-OPENDRAIN

PLEASE SELECT NO.(1) ? 1 

                                1. COMPLEMENTARY  SELECTED
    
```

Select the output specification for SOUT terminal. Either complementary output or Pch open drain output may be selected. Select complementary output for unused SOUT terminal.

18 SCLK specification

```

*** OPTION NO.18 ***
--- SCLK SPECIFICATION ---

PULL DOWN RESISTOR  1. WITH RESISTOR
                    2. GATE DIRECT

PLEASE SELECT NO.(1) ? 1 

OUTPUT SPECIFICATION 1. COMPLEMENTARY
                    2. PCH-OPENDRAIN

PLEASE SELECT NO.(1) ? 1 

LOGIC                1. POSITIVE
                    2. NEGATIVE

PLEASE SELECT NO.(1) ? 1 

PULL DOWN RESISTOR  1. WITH RESISTOR  SELECTED
OUTPUT SPECIFICATION 1. COMPLEMENTARY  SELECTED
LOGIC                1. POSITIVE      SELECTED
    
```

Select the pull down resistor, output specification and logic for SCLK terminal (input/output terminal of the SIO synchronous clock). Pull down resistor is only valid when the clock mode is set at external clock mode. Set unused SCLK terminal to with pull down resistor, complementary output, and positive logic. The SCLK timing chart is shown in Figure 4.3.9.




Fig. 4.3.9 SCLK timing chart

19 SIO data permutation

```

*** OPTION NO.19 ***
--- SIO DATA PERMUTATION ---

                                1. MSB FIRST
                                2. LSB FIRST

PLEASE SELECT NO.(1) ? 1 

                                1. MSB FIRST  SELECTED
    
```

Select whether the SIO input/output (SIN or SOUT) data bit permutation will be MSB first or LSB first. Select the one suitable to your programming needs. Input/output data permutation is shown in Figure 4.3.10.




Fig. 4.3.10 Input/output data permutation

4.4 FOG6233 Quick Reference

■ Starting command and input/output files

Execution file: FOG6233.EXE

Starting command: FOG6233

indicates the Return key.

Input file: C233XXXF.DOC (Function option document file, when modifying)

Output file: C233XXXF.DOC (Function option document file)
C233XXXF.HEX (Function option HEX file)

■ Display example

```

*** E0C6233 FUNCTION OPTION GENERATOR. --- Ver 3.10 ***
EEEEEEEEEE PPPPPPPP SSSSSSS 0000000 NNN NNN
EEEEEEEEEE PPPPPPPPP SSS SSSS 000 000 NNNN NNN
EEE PPP PPP SSS SSS 000 000 NNNNN NNN
EEE PPP PPP SSS SSS 000 000 NNNNNN NNN
EEEEEEEEEE PPPPPPPPP SSSSSSS 000 000 NNN NNN NNN
EEEEEEEEEE PPPPPPPP SSSS 000 000 NNN NNNNNN
EEE PPP SSS 000 000 NNN NNNNN
EEE PPP SSS SSS 000 000 NNN NNNN
EEEEEEEEEE PPP SSS SSS 000 000 NNN NNN
EEEEEEEEEE PPP SSSSSS 0000000 NNN NN

(C) COPYRIGHT 1991 SEIKO EPSON CORP.

THIS SOFTWARE MAKES NEXT FILES.

C233XXXF.HEX ... FUNCTION OPTION HEX FILE.
C233XXXF.DOC ... FUNCTION OPTION DOCUMENT FILE.

STRIKE ANY KEY.

```

Start-up message

When FOG6233 is started, the start-up message is displayed.

For "STRIKE ANY KEY.", press any key to advance the program execution.

To suspend execution, press the "CTRL" and "C" keys together: the sequence returns to the DOS command level.

```

*** E0C6233 USER'S OPTION SETTING. --- Ver 3.10 ***
CURRENT DATE IS 91/10/14
PLEASE INPUT NEW DATE : 91/10/14 

```

Date input

Enter the 2-digit year, month, and day of the month by delimiting them with a slash ("/").

When not modifying the date, press the RETURN key "" to continue.

```

*** OPERATION SELECT MENU ***
1. INPUT NEW FILE
2. EDIT FILE
3. RETURN TO DOS

PLEASE SELECT NO.?

```

Operation selection menu

Enter a number from 1 to 3 to select a subsequent operation.

1. To set new function options.
2. To modify the document file.
3. To terminate FOG6233.

```

*** OPERATION SELECT MENU ***
1. INPUT NEW FILE
2. EDIT FILE
3. RETURN TO DOS

PLEASE SELECT NO.? 1 
PLEASE INPUT FILE NAME? C2330A0  ..(1)
PLEASE INPUT USER'S NAME? SEIKO EPSON CORP.  ..(2)
PLEASE INPUT ANY COMMENT
(ONE LINE IS 50 CHR)? ED MARKETING DEPARTMENT  ..(3)
? 421-8 HINO HINO-SHI TOKYO 191-8501 JAPAN 
? TEL 042-587-5816 
? FAX 042-587-5624 
? 

```

Setting new function options

Select "1" on the operation selection menu.

- (1) Enter the file name.
- (2) Enter the customer's company name.
- (3) Enter any comment.

(Within 50 characters x 10 lines)

Next, start function option setting from option No. 1.

```

PLEASE INPUT FILE NAME? C2330A0 
EXISTS OVERWRITE(Y/N)? N 
PLEASE INPUT FILE NAME? C2330B0 
PLEASE INPUT USER'S NAME?

```

In case a function option document file with the same name as the file name specified in the current drive exists, the user is asked whether overwriting is desired. Enter "Y" or "N" accordingly.

```

*** OPERATION SELECT MENU ***

    1. INPUT NEW FILE
    2. EDIT FILE
    3. RETURN TO DOS

PLEASE SELECT NO.? 2

*** SOURCE FILE(S) ***

C2330A0          C2330B0          C2330C0          ..(1)

PLEASE INPUT FILE NAME? C2330A0
PLEASE INPUT USER'S NAME?
PLEASE INPUT ANY COMMENT
(ONE LINE IS 50 CHR)?
PLEASE INPUT EDIT NO.? 4
:
(Modifying function option settings)
:
PLEASE INPUT EDIT NO.? E

```

In step (1), if no modifiable source exists, the following message is displayed and the sequence returns to the operation selection menu.

```

*** SOURCE FILE(S) ***

FUNCTION OPTION DOCUMENT FILE IS NOT FOUND.

```

In step (2), if the function option document file is not in the current drive, the following message is displayed, prompting entry of other file name.

```

PLEASE INPUT FILE NAME? C2330N0
FUNCTION OPTION DOCUMENT FILE IS NOT FOUND.
PLEASE INPUT FILE NAME?

```

```

*** OPTION NO.3 ***

- MULTIPLE KEY ENTRY RESET -

COMBINATION      1. Not Use
                  2. Use  K00,K01
                  3. Use  K00,K01,K02
                  4. Use  K00,K01,K02,K03

PLEASE SELECT NO.(1) ? 2

COMBINATION      2. Use  K00,K01  SELECTED

```

```

END OF OPTION SETTING.
DO YOU MAKE HEX FILE (Y/N) ? Y
*** OPTION EPROM SELECT MENU ***

    1. 27C64
    2. 27C128
    3. 27C256
    4. 27C512

PLEASE SELECT NO.? 2
      2. 27C128  SELECTED

MAKING FILE(S) IS COMPLETED.

*** OPERATION SELECT MENU ***

    1. INPUT NEW FILE
    2. EDIT FILE
    3. RETURN TO DOS

PLEASE SELECT NO.?

```

Modifying function option settings

Select "2" on the operation selection menu.

- (1) Will display the files on the current drive.
- (2) Enter the file name.
- (3) Enter the customer's company name.
- (4) Enter any comment.

Previously entered data can be used by pressing the RETURN key "" at (3) and (4).

- (5) Enter the number of the function option to be modified. When selection of one option is complete, the system prompts entry of another function option number. Repeat selection until all options to be modified are selected. Enter "E" to end option setting. Then, move to the confirmation procedure for HEX file generation.

Option selection

The selections for each option correspond one to one to the option list. Enter the selection number.

The value in parentheses () indicates the default value, and is set when only the RETURN key "" is pressed.

In return, the confirmation is displayed.

When you wish to modify previously set function options in the new setting process, enter "B" to return 1 step back to the previous function option setting operation.

EPROM selection

When setting function options setting is completed, the following message is output to ask the operator whether to generate the HEX file.

- (1) When debugging the program with EVA6S32R, HEX file is needed, so enter "Y". If "N" is entered, no HEX file is generated and only document file is generated.
- (2) For the option ROM selection menu displayed when "Y" is entered in Step (1), select the EPROM to be used for setting EVA6S32R options.

When a series of operations are complete, the sequence returns to the operation selection menu.

4.5 Sample File

■ Example of function option document file

```

* E0C6233 FUNCTION OPTION DOCUMENT V 3.10
*
* FILE NAME      C2330A0F.DOC
* USER'S NAME   SEIKO EPSON CORP.
* INPUT DATE    91/10/14
*
* COMMENT       ED MARKETING DEPARTMENT
*               421-8 HINO HINO-SHI TOKYO 191-8501 JAPAN
*               TEL 042-587-5816
*               FAX 042-587-5624
*
*
* OPTION NO.1
* < DEVICE TYPE >
*
*               E0C62A33 ( TWIN CLOCK TYPE ) -  SELECTED
OPT0101 05
OPT0102 05
*
* OPTION NO.2
* < OSC3 OSCILLATOR >
*
*               CR -----  SELECTED
OPT0201 02
*
* OPTION NO.3
* < MULTIPLE KEY ENTRY RESET >
*   COMBINATION   NOT USE -----  SELECTED
*   TIME AUTHORIZE  USE -----  SELECTED
OPT0301 01
OPT0302 01
*
* OPTION NO.4
* < WATCH DOG TIMER >
*
*               USE -----  SELECTED
OPT0401 01
*
* OPTION NO.5
* < INTERRUPT NOISE REJECTOR >
*   K00-K03      USE -----  SELECTED
*   K10          USE -----  SELECTED
OPT0501 01
OPT0502 01
*
* OPTION NO.6
* < INPUT PORT PULL DOWN RESISTOR >
*   K00          WITH RESISTOR -----  SELECTED
*   K01          WITH RESISTOR -----  SELECTED
*   K02          WITH RESISTOR -----  SELECTED
*   K03          WITH RESISTOR -----  SELECTED
*   K10          WITH RESISTOR -----  SELECTED
OPT0601 01
OPT0602 01
OPT0603 01
OPT0604 01
OPT0605 01
*
* OPTION NO.7
* < OUTPUT PORT SPECIFICATION (R00-R03) >
*   R00          COMPLEMENTARY -----  SELECTED
*   R01          COMPLEMENTARY -----  SELECTED
*   R02          COMPLEMENTARY -----  SELECTED
*   R03          COMPLEMENTARY -----  SELECTED
OPT0701 01
OPT0702 01
OPT0703 01
OPT0704 01
*

```

4 FUNCTION OPTION GENERATOR FOG6233

```

* OPTION NO.8
* < R10 SPECIFICATION >
*   OUTPUT SPECIFICATION  COMPLEMENTARY  -----  SELECTED
*   OUTPUT TYPE           BUZZER         -----  SELECTED
OPT0801 01
OPT0802 02
*
* OPTION NO.9
* < R11 SPECIFICATION >
*   OUTPUT SPECIFICATION  COMPLEMENTARY  -----  SELECTED
OPT0901 01
*
* OPTION NO.10
* < R12 SPECIFICATION >
*   OUTPUT SPECIFICATION  COMPLEMENTARY  -----  SELECTED
*   OUTPUT TYPE           D.C.         -----  SELECTED
OPT1001 01
OPT1002 01
OPT1003 08
*
* OPTION NO.11
* < R13 SPECIFICATION >
*   OUTPUT SPECIFICATION  COMPLEMENTARY  -----  SELECTED
*   OUTPUT TYPE           D.C.         -----  SELECTED
OPT1101 01
OPT1102 01
*
* OPTION NO.12
* < I/O PORT OUTPUT SPECIFICATION >
*   P00                   COMPLEMENTARY  -----  SELECTED
*   P01                   COMPLEMENTARY  -----  SELECTED
*   P02                   COMPLEMENTARY  -----  SELECTED
*   P03                   COMPLEMENTARY  -----  SELECTED
*   P10                   COMPLEMENTARY  -----  SELECTED
*   P11                   COMPLEMENTARY  -----  SELECTED
*   P12                   COMPLEMENTARY  -----  SELECTED
*   P13                   COMPLEMENTARY  -----  SELECTED
OPT1201 01
OPT1202 01
OPT1203 01
OPT1204 01
OPT1205 01
OPT1206 01
OPT1207 01
OPT1208 01
*
* OPTION NO.13
* < EVENT COUNTER NOISE REJECTOR >
*   2048 [HZ]            -----  SELECTED
OPT1301 01
*
* OPTION NO.14
* < LCD COMMON DUTY >
*   1/4 DUTY            -----  SELECTED
OPT1401 01
*
* OPTION NO.15
* < SEGMENT MEMORY ADDRESS >
*   4* - 6* (R/W)      -----  SELECTED
OPT1501 01
*
* OPTION NO.16
* < SIN PULL DOWN RESISTOR >
*   WITH RESISTOR      -----  SELECTED
OPT1601 01
*
* OPTION NO.17
* < SOUT OUTPUT SPECIFICATION >
*   COMPLEMENTARY      -----  SELECTED
OPT1701 01
*

```



```

* OPTION NO.18
* < SCLK SPECIFICATION >
*   PULL DOWN RESISTOR      WITH RESISTOR  -----  SELECTED
*   OUTPUT SPECIFICATION    COMPLEMENTARY  -----  SELECTED
*   LOGIC                   POSITIVE      -----  SELECTED
OPT1801 01
OPT1802 01
OPT1803 01
*
* OPTION NO.19
* < SIO DATA PERMUTATION >
*                               MSB FIRST  -----  SELECTED
OPT1901 01
*
*
* SEIKO EPSON'S AREA
*
*
* OPTION NO.20
OPT2001 01
OPT2002 01
OPT2003 01
OPT2004 01
OPT2005 01
OPT2006 01
OPT2007 01
OPT2008 01
*
* OPTION NO.21
OPT2101 01
OPT2102 01
OPT2103 01
OPT2104 01
OPT2105 01
OPT2106 01
OPT2107 01
OPT2108 01
*
* OPTION NO.22
OPT2201 01
*
* OPTION NO.23
OPT2301 01
*
* OPTION NO.24
OPT2401 01
OPT2402 01
*
* OPTION NO.25
OPT2501 01
OPT2502 01
\\END

```

Note End mark "~~¥~~END" may be used instead of "\\END" depending on the PC used. (The code of \ and ¥ is 5CH.)

5 SEGMENT OPTION GENERATOR SOG6233

5.1 SOG6233 Outline

With the 4-bit single-chip E0C6233 microcomputers, the customer may select the LCD segment options. By modifying the mask patterns of the E0C6233 according to the selected options, the system can be customized to meet the specifications of the target system.

The Segment Option Generator SOG6233 is a software tool for generating data file used to generate mask patterns. From the data file created with SOG6233, the E0C6233 mask pattern is automatically generated by a general purpose computer. The HEX file for the evaluation board (EVA6S32R) segment option ROM is simultaneously generated with the data file.

The operating method is same as for the E0C62 Family. Refer to the "E0C62 Family Development Tool Reference Manual" for details.




Fig. 5.1.1 SOG6233 execution flow

5.2 Option List

TERMINAL NAME	ADDRESS												OUTPUT SPECIFICATION	
	COM0			COM1			COM2			COM3				
	H	L	D	H	L	D	H	L	D	H	L	D		
SEG0														SEG output
SEG1														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG2														SEG output
SEG3														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG4														SEG output
SEG5														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG6														SEG output
SEG7														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG8														SEG output
SEG9														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG10														SEG output
SEG11														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG12														SEG output
SEG13														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG14														SEG output
SEG15														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG16														SEG output
SEG17														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG18														SEG output
SEG19														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG20														SEG output
SEG21														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG22														SEG output
SEG23														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG24														SEG output
SEG25														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG26														SEG output
SEG27														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG28														SEG output
SEG29														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG30														SEG output
SEG31														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG32														SEG output
SEG33														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG34														SEG output
SEG35														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG36														SEG output
SEG37														DC output <input type="checkbox"/> C <input type="checkbox"/> P
SEG38														SEG output
SEG39														DC output <input type="checkbox"/> C <input type="checkbox"/> P
Legend:	<ADDRESS> H: High order address, L: Low order address D: Data bit												<OUTPUT SPECIFICATION> C: Complementary output P: Pch open drain output	

Note:
 1. Even if there are unused areas, set "---" (hyphens) such that there are no blank columns.
 2. When DC output is selected, the display memory of the COM0 column becomes effective.

5.3 Segment Ports Output Specifications

For the output specification of the segment output ports SEG0–SEG39 segment output and DC output can be selected in units of two terminals. When used for liquid crystal panel drives, select segment output; when used as regular output port, select DC output. When DC output is selected, either complementary output or Pch open drain output may further be selected.

However, for segment output ports that will not be used, select segment output.

Refer to the "E0C62 Family Development Tool Reference Manual" for the segment option source file creation.

■ When segment output is selected

The segment output port has a segment decoder built-in, and the data bit of the optional address in the segment memory area (040H–06FH or 0C0H–0EFH) can be allocated to the optional segment. With this, up to 160 segments (120 segments when 1/3 duty is selected) of liquid crystal panel could be driven.

The segment memory may be allocated only one segment and multiple setting is not possible.

The allocated segment displays when the bit for this segment memory is set to "1", and goes out when bit is set to "0".

Segment allocation is set to H for high address (4–6 or C–E), to L for low address (0–F), and to D for data bit (0–3) and are recorded in their respective column in the option list. For segment ports that will not be used, write "---" (hyphen) in the H, L, and D columns of COM0–COM3.

Examples

- When 1/4 duty is selected

0	601	600	632	603	S
1	612	611	610	623	S

- When 1/3 duty is selected

0	601	600	632	---	S
1	612	611	610	---	S

■ When DC output is selected

The DC output can be selected in units of two terminals and up to 40 terminals may be allocated for DC output. Also, either complementary output or Pch open drain output is likewise selected in units of two terminals. When the bit for the selected segment memory is set to "1", the segment output port goes high (VDD), and goes low (VSS) when set to "0". Segment allocation is the same as when segment output is selected but for the while the segment memory allocated to COM1–COM3 becomes ineffective. Write three hyphens ("---") in the COM1–COM3 columns in the option list.

Example

- When complementary output is set to SEG16 and SEG17, and Pch open drain output is set to SEG18 and SEG19.

16	6E0	---	---	---	C
17	6F0	---	---	---	C
18	6E1	---	---	---	P
19	6F1	---	---	---	P

5.4 SOG6233 Quick Reference

■ Starting command and input/output files

Execution file: SOG6233.EXE

_ indicates a blank.

indicates the Return key.

A parameter enclosed by [] can be omitted.

Starting command: **SOG6233_ [-H]**

Option: -H: Specifies the segment option document file for input file of SOG6233.

Input file: C233XXX.SEG (Segment option source file)
C233XXXS.DOC (Segment option document file, when -H option use)

Output file: C233XXXS.DOC (Segment option document file)
C233XXXS.HEX (Segment option HEX file)

■ Display example

```

*** E0C6233 SEGMENT OPTION GENERATOR. --- Ver 3.10A ***
EEEEEEEEEE PPPPPPPP SSSSSSSS OOOOOOOO NNN NNN
EEEEEEEEEE PPPPPPPPPP SSS SSSS OOO OOO NNNN NNN
EEE PPP PPP SSS SSS OOO OOO NNNNN NNN
EEE PPP PPP SSS SSS OOO OOO NNNNNN NNN
EEEEEEEEEE PPPPPPPPPP SSSSSSSS OOO OOO NNN NNN NNN
EEEEEEEEEE PPPPPPPP SSSS OOO OOO NNN NNNNNN
EEE PPP SSS OOO OOO NNN NNNNN
EEE PPP SSS SSS OOO OOO NNN NNNN
EEEEEEEEEE PPP SSS SSS OOO OOO NNN NNN
EEEEEEEEEE PPP SSSSSSSS OOOOOOOO NNN NN

(C) COPYRIGHT 1991 SEIKO EPSON CORP.

SEGMENT OPTION SOURCE FILE NAME IS " C233XXX.SEG "

THIS SOFTWARE MAKES NEXT FILES.

C233XXXS.HEX ... SEGMENT OPTION HEX FILE.
C233XXXS.DOC ... SEGMENT OPTION DOCUMENT FILE.

STRIKE ANY KEY.
    
```

Start-up message

When SOG6233 is started, the start-up message is displayed.

For "STRIKE ANY KEY.", press any key to advance the program execution.

To suspend execution, press the "CTRL" and "C" keys together: the sequence returns to the DOS command level.

```

*** E0C6233 USER'S OPTION SETTING. --- Ver 3.10A ***
CURRENT DATE IS 91/10/14
PLEASE INPUT NEW DATE : 91/10/14
    
```

Date input

Enter the 2-digit year, month, and day of the month by delimiting them with a slash ("/"). When not modifying the date, press the RETURN key "" to continue.

```

*** SOURCE FILE(S) ***
C2330A0 C2330B0 C2330C0 ..(1)
    
```

Input file selection

(1) Will display the files on the current drive.

```

SEGMENT OPTION SOURCE FILE IS NOT FOUND. ..(a) -H option not use
SEGMENT OPTION FILE IS NOT FOUND. ..(b) -H option use
FUNCTION OPTION FILE IS NOT FOUND. ..(c)
    
```

If no modifiable source exists, an error message (a) or (b) will be displayed and the program will be terminated.

If no function option document file exists, an error message (c) will be displayed and the program will be terminated

```

PLEASE INPUT SEGMENT OPTION FILE NAME? C2330A0 ..(2)
    
```

(2) Enter the file name.

```

PLEASE INPUT SEGMENT SOURCE FILE NAME? C2330N0
SEGMENT SOURCE FILE IS NOT FOUND. ..(d) -H option not use
PLEASE INPUT SEGMENT OPTION DOCUMENT FILE NAME? C2330N0
SEGMENT OPTION DOCUMENT FILE IS NOT FOUND. ..(e) -H option use
    
```

If the specified file name is not found in the current drive, an error message (d) or (e) is displayed, prompting entry of other file name.

```
SEGMENT RAM ADDRESS 400-6F3 select OK(Y/N)? Y  ..(3)
```

When C0-EF is selected for the segment RAM address by FOG6233, following message is displayed.

```
SEGMENT RAM ADDRESS C00-EF3 select OK(Y/N)? Y  ..(f)
```

```
PLEASE INPUT USER'S NAME? SEIKO EPSON CORP.  ..(4)
PLEASE INPUT ANY COMMENT
(ONE LINE IS 50 CHR)? ED MARKETING DEPARTMENT  ..(5)
? 421-8 HINO HINO-SHI TOKYO 191-8501 JAPAN 
? TEL 042-587-5816 
? FAX 042-587-5624 
? 
```

```
END OF OPTION SETTING.
DO YOU MAKE HEX FILE (Y/N) ? Y  ..(1)

*** OPTION EPROM SELECT MENU ***

1. 27C64
2. 27C128
3. 27C256
4. 27C512

PLEASE SELECT NO.? 2  ..(2)

2. 27C128 SELECTED

MAKING FILE IS COMPLETED.
```

(3) Refer to the file name input in number (2) + the "F.DOC" file (in this case, C2330A0F.DOC) from the current directory and indicate whether 40-6F or C0-EF has been selected for the segment RAM address. (FOG6233, option No. 15)

If this address is OK, enter a "Y" and if not enter an "N", then reset the function option using FOG6233.

(4) Enter the customer's company name.

(5) Enter any comment.
(Within 50 characters x 10 lines)

Then, move to the confirmation procedure for HEX file generation.

EPROM selection

When selecting file is completed, the following message is output to ask the operator whether to generate the HEX file.

(1) When debugging the program with EVA6S32R, HEX file is needed, so enter "Y ". If "N " is entered, no HEX file is generated and only document file is generated.

(2) For the option ROM selection menu displayed when "Y " is entered in Step (1), select the EPROM to be used for setting EVA6S32R options.

When a series of operations are complete, the SOG6233 generates files. If no error is committed while setting segment options, "MAKING FILE IS COMPLETED" will be displayed and the SOG6233 program will be terminated.

■ Error messages

Error message	Explanation
S (Syntax Error)	The data was written in an invalid format.
N (Segment No. Select Error)	The segment number outside the specificable range was specified.
R (RAM Address Select Error)	The segment memory address or data bit outside the specificable range was specified.
D (Duplication Error)	The same data (SEG port No., segment memory address, or data bit) was specified more than once.
Out Port Set Error	The output specifications were not set in units of two ports.

5.5 Sample Files

■ Example of segment option source file

```

; EVA6S32R LCD SEGMENT DECODE TABLE
0      680      681      690      691      S
1      692      693      6A0      6A2      S
2      6A3      6A1      682      683      S
3      6B0      6B1      6B2      6B3      S
4      640      641      650      651      S
5      652      653      660      662      S
6      663      661      642      643      S
7      670      671      672      673      S
8      600      601      610      611      S
9      612      613      620      622      S
10     623      621      602      603      S
11     630      631      632      633      S
12     5C0      5C1      5D0      5D1      S
13     5D2      5D3      5E0      5E2      S
14     5E3      5E1      5C2      5C3      S
15     5F0      5F1      5F2      5F3      S
16     580      581      590      591      S
17     592      593      5A0      5A2      S
18     5A3      5A1      582      583      S
19     5B0      5B1      5B2      5B3      S
20     540      541      550      551      S
21     552      553      560      562      S
22     563      561      542      543      S
23     570      571      572      573      S
24     500      501      510      511      S
25     512      513      520      522      S
26     523      521      502      503      S
27     530      531      532      533      S
28     4C0      4C1      4D0      4D1      S
29     4D2      4D3      4E0      4E2      S
30     4E3      4E1      4C2      4C3      S
31     4F0      4F1      4F2      4F3      S
32     480      481      490      491      S
33     492      493      4A0      4A2      S
34     4A3      4A1      482      483      S
35     4B0      4B1      4B2      4B3      S
36     440      441      450      451      S
37     452      453      460      462      S
38     6E0      -        -        -        C
39     6E1      -        -        -        C

```

■ Example of segment option document file

```

* EOC6233 SEGMENT OPTION DOCUMENT V 3.10A
*
* FILE NAME      C2330A0S.DOC
* USER'S NAME   SEIKO EPSON CORP.
* INPUT DATE    91/10/14
* COMMENT       ED MARKETING DEPARTMENT
*               421-8 HINO HINO-SHI TOKYO 191-8501 JAPAN
*               TEL 042-587-5816
*               FAX 042-587-5624
*
*
* OPTION NO.20
*
* < LCD SEGMENT DECODE TABLE >
*
* SEG COM0 COM1 COM2 COM3 SPEC
*
  0  680  681  690  691  S
  1  692  693  6A0  6A2  S
  2  6A3  6A1  682  683  S
  3  6B0  6B1  6B2  6B3  S
  4  640  641  650  651  S
  5  652  653  660  662  S
  6  663  661  642  643  S
  7  670  671  672  673  S
  8  600  601  610  611  S
  9  612  613  620  622  S
 10  623  621  602  603  S
 11  630  631  632  633  S
 12  5C0  5C1  5D0  5D1  S
 13  5D2  5D3  5E0  5E2  S
 14  5E3  5E1  5C2  5C3  S
 15  5F0  5F1  5F2  5F3  S
 16  580  581  590  591  S
 17  592  593  5A0  5A2  S
 18  5A3  5A1  582  583  S
 19  5B0  5B1  5B2  5B3  S
 20  540  541  550  551  S
 21  552  553  560  562  S
 22  563  561  542  543  S
 23  570  571  572  573  S
 24  500  501  510  511  S
 25  512  513  520  522  S
 26  523  521  502  503  S
 27  530  531  532  533  S
 28  4C0  4C1  4D0  4D1  S
 29  4D2  4D3  4E0  4E2  S
 30  4E3  4E1  4C2  4C3  S
 31  4F0  4F1  4F2  4F3  S
 32  480  481  490  491  S
 33  492  493  4A0  4A2  S
 34  4A3  4A1  482  483  S
 35  4B0  4B1  4B2  4B3  S
 36  440  441  450  451  S
 37  452  453  460  462  S
 38  6E0  6E2  6E3  6F0  C
 39  6E1  6F1  6F2  6F3  C
\\END

```

Note End mark "¥¥END" may be used instead of "\\END" depending on the PC used. (The code of \ and ¥ is 5CH.)

6 ICE CONTROL SOFTWARE ICS6233

6.1 ICS6233 Outline

The In-circuit Emulator ICE62R (ICE6200) connects the target board produced by the user via the EVA6S32R and performs real time target system evaluation and debugging by passing through the RS-232C from the host computer and controlling it. The operation on the host computer side and ICE62R (ICE6200) control is done through the ICE Control Software ICS6233.

The ICS6233 has a set of numerous and highly functional emulation commands which provide sophisticated break function, on-the-fly data display, history display, etc., and so perform a higher level of debugging.




Fig. 6.1.1 Debugging system using ICE62R (ICE6200)

☞ The functions of the ICE62R (ICE6200) and commands are same as for the E0C62 Family. Refer to the "E0C62 Family Development Tool Reference Manual" for details.

6.2 ICS6233 Restrictions

Take the following precautions when using the ICS6233.

■ ROM Area

The ROM area is limited to a maximum address of BFFH. Assigning data above the BFFH address causes an error.

■ RAM Area

The RAM area is limited to a maximum address of 1FEH. However, as the following addresses are in the unused area, designation of this area with the ICE commands produces an error.

Unused area: 0A0H–0BFH, 0C0H–0EFH (when 040H–06FH is selected for the display memory),
0F4H, 0F5H, 0FAH, 0FBH, 180H–1EFH, 1F4H, 1F5H, 1FAH, 1FBH

(Refer to the "E0C6233 Technical Manual" for details.)

■ Undefined Code

The SLP instruction is not specified for the E0C6233 and so cannot be used.

■ OPTLD Command

In the ICS6233, OPTLD command can be used.

This command loads HEX files (function option and LCD segment option data) into the EVA6S32R memory via the ICE62R (ICE6200).

OPTLD *READ HEXA DATA FILE*

Format #OPTLD, 1, <file name> [] ... (1)
 #OPTLD, 2, <file name> [] ... (2)

Function (1) Load function option HEX file in the EVA6S32R function option data memory.
 It is HEX file output by the function option generator and has intel HEX format.
 (2) Load segment option HEX file in the EVA6S32R segment option data memory.
 It is HEX file output by the segment option generator and has intel HEX format.

Examples #OPTLD, 1, C233XXX [] C233XXXF.HEX file is loaded in the function option data memory.
 #OPTLD, 2, C233XXX [] C233XXXS.HEX file is loaded in the segment option data memory.

6.3 ICS6233 Quick Reference

■ Starting command and input/output files

␣ indicates the Return key.

Execution file: ICS6233.BAT (ICS6233J.EXE) . . . for MS-DOS
ICS6233B.BAT (ICS6233W.EXE) . . . for PC-DOS

Starting command: **ICS6233 (ICS6233J)**␣ . . . for MS-DOS
ICS6233B (ICS6233W)␣ . . . for PC-DOS

Input file: C233XXXL.HEX (Object file, low-order)
C233XXXH.HEX (Object file, high-order)
C233XXXD.HEX (Data RAM file)
C233XXXC.HEX (Control file)

Output file: C233XXXL.HEX (Object file, low-order)
C233XXXH.HEX (Object file, high-order)
C233XXXD.HEX (Data RAM file)
C233XXXC.HEX (Control file)

■ Display example

```

*** E0C6233 ICE CONTROL SOFTWARE. --- Ver 3.01 ***
EEEEEEEEEE PPPPPPPP SSSSSSS 0000000 NNN NNN
EEEEEEEEEE PPPPPPPP SSS SSSS 000 000 NNNN NNN
EEE PPP PPP SSS SSS 000 000 NNNNN NNN
EEE PPP PPP SSS 000 000 NNNNNN NNN
EEEEEEEEEE PPPPPPPP SSSSSS 000 000 NNN NNN NNN
EEEEEEEEEE PPPPPPPP SSSS 000 000 NNN NNNNNN
EEE PPP SSS 000 000 NNN NNNNN
EEE PPP SSS SSS 000 000 NNN NNNN
EEEEEEEEEE PPP SSS SSS 000 000 NNN NNN
EEEEEEEEEE PPP SSSSSS 0000000 NNN NN

```

(C) COPYRIGHT 1991 SEIKO EPSON CORP.

* ICE POWER ON RESET *
* DIAGNOSTIC TEST OK *
#

Start-up message

When ICS6233 is started, the start-up message is displayed, and a self-test is automatically performed. ICS6233 commands are awaited when the program is properly loaded and the # mark is displayed.

Debugging can be done by entering command after the # mark.

The ICS6233 program is terminated by entering the Q (Quit) command.

Note Confirm that the cables connected properly, then operate the ICS6233.

■ Error messages

Error message	Meaning	Recover procedure
* COMMUNICATION ERROR OR ICE NOT READY *	ICE62R (ICE6200) is disconnected or power is OFF.	Switch OFF the host power supply, connect cable, and reapply power. Or switch ON power to ICE62R (ICE6200).
* TARGET DOWN (1) *	Evaluation board is disconnected. (Check at power ON)	Switch OFF power to ICE, and connect the evaluation board. Then, apply power to ICE62R (ICE6200).
* TARGET DOWN (2) *	Evaluation board is disconnected. (Check at command execution)	Switch OFF power to ICE, and connect the evaluation board. Then, apply power to ICE62R (ICE6200).
* UNDEFINED PROGRAM CODE EXIST *	Undefined code is detected in the program loaded from ROM or FD.	Convert ROM and FD data with the cross assembler, then restart the ICE62R (ICE6200).
* COMMAND ERROR *	A miss occurs by command input.	Reenter the proper command.
(No response after power on)	The ICE-to-HOST cable is disconnected on the host side.	Switch OFF the host power supply, connect cable, and reapply power.

■ Command list

Item No.	Function	Command Format	Outline of Operation
1	Assemble	#A,a [↵]	Assemble command mnemonic code and store at address "a"
2	Disassemble	#L,a1,a2 [↵]	Contents of addresses a1 to a2 are disassembled and displayed
3	Dump	#DP,a1,a2 [↵]	Contents of program area a1 to a2 are displayed
		#DD,a1,a2 [↵]	Content of data area a1 to a2 are displayed
4	Fill	#FP,a1,a2,d [↵]	Data d is set in addresses a1 to a2 (program area)
		#FD,a1,a2,d [↵]	Data d is set in addresses a1 to a2 (data area)
5	Set Run Mode	#G,a [↵]	Program is executed from the "a" address
		#TIM [↵]	Execution time and step counter selection
		#OTF [↵]	On-the-fly display selection
6	Trace	#T,a,n [↵]	Executes program while displaying results of step instruction from "a" address
		#U,a,n [↵]	Displays only the final step of #T,a,n
7	Break	#BA,a [↵]	Sets Break at program address "a"
		#BAR,a [↵]	Breakpoint is canceled
		#BD [↵]	Break condition is set for data RAM
		#BDR [↵]	Breakpoint is canceled
		#BR [↵]	Break condition is set for EVA6S32R CPU internal registers
		#BRR [↵]	Breakpoint is canceled
		#BM [↵]	Combined break conditions set for program data RAM address and registers
		#BMR [↵]	Cancel combined break conditions for program data ROM address and registers
		#BRES [↵]	All break conditions canceled
		#BC [↵]	Break condition displayed
		#BE [↵]	Enter break enable mode
8	Move	#MP,a1,a2,a3 [↵]	Contents of program area addresses a1 to a2 are moved to addresses a3 and after
		#MD,a1,a2,a3 [↵]	Contents of data area addresses a1 to a2 are moved to addresses a3 and after
9	Data Set	#SP,a [↵]	Data from program area address "a" are written to memory
		#SD,a [↵]	Data from data area address "a" are written to memory
10	Change CPU Internal Registers	#DR [↵]	Display EVA6S32R CPU internal registers
		#SR [↵]	Set EVA6S32R CPU internal registers
		#I [↵]	Reset EVA6S32R CPU
		#DXY [↵]	Display X, Y, MX and MY
		#SXY [↵]	Set data for X and Y display and MX, MY

Item No.	Function	Command Format	Outline of Operation
11	History	#H,p1,p2 <input type="checkbox"/>	Display history data for pointer 1 and pointer 2
		#HB <input type="checkbox"/>	Display upstream history data
		#HG <input type="checkbox"/>	Display 21 line history data
		#HP <input type="checkbox"/>	Display history pointer
		#HPS,a <input type="checkbox"/>	Set history pointer
		#HC,S/C/E <input type="checkbox"/>	Sets up the history information acquisition before (S), before/after (C) and after (E)
		#HA,a1,a2 <input type="checkbox"/>	Sets up the history information acquisition from program area a1 to a2
		#HAR,a1,a2 <input type="checkbox"/>	Sets up the prohibition of the history information acquisition from program area a1 to a2
		#HAD <input type="checkbox"/>	Indicates history acquisition program area
		#HS,a <input type="checkbox"/>	Retrieves and indicates the history information which executed a program address "a"
		#HSW,a <input type="checkbox"/>	Retrieves and indicates the history information which wrote or
#HSR,a <input type="checkbox"/>	read the data area address "a"		
12	File	#RF,file <input type="checkbox"/>	Move program file to memory
		#RFD,file <input type="checkbox"/>	Move data file to memory
		#VF,file <input type="checkbox"/>	Compare program file and contents of memory
		#VFD,file <input type="checkbox"/>	Compare data file and contents of memory
		#WF,file <input type="checkbox"/>	Save contents of memory to program file
		#WFD,file <input type="checkbox"/>	Save contents of memory to data file
		#CL,file <input type="checkbox"/>	Load ICE62R (ICE6200) set condition from file
		#CS,file <input type="checkbox"/>	Save ICE62R (ICE6200) set condition to file
		#OPTLD,1,file <input type="checkbox"/>	Load function option data from file
#OPTLD,2,file <input type="checkbox"/>	Load segment option data from file		
13	Coverage	#CVD <input type="checkbox"/>	Indicates coverage information
		#CVR <input type="checkbox"/>	Clears coverage information
14	ROM Access	#RP <input type="checkbox"/>	Move contents of ROM to program memory
		#VP <input type="checkbox"/>	Compare contents of ROM with contents of program memory
		#ROM <input type="checkbox"/>	Set ROM type
15	Terminate ICE	#Q <input type="checkbox"/>	Terminate ICE and return to operating system control
16	Command Display	#HELP <input type="checkbox"/>	Display ICE62R (ICE6200) instruction
17	Self Diagnosis	#CHK <input type="checkbox"/>	Report results of ICE62R (ICE6200) self diagnostic test

means press the RETURN key.

7 MASK DATA CHECKER MDC6233

7.1 MDC6233 Outline

The Mask Data Checker MDC6233 is a software tool which checks the program data (C233XXXH.HEX and C233XXXL.HEX) and option data (C233XXXF.DOC and C233XXXS.DOC) created by the user and creates the data file (C6233XXX.PAn) for generating mask patterns. The user must send the file generated through this software tool to Seiko Epson.

Moreover, MDC6233 has the capability to restore the generated data file (C6233XXX.PA0) to the original file format.




Fig. 7.1.1 MDC6233 execution flow

☞ The operating method is same as for the E0C62 Family. Refer to the "E0C62 Family Development Tool Reference Manual" for details.

7.2 MDC6233 Quick Reference

■ Starting command and input/output files

Execution file: MDC6233.EXE

Starting command: **MDC6233**

indicates the Return key.

Input file:	C233XXXL.HEX (Object file, low-order)] When packing
	C233XXXH.HEX (Object file, high-order)	
	C233XXXF.DOC (Function option document file)	
	C233XXXS.DOC (Segment option document file)	
	C6233XXX.PAn (Packed file)] When unpacking
Output file:	C6233XXX.PAn (Packed file)] When packing
	C233XXXL.PAn (Object file, low-order)] When unpacking
	C233XXXH.PAn (Object file, high-order)	
	C233XXXF.PAn (Function option document file)	
	C233XXXS.PAn (Segment option document file)	

■ Display examples

```

*** E0C6233 PACK / UNPACK PROGRAM Ver 2.00 ***
EEEEEEEEEE P P P P P P P P S S S S S S S S O O O O O O O O N N N N N N N N
EEEEEEEEEE P P P P P P P P P P S S S S S S S S O O O O O O N N N N N N N N
EEE PPP PPP S S S S S S S S O O O O O O N N N N N N N N
EEE PPP PPP S S S S S S S S O O O O O O N N N N N N N N
EEEEEEEEEE P P P P P P P P P P S S S S S S S S O O O O O O N N N N N N N N
EEEEEEEEEE P P P P P P P P S S S S S S S S O O O O O O N N N N N N N N
EEE PPP PPP S S S S S S S S O O O O O O N N N N N N N N
EEE PPP PPP S S S S S S S S O O O O O O N N N N N N N N
EEEEEEEEEE P P P P P P P P S S S S S S S S O O O O O O N N N N N N N N
EEEEEEEEEE P P P P P P P P S S S S S S S S O O O O O O N N N N N N N N

(C) COPYRIGHT 1991 SEIKO EPSON CORP.

--- OPERATION MENU ---

      1. PACK
      2. UNPACK

PLEASE SELECT NO.?
```

Start-up message

When MDC6233 is started, the start-up message and operation menu are displayed. Here, the user is prompted to select operation options.

```

--- OPERATION MENU ---

      1. PACK
      2. UNPACK

PLEASE SELECT NO.? 1

C233XXXH.HEX -----+
C233XXXL.HEX -----+
C233XXXF.DOC -----+----- C233XXX.PAn (PACK FILE)
C233XXS.DOC -----+

PLEASE INPUT PACK FILE NAME (C6233XXX.PAn) ? C62330A0.PA0 ... (2)

C2330A0H.HEX -----+
C2330A0L.HEX -----+
C2330A0F.DOC -----+----- C2330A0.PA0
C2330A0S.DOC -----+
```

Packing of data

- (1) Select "1.PACK" in the operation menu.
- (2) Enter the file name.

After submitting the data to Seiko Epson and there is a need to re-submit the data, increase the numeric value of "n" by one when the input is made. (Example: When re-submitting data after "C6233XXX.PA0" has been submitted, the pack file name should be entered as "C6233XXX.PA1".)

With this, the mask file (C6233XXX.PAn) is generated, and the MDC6233 program will be terminated. Submit this file to Seiko Epson.

Note Don't use the data generated with the -N option of the Cross Assembler (ASM6233) as program data. If the program data generated with the -N option of the Cross Assembler is packed, following message is displayed.

```

HEX DATA ERROR : DATA (NO FFh)
```

```

--- OPERATION MENU ---

      1. PACK
      2. UNPACK

PLEASE SELECT NO.? 2

PLEASE INPUT PACKED FILE NAME (C6233XXX.PAn) ? C62330A0.PA0 ... (2)

      +----- C2330A0H.PA0
      +----- C2330A0L.PA0
C62330A0.PA0 -----+----- C2330A0F.PA0
      +----- C2330A0S.PA0
```

Unpacking of data

- (1) Select "2.UNPACK" in the operation menu.
- (2) Enter the packed file name.

With this, the mask data file (C6233XXX.PAn) is restored to the original file format, and the MDC6233 program will be terminated.

Since the extension of the file name remains as "PAn", it must be renamed back to its original form ("HEX" and "DOC") in order to re-debug or modify the restored file.

■ Error messages

Program data error

Error Message	Explanation
1. HEX DATA ERROR : NOT COLON.	There is no colon.
2. HEX DATA ERROR : DATA LENGTH. (NOT 00-20h)	The data length of 1 line is not in the 00-20H range.
3. HEX DATA ERROR : ADDRESS.	The address is beyond the valid range of the program ROM.
4. HEX DATA ERROR : RECORD TYPE. (NOT 00)	The record type of 1 line is not 00.
5. HEX DATA ERROR : DATA. (NOT 00-FFh)	The data is not in the range between 00H and 0FFH.
6. HEX DATA ERROR : TOO MANY DATA IN ONE LINE.	There are too many data in 1 line.
7. HEX DATA ERROR : CHECK SUM.	The checksum is not correct.
8. HEX DATA ERROR : END MARK.	The end mark is not : 00000001FF.
9. HEX DATA ERROR : DUPLICATE.	There is duplicate definition of data in the same address.
10. HEX DATA ERROR : DATA (NO FFh)	There is an undefined field in the HEX data.

Function option data error

Error Message	Explanation
1. OPTION DATA ERROR : START MARK.	The start mark is not "\OPTION". (during unpacking) *
2. OPTION DATA ERROR : OPTION NUMBER.	The option number is not correct.
3. OPTION DATA ERROR : SELECT NUMBER.	The option selection number is not correct.
4. OPTION DATA ERROR : END MARK.	The end mark is not "\\END" (packing) or "\END" (unpacking).*

Segment option data error

Error Message	Explanation
1. SEGMENT DATA ERROR : START MARK.	The start mark is not "\SEGMENT". (during unpacking) *
2. SEGMENT DATA ERROR : DATA.	The segment data is not correct.
3. SEGMENT DATA ERROR : SEGMENT NUMBER.	The SEG No. is not correct.
4. SEGMENT DATA ERROR : SPEC.	The output specification of the SEG terminal is not correct.
5. SEGMENT DATA ERROR : END MARK.	The end mark is not "\\END" (packing) or "\END" (unpacking).*

File error

Error Message	Explanation
1. <File_name> FILE IS NOT FOUND.	The file is not found or the file number set in CONFIG.SYS is less than 10.
2. PACK FILE NAME (File_name) ERROR.	The packed input format for the file name is wrong.
3. PACKED FILE NAME (File_name) ERROR.	The unpacked input format for the file name is wrong.
4. VERSION NUMBER ERROR : X.DOC	FOG6233, SOG6233 different from the version No. has been used.

System error

Error Message	Explanation
1. DIRECTORY FULL.	The directory is full.
2. DISK WRITE ERROR.	Writing on the disk is failed.

* / sometimes appears as ¥, depending on the personal computer being used.

APPENDIX A. E0C6233 INSTRUCTION SET

Classification	Mnemonic	Operand	Operation Code						Flag			Clock	Operation							
			B	A	9	8	7	6	5	4	3			2	1	0	I	D	Z	C
Branch instructions	PSET	p	1	1	1	0	0	1	0	p3	p2	p1	p0					5	NBP ← p4, NPP ← p3~p0	
	JP	s	0	0	0	0	s7	s6	s5	s4	s3	s2	s1	s0					5	PCB ← NBP, PCP ← NPP, PCS ← s7~s0
		C, s	0	0	1	0	s7	s6	s5	s4	s3	s2	s1	s0					5	PCB ← NBP, PCP ← NPP, PCS ← s7~s0 if C=1
		NC, s	0	0	1	1	s7	s6	s5	s4	s3	s2	s1	s0					5	PCB ← NBP, PCP ← NPP, PCS ← s7~s0 if C=0
		Z, s	0	1	1	0	s7	s6	s5	s4	s3	s2	s1	s0					5	PCB ← NBP, PCP ← NPP, PCS ← s7~s0 if Z=1
		NZ, s	0	1	1	1	s7	s6	s5	s4	s3	s2	s1	s0					5	PCB ← NBP, PCP ← NPP, PCS ← s7~s0 if Z=0
	JPBA		1	1	1	1	1	1	1	0	1	0	0	0					5	PCB ← NBP, PCP ← NPP, PCSH ← B, PCSL ← A
	CALL	s	0	1	0	0	s7	s6	s5	s4	s3	s2	s1	s0					7	M(SP-1) ← PCP, M(SP-2) ← PCSH, M(SP-3) ← PCSL+1 SP ← SP-3, PCP ← NPP, PCS ← s7~s0
	CALZ	s	0	1	0	1	s7	s6	s5	s4	s3	s2	s1	s0					7	M(SP-1) ← PCP, M(SP-2) ← PCSH, M(SP-3) ← PCSL+1 SP ← SP-3, PCP ← 0, PCS ← s7~s0
	RET		1	1	1	1	1	1	0	1	1	1	1	1					7	PCSL ← M(SP), PCSH ← M(SP+1), PCP ← M(SP+2) SP ← SP+3
	RETS		1	1	1	1	1	1	0	1	1	1	1	0					12	PCSL ← M(SP), PCSH ← M(SP+1), PCP ← M(SP+2) SP ← SP+3, PC ← PC+1
RETD	l	0	0	0	1	l7	l6	l5	l4	l3	l2	l1	l0					12	PCSL ← M(SP), PCSH ← M(SP+1), PCP ← M(SP+2) SP ← SP+3, M(X) ← l3~l0, M(X+1) ← l7~l4, X ← X+2	
System control instructions	NOP5		1	1	1	1	1	1	1	1	1	0	1	1					5	No operation (5 clock cycles)
	NOP7		1	1	1	1	1	1	1	1	1	1	1	1					7	No operation (7 clock cycles)
	HALT		1	1	1	1	1	1	1	1	1	0	0	0					5	Halt (stop clock)
Index operation instructions	INC	X	1	1	1	0	1	1	1	0	0	0	0	0					5	X ← X+1
		Y	1	1	1	0	1	1	1	1	0	0	0	0					5	Y ← Y+1
	LD	X, x	1	0	1	1	x7	x6	x5	x4	x3	x2	x1	x0					5	XH ← x7~x4, XL ← x3~x0
		Y, y	1	0	0	0	y7	y6	y5	y4	y3	y2	y1	y0					5	YH ← y7~y4, YL ← y3~y0
		XP, r	1	1	1	0	1	0	0	0	0	0	r1	r0					5	XP ← r
		XH, r	1	1	1	0	1	0	0	0	0	1	r1	r0					5	XH ← r
		XL, r	1	1	1	0	1	0	0	0	1	0	r1	r0					5	XL ← r
		YP, r	1	1	1	0	1	0	0	1	0	0	r1	r0					5	YP ← r
		YH, r	1	1	1	0	1	0	0	1	0	1	r1	r0					5	YH ← r
		YL, r	1	1	1	0	1	0	0	1	1	0	r1	r0					5	YL ← r
		r, XP	1	1	1	0	1	0	1	0	0	0	r1	r0					5	r ← XP
		r, XH	1	1	1	0	1	0	1	0	0	1	r1	r0					5	r ← XH
		r, XL	1	1	1	0	1	0	1	0	1	0	r1	r0					5	r ← XL
		r, YP	1	1	1	0	1	0	1	1	0	0	r1	r0					5	r ← YP
		r, YH	1	1	1	0	1	0	1	1	0	1	r1	r0					5	r ← YH
		r, YL	1	1	1	0	1	0	1	1	1	0	r1	r0					5	r ← YL
		ADC	XH, i	1	0	1	0	0	0	0	0	i3	i2	i1	i0		↕	↕		7
	XL, i		1	0	1	0	0	0	0	1	i3	i2	i1	i0		↕	↕		7	XL ← XL+i3~i0+C
	YH, i		1	0	1	0	0	0	1	0	i3	i2	i1	i0		↕	↕		7	YH ← YH+i3~i0+C
YL, i	1		0	1	0	0	0	1	1	i3	i2	i1	i0		↕	↕		7	YL ← YL+i3~i0+C	

Classification	Mnemonic	Operand	Operation Code								Flag			Clock	Operation					
			B	A	9	8	7	6	5	4	3	2	1			0	I	D	Z	C
Index operation instructions	CP	XH, i	1	0	1	0	0	1	0	0	i3	i2	i1	i0	↑	↓			7	XH-i3~i0
		XL, i	1	0	1	0	0	1	0	1	i3	i2	i1	i0	↓	↑			7	XL-i3~i0
		YH, i	1	0	1	0	0	1	1	0	i3	i2	i1	i0	↑	↓			7	YH-i3~i0
		YL, i	1	0	1	0	0	1	1	1	i3	i2	i1	i0	↓	↑			7	YL-i3~i0
Data transfer instructions	LD	r, i	1	1	1	0	0	0	r1	r0	i3	i2	i1	i0					5	r ← i3~i0
		r, q	1	1	1	0	1	1	0	0	r1	r0	q1	q0					5	r ← q
		A, Mn	1	1	1	1	1	0	1	0	n3	n2	n1	n0					5	A ← M(n3~n0)
		B, Mn	1	1	1	1	1	0	1	1	n3	n2	n1	n0					5	B ← M(n3~n0)
		Mn, A	1	1	1	1	1	0	0	0	n3	n2	n1	n0					5	M(n3~n0) ← A
		Mn, B	1	1	1	1	1	0	0	1	n3	n2	n1	n0					5	M(n3~n0) ← B
	LDPX	MX, i	1	1	1	0	0	1	1	0	i3	i2	i1	i0					5	M(X) ← i3~i0, X ← X+1
		r, q	1	1	1	0	1	1	1	0	r1	r0	q1	q0					5	r ← q, X ← X+1
	LDPY	MY, i	1	1	1	0	0	1	1	1	i3	i2	i1	i0					5	M(Y) ← i3~i0, Y ← Y+1
		r, q	1	1	1	0	1	1	1	1	r1	r0	q1	q0					5	r ← q, Y ← Y+1
LBPX	MX, l	1	0	0	1	l7	l6	l5	l4	l3	l2	l1	l0					5	M(X) ← l3~l0, M(X+1) ← l7~l4, X ← X+2	
Flag operation instructions	SET	F, i	1	1	1	1	0	1	0	0	i3	i2	i1	i0	↑	↑	↑	↑	7	F ← F∨i3~i0
	RST	F, i	1	1	1	1	0	1	0	1	i3	i2	i1	i0	↓	↓	↓	↓	7	F ← F∧i3~i0
	SCF		1	1	1	1	0	1	0	0	0	0	0	1			↑		7	C ← 1
	RCF		1	1	1	1	0	1	0	1	1	1	1	0			↓		7	C ← 0
	SZF		1	1	1	1	0	1	0	0	0	0	1	0			↑		7	Z ← 1
	RZF		1	1	1	1	0	1	0	1	1	1	0	1			↓		7	Z ← 0
	SDF		1	1	1	1	0	1	0	0	0	1	0	0			↑		7	D ← 1 (Decimal Adjuster ON)
	RDF		1	1	1	1	0	1	0	1	1	0	1	1			↓		7	D ← 0 (Decimal Adjuster OFF)
	EI		1	1	1	1	0	1	0	0	1	0	0	0			↑		7	I ← 1 (Enables Interrupt)
	DI		1	1	1	1	0	1	0	1	0	1	1	1			↓		7	I ← 0 (Disables Interrupt)
Stack operation instructions	INC	SP	1	1	1	1	1	1	0	1	1	0	1	1					5	SP ← SP+1
	DEC	SP	1	1	1	1	1	1	0	0	1	0	1	1					5	SP ← SP-1
	PUSH	r	1	1	1	1	1	1	0	0	0	0	r1	r0					5	SP ← SP-1, M(SP) ← r
		XP	1	1	1	1	1	1	0	0	0	1	0	0					5	SP ← SP-1, M(SP) ← XP
		XH	1	1	1	1	1	1	0	0	0	1	0	1					5	SP ← SP-1, M(SP) ← XH
		XL	1	1	1	1	1	1	0	0	0	1	1	0					5	SP ← SP-1, M(SP) ← XL
		YP	1	1	1	1	1	1	0	0	0	1	1	1					5	SP ← SP-1, M(SP) ← YP
		YH	1	1	1	1	1	1	0	0	1	0	0	0					5	SP ← SP-1, M(SP) ← YH
		YL	1	1	1	1	1	1	0	0	1	0	0	1					5	SP ← SP-1, M(SP) ← YL
		F	1	1	1	1	1	1	0	0	1	0	1	0					5	SP ← SP-1, M(SP) ← F
	POP	r	1	1	1	1	1	1	0	1	0	0	r1	r0					5	r ← M(SP), SP ← SP+1
		XP	1	1	1	1	1	1	0	1	0	1	0	0					5	XP ← M(SP), SP ← SP+1
		XH	1	1	1	1	1	1	0	1	0	1	0	1					5	XH ← M(SP), SP ← SP+1
XL		1	1	1	1	1	1	0	1	0	1	1	0					5	XL ← M(SP), SP ← SP+1	
YP		1	1	1	1	1	1	0	1	0	1	1	1					5	YP ← M(SP), SP ← SP+1	

APPENDIX A. E0C6233 INSTRUCTION SET

Classification	Mnemonic	Operand	Operation Code							Flag	Clock	Operation					
			B	A	9	8	7	6	5	4			3	2	1	0	I
Stack operation instructions	POP	YH	1	1	1	1	1	1	0	1	1	0	0	0		5	YH ← M(SP), SP ← SP+1
		YL	1	1	1	1	1	1	0	1	1	0	0	1		5	YL ← M(SP), SP ← SP+1
		F	1	1	1	1	1	1	0	1	1	0	1	0	↑ ↓ ↑ ↓ ↑ ↓	5	F ← M(SP), SP ← SP+1
	LD	SPH, r	1	1	1	1	1	1	1	0	0	0	r1	r0		5	SPH ← r
		SPL, r	1	1	1	1	1	1	1	1	0	0	r1	r0		5	SPL ← r
		r, SPH	1	1	1	1	1	1	1	0	0	1	r1	r0		5	r ← SPH
		r, SPL	1	1	1	1	1	1	1	1	0	1	r1	r0		5	r ← SPL
Arithmetic instructions	ADD	r, i	1	1	0	0	0	0	r1	r0	i3	i2	i1	i0	★ ↑ ↓	7	r ← r+i3~i0
		r, q	1	0	1	0	1	0	0	0	r1	r0	q1	q0	★ ↑ ↓	7	r ← r+q
	ADC	r, i	1	1	0	0	0	1	r1	r0	i3	i2	i1	i0	★ ↑ ↓	7	r ← r+i3~i0+C
		r, q	1	0	1	0	1	0	0	1	r1	r0	q1	q0	★ ↑ ↓	7	r ← r+q+C
	SUB	r, q	1	0	1	0	1	0	1	0	r1	r0	q1	q0	★ ↑ ↓	7	r ← r-q
		SBC	r, i	1	1	0	1	0	1	r1	r0	i3	i2	i1	i0	★ ↑ ↓	7
	r, q		1	0	1	0	1	0	1	1	r1	r0	q1	q0	★ ↑ ↓	7	r ← r-q-C
	AND	r, i	1	1	0	0	1	0	r1	r0	i3	i2	i1	i0	↓	7	r ← r∧i3~i0
		r, q	1	0	1	0	1	1	0	0	r1	r0	q1	q0	↓	7	r ← r∧q
	OR	r, i	1	1	0	0	1	1	r1	r0	i3	i2	i1	i0	↓	7	r ← r∨i3~i0
		r, q	1	0	1	0	1	1	0	1	r1	r0	q1	q0	↓	7	r ← r∨q
	XOR	r, i	1	1	0	1	0	0	r1	r0	i3	i2	i1	i0	↓	7	r ← r∨i3~i0
		r, q	1	0	1	0	1	1	1	0	r1	r0	q1	q0	↓	7	r ← r∨q
	CP	r, i	1	1	0	1	1	1	r1	r0	i3	i2	i1	i0	↓ ↓	7	r-i3~i0
		r, q	1	1	1	1	0	0	0	0	r1	r0	q1	q0	↓ ↓	7	r-q
	FAN	r, i	1	1	0	1	1	0	r1	r0	i3	i2	i1	i0	↓	7	r∧i3~i0
		r, q	1	1	1	1	0	0	0	1	r1	r0	q1	q0	↓	7	r∧q
	RLC	r	1	0	1	0	1	1	1	1	r1	r0	r1	r0	↓ ↓	7	d3 ← d2, d2 ← d1, d1 ← d0, d0 ← C, C ← d3
	RRC	r	1	1	1	0	1	0	0	0	1	1	r1	r0	↓ ↓	5	d3 ← C, d2 ← d3, d1 ← d2, d0 ← d1, C ← d0
	INC	Mn	1	1	1	1	0	1	1	0	n3	n2	n1	n0	↓ ↓	7	M(n3~n0) ← M(n3~n0)+1
	DEC	Mn	1	1	1	1	0	1	1	1	n3	n2	n1	n0	↓ ↓	7	M(n3~n0) ← M(n3~n0)-1
	ACPX	MX, r	1	1	1	1	0	0	1	0	1	0	r1	r0	★ ↑ ↓	7	M(X) ← M(X)+r+C, X ← X+1
	ACPY	MY, r	1	1	1	1	0	0	1	0	1	1	r1	r0	★ ↑ ↓	7	M(Y) ← M(Y)+r+C, Y ← Y+1
	SCPX	MX, r	1	1	1	1	0	0	1	1	1	0	r1	r0	★ ↑ ↓	7	M(X) ← M(X)-r-C, X ← X+1
	SCPY	MY, r	1	1	1	1	0	0	1	1	1	1	r1	r0	★ ↑ ↓	7	M(Y) ← M(Y)-r-C, Y ← Y+1
	NOT	r	1	1	0	1	0	0	r1	r0	1	1	1	1	↓	7	r ← \bar{r}

Abbreviations used in the explanations have the following meanings.

Symbols associated with registers and memory

A	A register
B	B register
X	XHL register (low order eight bits of index register IX)
Y	YHL register (low order eight bits of index register IY)
XH	XH register (high order four bits of XHL register)
XL	XL register (low order four bits of XHL register)
YH	YH register (high order four bits of YHL register)
YL	YL register (low order four bits of YHL register)
XP	XP register (high order four bits of index register IX)
YP	YP register (high order four bits of index register IY)
SP	Stack pointer SP
SPH	High-order four bits of stack pointer SP
SPL	Low-order four bits of stack pointer SP
MX, M(X)	Data memory whose address is specified with index register IX
MY, M(Y)	Data memory whose address is specified with index register IY
Mn, M(n)	Data memory address 000H–00FH (address specified with immediate data n of 00H–0FH)
M(SP)	Data memory whose address is specified with stack pointer SP
r, q	Two-bit register code r, q is two-bit immediate data; according to the contents of these bits, they indicate registers A, B, and MX and MY (data memory whose addresses are specified with index registers IX and IY)

r		q		Register specified
r1	r0	q1	q0	
0	0	0	0	A
0	1	0	1	B
1	0	1	0	MX
1	1	1	1	MY

Symbols associated with program counter

NBP	New bank pointer
NPP	New page pointer
PCB	Program counter bank
PCP	Program counter page
PCS	Program counter step
PCSH	Four high order bits of PCS
PCSL	Four low order bits of PCS

Symbols associated with flags

F	Flag register (I, D, Z, C)
C	Carry flag
Z	Zero flag
D	Decimal flag
I	Interrupt flag
↓	Flag reset
↑	Flag set
↕	Flag set or reset

Associated with immediate data

p	Five-bit immediate data or label 00H–1FH
s	Eight-bit immediate data or label 00H–0FFH
l	Eight-bit immediate data 00H–0FFH
i	Four-bit immediate data 00H–0FH

Associated with arithmetic and other operations

+	Add
-	Subtract
∧	Logical AND
∨	Logical OR
⊕	Exclusive-OR
★	Add-subtract instruction for decimal operation when the D flag is set

APPENDIX B. E0C6233 RAM MAP

PROGRAM NAME:																				
P	H	L	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F		
0	0	NAME MSB																		
		LSB																		
1	NAME MSB																			
		LSB																		
2	NAME MSB																			
		LSB																		
3	NAME MSB																			
		LSB																		
4	NAME MSB																			
		LSB																		
5	NAME MSB																			
		LSB																		
6	NAME MSB																			
		LSB																		
7	NAME MSB		TM3	SWL3	SWH3	K03	DFK03	EIK03	HVLD	SCTRG	CSDC	-	IK1	R03	R13	P03	TMRST	WDRST		
		LSB	TM2	SWL2	SWH2	K02	DFK02	EIK02	SVDDT	EIK10	ETI2	T12	IK0	R02	R12	P02	SWRUN	WD2		
			TM1	SWL1	SWH1	K01	DFK01	EIK01	EISWIT1	DFK10	ETI8	T18	SWIT1	R01	R11	P01	SWRST	WD1		
			TM0	SWL0	SWH0	K00	DFK00	EIK00	EISWIT0	K10	ETI32	T132	SWIT0	R00	R10	P00	IOC0	WD0		

PROGRAM NAME:																		
P	H	L	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	8	NAME MSB																
		LSB																
9	NAME MSB																	
		LSB																
C	NAME MSB																	
		LSB																
D	NAME MSB																	
		LSB																
E	NAME MSB																	
		LSB																
F	NAME MSB	SD3	SD7	SD6	SCS1				BZFQ		EV03	EV07				P13		
		SD2	SD6	SCS0							EV02	EV06				P12	CLKCHG	
		SD1	SD5	SE2						AMPDT	EV01	EV05				P11	OSCC	
		SD0	SD4	EISIO	ISIO					AMPON	EV00	EV04				P10	IOCC1	

PROGRAM NAME:																		
P	H	L	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
1	0	NAME MSB																
		LSB																
1	1	NAME MSB																
		LSB																
2	1	NAME MSB																
		LSB																
3	1	NAME MSB																
		LSB																
4	1	NAME MSB																
		LSB																
5	1	NAME MSB																
		LSB																
6	1	NAME MSB																
		LSB																
7	1	NAME MSB	TM3	SWL3	SWH3	K03	DFK03	EIK03	HVL3	SCTR3	CSDC		IK1	R03	R13	P03	TMRST	WDRST
		MSB	TM2	SWL2	SWH2	K02	DFK02	EIK02	SVD2	EIK10	ET12	T12	IK0	R02	R12	P02	SWRUN	WD2
		MSB	TM1	SWL1	SWH1	K01	DFK01	EIK01	EISWIT1	DFK10	ET18	T18	SWIT1	R01	R11	P01	SWRST	WD1
		LSB	TM0	SWL0	SWH0	K00	DFK00	EIK00	EISWIT0	K10	ET132	T132	SWIT0	R00	R10	P00	IOCO	WD0
F	1	NAME MSB	SD3	SD7	SCS1				BZFQ		EV03	EV07				P13		
		MSB	SD2	SD6	SCS0						EV02	EV06				P12	CLKCHG	
		MSB	SD1	SD5	SE2					AMPDT	EV01	EV05				P11	OSCC	
		LSB	SD0	SD4	EISIO	ISIO				AMPON	EV00	EV04				P10	IOCC	

APPENDIX C. E0C6233 I/O MEMORY MAP

Address *7	Register				Name	Init *1	1	0	Comment
	D3	D2	D1	D0					
70H	TM3	TM2	TM1	TM0	TM3	0			Timer data (clock timer 2 Hz)
	R				TM2	0			Timer data (clock timer 4 Hz)
	R				TM1	0			Timer data (clock timer 8 Hz)
	R				TM0	0			Timer data (clock timer 16 Hz)
71H	SWL3	SWL2	SWL1	SWL0	SWL3	0			MSB Stopwatch counter 1/100 sec (BCD) LSB
	R				SWL2	0			
	R				SWL1	0			
	R				SWL0	0			
72H	SWH3	SWH2	SWH1	SWH0	SWH3	0			MSB Stopwatch counter 1/10 sec (BCD) LSB
	R				SWH2	0			
	R				SWH1	0			
	R				SWH0	0			
73H	K03	K02	K01	K00	K03	*2	High	Low	Input port (K00–K03)
	R				K02	*2	High	Low	
	R				K01	*2	High	Low	
	R				K00	*2	High	Low	
74H	DFK03	DFK02	DFK01	DFK00	DFK03	0	Falling	Rising	Differential register (K00–K03)
	R/W				DFK02	0	Falling	Rising	
	R/W				DFK01	0	Falling	Rising	
	R/W				DFK00	0	Falling	Rising	
75H	EIK03	EIK02	EIK01	EIK00	EIK03	0	Enable	Mask	Interrupt mask register (K00–K03)
	R/W				EIK02	0	Enable	Mask	
	R/W				EIK01	0	Enable	Mask	
	R/W				EIK00	0	Enable	Mask	
76H	HVLD	SVDDT SVDON	EISWIT1	EISWIT0	HVLD	0	Heavy load	Normal	Heavy load protection mode register SVD evaluation data (at read-out) SVD ON/OFF (at writing) Interrupt mask register (stopwatch 1 Hz) Interrupt mask register (stopwatch 10 Hz)
	R/W	R W	R/W		SVDDT	0	Low voltage	Normal	
	R/W				SVDON	0	On	Off	
	R/W				EISWIT1	0	Enable	Mask	
77H	SCTRG SIOF	EIK10	DFK10	K10	SCTRG	–	Trigger	–	Serial interface clock trigger SIOF Interrupt mask register (K10) Differential register (K10) Input port (K10)
	W	R/W		R	SIOF	0	Run	Stop	
	R/W				EIK10	0	Enable	Mask	
	R/W				DFK10	0	Falling	Rising	
78H	CSDC	ETI2	ETI8	ETI32	CSDC	0	Static	Dynamic	LCD drive switch Interrupt mask register (clock timer 2 Hz) Interrupt mask register (clock timer 8 Hz) Interrupt mask register (clock timer 32 Hz)
	R/W				ETI2	0	Enable	Mask	
	R/W				ETI8	0	Enable	Mask	
	R/W				ETI32	0	Enable	Mask	
79H	–	TI2	TI8	TI32	–	*2			Unused *5 Interrupt factor flag (clock timer 2 Hz) *4 Interrupt factor flag (clock timer 8 Hz) *4 Interrupt factor flag (clock timer 32 Hz) *4
	R				TI2	0	Yes	No	
	R				TI8	0	Yes	No	
	R				TI32	0	Yes	No	
7AH	IK1	IK0	SWIT1	SWIT0	IK1	0	Yes	No	Interrupt factor flag (K10) *4 Interrupt factor flag (K00–K03) *4 Interrupt factor flag (stopwatch 1 Hz) *4 Interrupt factor flag (stopwatch 10 Hz) *4
	R				IK0	0	Yes	No	
	R				SWIT1	0	Yes	No	
	R				SWIT0	0	Yes	No	
7BH	R03	R02	R01	R00	R03	0	High	Low	Output port (R00–R03)
	R/W				R02	0	High	Low	
	R/W				R01	0	High	Low	
	R/W				R00	0	High	Low	
7CH	R13	R12	R11	R10	R13	0	High	Low	Output port (R13, \overline{BZ}) *6 Output port (R12, FOUT) *6 Output port (R11) Output port (R10, BZ) *6
	R/W				R12	0	High	Low	
	R/W				R11	0	High	Low	
	R/W				R10	0	High	Low	
7DH	P03	P02	P01	P00	P03	*2	High	Low	I/O port (P00–P03) Output latch reset at time of initial reset
	R/W				P02	*2	High	Low	
	R/W				P01	*2	High	Low	
	R/W				P00	*2	High	Low	
7EH	TMRST	SWRUN	SWRST	IOC0	TMRST	Reset	Reset	–	Clock timer reset *5 Stopwatch counter RUN/STOP Stopwatch counter reset *5 I/O control register 0 (P00–P03)
	W	R/W	W	R/W	SWRUN	0	Run	Stop	
	R/W				SWRST	Reset	Reset	–	
	R/W				IOC0	0	Output	Input	
7FH	WDRST	WD2	WD1	WD0	WDRST	Reset	Reset	–	Watchdog timer reset *5 Timer data (watchdog timer 1/4 Hz) Timer data (watchdog timer 1/2 Hz) Timer data (watchdog timer 1 Hz)
	W	R		WD2	0				
	R				WD1	0			
	R				WD0	0			

Address *7	Register				Name	Init *1	1	0	Comment
	D3	D2	D1	D0					
F0H	SD3	SD2	SD1	SD0	SD3	*3			Serial interface data register Low order (SD0–SD3)
	R/W				SD2	*3			
F1H	SD7	SD6	SD5	SD4	SD7	*3			Serial interface data register High order (SD4–SD7)
	R/W				SD6	*3			
F2H	SCS1	SCS0	SE2	EISIO	SCS1	1	*6	*6	Clock edge selection register (SCS0, SCS1)
	R/W				SCS0	1	*6	*6	
F2H					SE2	0	Rising	Falling	Clock edge selection register Interrupt mask register (serial interface)
					EISIO	0	Enable	Mask	
F3H	-	-	-	ISIO	-	*2			Unused *5 Unused *5 Unused *5
	R				ISIO	0	Yes	No	
F6H	BZFO	-	-	-	BZFO	0	2 kHz	4 kHz	Buzzer frequency selection register Unused *5 Unused *5 Unused *5
	R/W	R			-	*2			
F7H	-	-	AMPDT	AMPON	-	*2			Unused *5 Unused *5
	R			R/W	AMPDT	1	+ > -	- > +	
F7H					AMPON	0	On	Off	Analog comparator data Analog comparator ON/OFF
					-	*2			
F8H	EV03	EV02	EV01	EV00	EV03	0			Event counter Low order (EV00–EV03)
	R				EV02	0			
F8H					EV01	0			Event counter High order (EV04–EV07)
					EV00	0			
F9H	EV07	EV06	EV05	EV04	EV07	0			Event counter High order (EV04–EV07)
	R				EV06	0			
F9H					EV05	0			Event counter Low order (EV00–EV03)
					EV04	0			
FCH	-	EVRUN	-	EVRST	-	*2			Unused *5 Event counter RUN/STOP Unused *5 Event counter reset *5
	R	R/W	R	W	EVRUN	0	Run	Stop	
FCH					-	*2			Event counter reset *5
					EVRST	Reset	Reset	-	
FDH	P13	P12	P11	P10	P13	*2	High	Low	I/O port (P10–P13) Output latch reset at time of initial reset
	R/W				P12	*2	High	Low	
FDH					P11	*2	High	Low	I/O port (P10–P13) Output latch reset at time of initial reset
					P10	*2	High	Low	
FEH	-	CLKCHG	OSCC	IOC1	-	*2			Unused *5 CPU clock switch OSC3 oscillator ON/OFF I/O control register 1 (P10–P13)
	R	R/W			CLKCHG	0	OSC3	OSC1	
FEH					OSCC	0	On	Off	CPU clock switch OSC3 oscillator ON/OFF I/O control register 1 (P10–P13)
					IOC1	0	Output	Input	

Remarks

- *1 Initial value following initial reset
- *2 Not set in the circuit
- *3 Undefined
- *4 Reset (0) immediately after being read
- *5 Always "0" when being read
- *6 Refer to the "E0C6233 Technical Manual"
- *7 Page switching in I/O memory is not necessary

APPENDIX D. TROUBLESHOOTING

Tool	Problem	Remedy measures
ICE62R (ICE6200)	Nothing appears on the screen, or nothing works, after activation.	<p>Check the following and remedy if necessary:</p> <ul style="list-style-type: none"> • Is the RS-232C cable connected correctly? • Is the RS-232C driver installed? • Is SPEED.COM or MODE.COM on the disk? • Is the execution file correct? <ul style="list-style-type: none"> MS-DOS ICS6233J.EXE PC-DOS ICS6233W.EXE • Is the DOS version correct? <ul style="list-style-type: none"> MS-DOS Ver. 3.1 or later PC-DOS Ver. 2.1 or later • Is the DIP switches that set the baud rate of the main ICE62R (ICE6200) unit set correctly? • Is the breaker of the ICE62R (ICE6200) set to ON?
	The ICE6200 breaker tripped or the ICE62R fuse cut immediately after activation.	<p>Check the following and remedy if necessary:</p> <ul style="list-style-type: none"> • Are connectors F1 and F5 connected to the EVA6S32R correctly? • Is the target board power short-circuiting?
	<ILLEGAL VERSION ICE6200> appears on the screen immediately after activation.	The wrong version of ICE is being used. Use the latest version.
	<ILLEGAL VERSION PARAMETER FILE> appears on the screen immediately after activation.	The wrong version of ICS6233P.PAR is being used. Use the latest version.
	Immediate values A (10) and B (11) cannot be entered correctly with the A command.	<p>The A and B registers are reserved for the entry of A and B. Write 0A and 0B when entering A (10) and B (11).</p> <p><i>Example:</i></p> <pre>LD A, B Data in the B register is loaded into the A register. LD B, 0A Immediate value A is loaded into the B register.</pre>
	<UNUSED AREA> is displayed by the SD command.	This message is output when the address following one in which data is written is unused. It does not indicate problem. Data is correctly set in areas other than the read-only area.
	You can not do a real-time run in break-trace mode.	Since the CPU stops temporarily when breaking conditions are met, executing in a real-time is not performed.
	Output from the EVA is impossible when data is written to the I/O memory for Buzzer and Fout output with the ICE command.	Output is possible only in the real-time run mode.
SOG6233	An R error occurs although the address is correctly set in the segment source file.	<p>Check the following and remedy if necessary:</p> <ul style="list-style-type: none"> • Does the address symbol use capital letters? • Are the output ports set for every two terminals?

APPENDIX D. TROUBLESHOOTING

Tool	Problem	Remedy measures
ASM6233	An R error occurs although the final page is passed.	The cross assembler is designed to output "R error" every time the page is changed. Use a pseudo-instruction to set the memory, such as ORG or PAGE, to change the page. See "Memory setting pseudo-instructions" in the cross assembler manual.
MDC6233	Activation is impossible.	Check the following and remedy if necessary: <ul style="list-style-type: none"> • Is the number of files set at ten or more in OS environment file CONFIG.SYS?
EVA6S32R	The EVA6S32R does not work when it is used independently.	Check the following and remedy if necessary: <ul style="list-style-type: none"> • Has the EPROM for F.HEX and S.HEX been replaced by the EPROM for the target? • Is the EPROM for F.HEX and S.HEX installed correctly? • Is the appropriate voltage being supplied? (5V DC, 3A, or more) • Are the program ROMs (H and L) installed correctly? • Is data written from address 4000H? (When the 27C256 is used as the program ROM)
	Target segment does not light.	Check the following and remedy if necessary: <ul style="list-style-type: none"> • Is an EPROM with an access time of 250 ns or less being used for S.HEX. • Has the VADJ VR inside the EVA6S32R top cover been turned to a lower setting?

EPSON International Sales Operations

AMERICA

EPSON ELECTRONICS AMERICA, INC.

- HEADQUARTERS -
1960 E. Grand Avenue
El Segundo, CA 90245, U.S.A.
Phone: +1-310-955-5300 Fax: +1-310-955-5400

- SALES OFFICES -

West
150 River Oaks Parkway
San Jose, CA 95134, U.S.A.
Phone: +1-408-922-0200 Fax: +1-408-922-0238

Central
1450 East American Lane, Suite 1550
Schaumburg, IL 60173, U.S.A.
Phone: +1-847-517-7667 Fax: +1-847-517-7601

101 Virginia Street, Suite 290
Crystal Lake, IL 60014, U.S.A.
Phone: +1-815-455-7630 Fax: +1-815-455-7633

Northeast
301 Edgewater Place, Suite 120
Wakefield, MA 01880, U.S.A.
Phone: +1-781-246-3600 Fax: +1-781-246-5443

Southeast
4300 Six Forks Road, Suite 430
Raleigh, NC 27609, U.S.A.
Phone: +1-919-781-7667 Fax: +1-919-781-6778
1700 Spinnaker Drive
Alpharetta, GA 30005, U.S.A.
Phone: +1-770-754-4872 Fax: +1-770-753-0601

EUROPE

EPSON EUROPE ELECTRONICS GmbH

- HEADQUARTERS -
Riesstrasse 15
80992 Muenchen, GERMANY
Phone: +49-(0)89-14005-0 Fax: +49-(0)89-14005-110

- GERMANY -

SALES OFFICE
Breidenbachstrasse 46
D-51373 Leverkusen, GERMANY
Phone: +49-(0)214-83070-0 Fax: +49-(0)214-83070-10

- UNITED KINGDOM -

UK BRANCH OFFICE
G6 Doncastle House, Doncastle Road
Bracknell, Berkshire RG12 8PE, ENGLAND
Phone: +44-(0)1344-381700 Fax: +44-(0)1344-381701

- FRANCE -

FRENCH BRANCH OFFICE
1 Avenue de l'Atlantique, LP 915 Les Conquerants
Z.A. de Courtaboeuf 2, F-91976 Les Ulis Cedex, FRANCE
Phone: +33-(0)1-64862350 Fax: +33-(0)1-64862355

ASIA

- HONG KONG, CHINA -
EPSON HONG KONG LTD.
20/F., Harbour Centre, 25 Harbour Road
Wanchai, HONG KONG
Phone: +852-2585-4600 Fax: +852-2827-4346
Telex: 65542 EPSCO HX

- CHINA -

SHANGHAI EPSON ELECTRONICS CO., LTD.
4F, Bldg., 27, No. 69, Gui Jing Road
Caohejing, Shanghai, CHINA
Phone: 21-6485-5552 Fax: 21-6485-0775

- TAIWAN, R.O.C. -

EPSON TAIWAN TECHNOLOGY & TRADING LTD.
10F, No. 287, Nanking East Road, Sec. 3
Taipei, TAIWAN, R.O.C.
Phone: 02-2717-7360 Fax: 02-2712-9164
Telex: 24444 EPSONTB

HSINCHU OFFICE

13F-3, No. 295, Kuang-Fu Road, Sec. 2
HsinChu 300, TAIWAN, R.O.C.
Phone: 03-573-9900 Fax: 03-573-9169

- SINGAPORE -

EPSON SINGAPORE PTE., LTD.
No. 1 Temasek Avenue, #36-00
Millenia Tower, SINGAPORE 039192
Phone: +65-337-7911 Fax: +65-334-2716

- KOREA -

SEIKO EPSON CORPORATION
KOREA OFFICE
50F, KLI 63 Bldg., 60 Yoido-Dong
Youngdeungpo-Ku, Seoul, 150-010, KOREA
Phone: 02-784-6027 Fax: 02-767-3677

- JAPAN -

SEIKO EPSON CORPORATION
ELECTRONIC DEVICES MARKETING DIVISION

Electronic Device Marketing Department
IC Marketing & Engineering Group
421-8, Hino, Hino-shi, Tokyo 191-8501, JAPAN
Phone: +81-(0)42-587-5816 Fax: +81-(0)42-587-5624

ED International Marketing Department I
(Europe & U.S.A.)
421-8, Hino, Hino-shi, Tokyo 191-8501, JAPAN
Phone: +81-(0)42-587-5812 Fax: +81-(0)42-587-5564

ED International Marketing Department II
(Asia)
421-8, Hino, Hino-shi, Tokyo 191-8501, JAPAN
Phone: +81-(0)42-587-5814 Fax: +81-(0)42-587-5110



In pursuit of **“Saving” Technology**, Epson electronic devices.
Our lineup of semiconductors, liquid crystal displays and quartz devices
assists in creating the products of our customers’ dreams.
Epson IS energy savings.

EPSON

SEIKO EPSON CORPORATION
ELECTRONIC DEVICES MARKETING DIVISION

■ Electronic devices information on Epson WWW server

<http://www.epson.co.jp>

First issue JANUARY 1992, Printed MARCH 1999 in Japan ® A